


Amersham - Corner TV Unit

Assembly Instructions - Please keep for future reference

881/4968



Dimensions

Width - 120cm

Depth - 44cm

Height - 50cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**



Safety and Care Advice

Important – Please read these instructions fully before starting assembly


- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

- This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.

- The product has been treated with a wax and oil finish to prevent dirt ingress and preserve moisture.

- On unpacking the furniture you may notice an odour due to this treatment; this will disappear once the furniture is unpacked and assembled after a period of time.

- This process may leave some staining on the packaging material; please take care to ensure this does not transfer to clothing or carpeted surfaces during assembly.



as this could damage the unit. Only use hand screwdrivers.

- We do not recommend the use of power drill/drivers **for inserting screws**,

- Parts of the assembly will be easier with 2 people.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.
- Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.


- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

Please check you have all the panels listed below



1 Top panel (120 x 44cm)



2 Base panel (114.4 x 38cm)




3 Front frame x 2 (103.6 x 6.5cm)



4 Inside panel x 2 (37.5 x 38cm)



5 Shelf (36.4 x 37.4cm)




6 Door x 2 (30.4 x 30.4cm)




7 Right side panel (48 x 14.4cm)



8 Left side panel (48 x 14.4cm)




9 Right front frame (48 x 9.2cm)




10 Left front frame (48 x 9.2cm)



11 Left back column (48 x 6.5cm)



12 Right back column (48 x 6.5cm)



13 Large back panel (54 x 30cm)



14 Small back panel x 2 (39 x 37cm)

















15 Block x 4 (10 x 2cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Wooden dowel x 24	B  14mm Screw x 26	C  35mm Screw x 16
D  40mm Screw x 6	E  22mm Bolt x 2	F  Metal dowel x 14
G  Locking nut x 14	H  Door hinge x 4	I  Door handle x 2
J  Clip x 2	K  Plug x 2	L  Metal bracket x 1
M  Door spacer x 1	N  Nail x 20	


Tools required



Phillips screwdriver
(medium & large)



Ruler/tape
measure



Small
hammer



Eye protection
(when using a
hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Fixing right front frame to the right side panel
(Two people required for an easier assembly).

a: Insert right side panel **7** into right front frame **9** through joints.





Note:

Before fixing blocks **15** into place it is important to ensure that the slot and groove of parts **7** and **9** are fully pushed together and lined up correctly at the top and bottom.


b: Place blocks **15** between the two marks as shown. First fix to the side panel using screws **C**.

c: Fix front frame through blocks **15** using screws **C**.


a:



c:



Attention:
correct position.



Step 2

Fixing left front frame to the left side panel
(Two people required for an easier assembly).

a: Insert left side panel **8** into left front frame **10** through joints.




Note:

Before fixing blocks **15** into place it is important to ensure that the slot and groove of parts **8** and **10** are fully pushed together and lined up correctly at the top and bottom.


b: Place blocks **15** between the two marks as shown. First fix to the side panel using screws **C**.

c: Fix front frame through blocks **15** using screws **C**.


a:




b:



c:



Attention:
correct position.



Assembly Instructions

Step 3


Fitting Metal dowels.

Screw metal dowels **F** into right side panel **7**, left side panel **8** and top panel **1**.




Note: Insert metal dowels as far as shown.

Do not over tighten.



Step 4

Insert dowels **A** into the indicated parts.




Assembly Instructions

Step 5

Fit shelf **5** into the holes on inside panels **4**.



Important! Panels must be positioned as shown in the picture.




Step 6

Fixing base panel.

With help, fit inside panels **4** to the base panel **2** then fix it using screws **D**.


Do not over tighten screws.



Assembly Instructions

Step 7

Insert front frames **3** into the holes on right side panel **7**.



Step 8




Fixing base panel.

With help, fit base panel **2** to the right side panel.

Insert 2 locking nuts **G** into base panel where shown.

Use a screwdriver to turn locking nuts **G** clockwise to lock.

Do not over tighten.



Assembly Instructions

Step 9



Fixing right side panel.

With help, place left side panel **8** properly ensuring dowels and front frames are all fit into their holes at the same time.

Insert 2 locking nuts **G** into base panel where shown.


Use a screwdriver to turn locking nuts **G** clockwise to lock.

Do not over tighten.



Step 10


Fix metal bracket **L** in the base panel **2** and bottom front frame **3** using screws **B** as shown.



Assembly Instructions

Step 11


Fixing top panel.





 **Important:** With help, carefully turn the product upside down on top of panel **1**.

Insert 10 locking nuts **G** into the panels shown.

Use a screwdriver to turn locking nuts **G** clockwise to lock.

Do not over tighten.


 With help, stand the product upright.



Step 12

Fitting hinges to doors.

Attach hinges **H** in the pre marked holes on doors **6** using screws **B** as shown.




Assembly Instructions


Step 13

Hanging doors.

a: With help, centralise the doors in the opening of the cabinet using the door spacer **M** to ensure correct spacing, as shown.

b: From inside the cabinet fix hinges using screws **B** as shown.

 **Note:** To ensure the alignment of the doors is correct, centralise the doors in the opening before attaching to the cabinet.



Step 14


Hinge adjustment.

a: To move doors up or down: loosen screws shown and move doors to suit.

Once doors are aligned, re-tighten screws.

b: To move doors left or right: loosen screws shown and move doors to suit.

Re-tighten screws.



Assembly Instructions

Step 15


Fitting door lock.

a: Screw clip **J** in place using screws **B**. Ensure that the 2 small wheels are flush with the edge of the base as shown in the diagram.


b: Insert plug **K** into clip **J**, ensuring they are leveled as shown in the diagram.

c: Push the door against plug **K**. This will make 2 small marks on the door as shown in the diagram.


d: The door can then be opened and plug **K** can be screwed into place using the 2 marks made as a guide. This will ensure that the 2 parts of the door clips are lined up correctly.




a:




b:



c:




d:



Step 16

Fitting handles to doors.

Attach handles **I** to the doors using bolts **E** as shown.



Assembly Instructions

Step 17

Fixing back panel.






Important:

Cabinet **MUST** be 'square' when back panels are attached.

With help, turn cabinet upside down.



a: Slide large back panel **13** within grooves and then attach it using nails **N**.

a:




b: Place small back panels **14** within grooves and then attach using nails **N**.

b:



Attention:



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**

Your 1 Year Guarantee

Peace Of Mind

Knowing Your Furniture Is Protected

Protection received within the Manufacturer's Guarantee	Optional Added Protection with Furniture Care
Covers you for manufacturing defects for 1 year.	Covers you for up to 2 years for specific structural defects following the expiry of the manufacturer's guarantee.
In the event of a problem within this time please call 0345 640 0800 , or visit an Argos store. Please retain your receipt and order number as proof of purchase.	Plus - covers you for accidental damage up to 3 years for incidents such as household spills, rips, tears and burns. Accidental damage cover begins from the moment your plan starts.
	If you want to purchase Furniture Care visit https://argos.productaftercare.co.uk or go into an Argos store
Key exclusions applying to both the Manufacturer's Guarantee and Furniture Care include where the fault is due to misuse, abuse, deliberate damage, wear and tear, neglect, use in contravention with the instructions, or if the product has been the subject of unauthorised alterations or commercial use (for full list of exclusions please visit https://argos.productaftercare.co.uk or visit an Argos store for more information). You have up to 45 days post purchase to take out Furniture Care. Terms and conditions apply. Your statutory rights remain unaffected.	

Register

For Your Manufacturer's Guarantee

Thank you for choosing Argos Home.

We hope you love your shiny new things!

To provide you with the best possible after sales service, don't forget to visit **<https://argos.productaftercare.co.uk>** where you can **register** for your guarantee.

Once you've registered, you can upload your receipt to store safely online, alongside details of our after sales support service, ready at hand should you need it.

You can also take out Furniture Care which protects you against accidental damage, from the moment you take the plan out, to keep your new furniture looking newer for longer.

Register Today

<https://argos.productaftercare.co.uk>