

MAX DESK

Assembly Instructions - Please keep for future reference

MAX-DS-AW18-A



Dimensions

Width - 110cm

Depth - 45cm

Height - 75cm

Tools required



Important – Please read these instructions before assembly

If you need help or have damaged or missing parts, email:
customerservices@habitat.co.uk or call: 0344 499 4686

habitat 



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

Check you have all the components and tools listed on the front cover and page 3.

Remove all fittings from the plastic bags and separate them into their groups.

Keep children and animals away from the work area, small parts could choke if swallowed.

Make sure you have enough space to layout the parts before starting.

Do not stand or put weight on the product, this could cause damage.

Assemble the item as close to its final position (in the same room) as possible.

Do not place furniture directly in front of radiators, fires or any other source of heat.

Assemble on a soft level surface to avoid damaging the unit or your floor.



Assembly requires at least 2 people



We do not recommend the use of power drill/drivers for inserting screws, as this could

damage the unit. Only use hand screwdrivers.

Dispose of all packaging carefully and responsibly.

Please see recommended maximum loading guidance near end of this document.

General care and maintenance

Take care when moving furniture - dragging pieces across the floor will damage the joints. **Always lift and move.**

From time to time check that there are no loose fittings. Tighten as necessary.

Avoid exposing your furniture to direct and prolonged periods of sunlight and heat sources as fading and cracking may occur.

Take care to prevent sharp objects e.g. toys, buckles and heels from coming into contact with your furniture, and avoid contact with chemicals e.g. cosmetics or hairs products which may permanently mark the surface.

Cleaning and care

Dust regularly with a clean dry cloth.

The use of furniture polish or spray is not necessary or recommended.

Reapply oil every year.

Wipe up any spills immediately with a damp cloth and then dry the surface with a clean dry duster.

Light marks can be sanded away with very fine grade sandpaper and the whole surface re-oiled.

Apply a generous coating of Becker Acroma GA932 oil. Allow to absorb for 1-2 hours and wipe dry.

Repeat this procedure for periodic cleaning.

Always use place mats and coasters to protect the surface from moisture and heat.

Follow directions given.

General information

If for any reason you should have problems with your Habitat product, please contact the store from which you purchased it.

Please retain your receipt as proof of purchase.

If you have any comments or suggestions regarding this product, assembly instructions or service

received, please contact the store or Habitat Head Office via its web site: www.habitat.co.uk

or write directly to: Habitat Retail Ltd.
489-499 Avebury Boulevard,
Milton Keynes MK9 2NW


Components

If you need help or have damaged or missing parts, email: customerservices@habitat.co.uk or call: 0344 499 4686


Please check you have all the panels listed below



WARNING! Keep children away from the assembly area. Small component parts are a choking hazard. Dispose of plastic bags safely.



Retain batch code label.




Q X4




R X1



S X1



T X1



U X1



V X4



A X23




B X23




C X14



D X4



E X1



F X2



G X2




H X1




I X4




J X12



K X1




L X1



M X1




N X1



O X2



P X2



Assembly Instructions

Assembly Instructions

Please keep safe for future reference

Before assembling the furniture please identify all component parts.



It would be sensible to assemble the furniture as close to its final position as possible.

Do not place furniture directly in front of radiators, fires or any source of heat.

Ensure the surface on which you are assembling the furniture is flat and clear of anything that might scratch it.

Check all packaging carefully for components and fittings before discarding it.

Step1:



Please note : Do not tighten the screws or bolts fully until the unit is completely assembled.



Ⓐ X3



Ⓥ X4




Ⓖ X2




Ⓒ X2

Assembly Instructions

Step2:




Step3:




Assembly Instructions

Step4:





Step5:






Assembly Instructions

Step6:





Step7:





Assembly Instructions

Step8:



Ⓑ X3






Step9:



Ⓑ X3





Assembly Instructions

Step10:



Assembly Instructions


Step11:






Take care when standing product upright

Assembly Instructions

Step12:





Step13:




Assembly Instructions

Step14:




Ⓑ X11



Assembly Instructions

Step15:



WARNING!

In order to prevent overturning this product must be used with the wall attachment device provided.

Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent topple over :-



- Use the wall attachment devices provided
- Never allow children to climb or hang on drawers
- Do not overload the drawers beyond maximum recommended loading.
- Place heaviest items in the lower drawers or shelves.
- Unless specifically designed to accommodate, do not set TV's or other heavy objects on top of this product
- Never open more than one drawer at a time

An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt consult a qualified trades person.


Always ensure that the wall to be drilled into is free from hidden electrical wires, water and gas pipes.

Assembly Instructions

Step16:







Step17:



Ⓢ X1

Assembly Instructions




Step18:



 (R) X1


Assembly Instructions

Step19:




Assembly Instructions

Step20:





Metal strike plate for magnetic door fitting.





Please Note!

Adjusting Push-To-Open Door Mechanism
If door does not open when pushed in it could be because the push-to-open mechanism needs adjustment. Simply turn the magnetic end of the mechanism to screw it out further so that it makes better contact with the metal strike plate.



Assembly Instructions

Step21:



A Guide to - Wall Mounting & Fixings

Important note:

Wall Fixings:



- because of the variety of different wall types, Habitat cannot provide you with the exact fixings you will need to fix this product to the wall.

You must first identify the type of wall you intend to fix product onto and then contact your local hardware store to get the appropriate fixings.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:** Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.