

BUSH

Instruction manual

Table Top Beverage Chiller

TTCHILLO



You'll soon be enjoying your new Table Top Beverage Chiller

It all begins here, with your instructions. Don't worry, there's nothing too technical coming up. Just simple, step-by-step guidance to get you up and running quickly. Sound good? Then let's get started.

Help and Guidance

We're here to help you get the most from your Table Top Chiller. Should you require any guidance, a simple solution can often be found online at:

www.bush-support.co.uk

If you still require further assistance, call one of our experts on **01759 487838**.

Contents

1 Safety information

Safety information 6

2 Getting to know your Table Top Chiller

Ready? Let's begin 10

Accessories 12

3 Installing your Table

Top Chiller

Installation requirements 14

Unpacking 14

4 Using your Table Top Chiller

Arranging your drinks in the Table Top Chiller 17

5 Care and Maintenance

Cleaning 20

Maintenance actions

Technical specifications 21

6 Product support

Troubleshooting 24

Help and assistance 25

Declaration of conformance to product standards 26

Disposal 26

Guarantee 27

This page is left intentionally blank

Safety information

1





Safety information

Important - Please read these instructions fully before installing or operating

General warnings

WARNING: Keep ventilation openings, in the appliance enclosure or to the inside unit, clear of obstruction.

WARNING: Do not use electrical appliances inside the storage compartments of the appliance, unless they are of the type recommended by the manufacturer.

WARNING: Do not damage the refrigerant circuit.

WARNING: Due to the instability of the appliance, it must be fixed in accordance with the instructions to avoid a hazard.

WARNING: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: This appliance is intended to be used in household and similar applications such as

- staff kitchen areas in shops, offices and other working environments;
- farm houses and by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- catering and similar non-retail applications.

• This appliance contains the coolant Isobutane (R600a), a natural gas which is environmentally friendly. Although it is flammable, it does not damage the ozone layer and does not increase the greenhouse effect. The use of this coolant has, however, led to a slight increase in the noise level of the appliance. In addition to the noise of the compressor, you might be able to hear the coolant flowing around the system. This is unavoidable, but does not have any adverse effect on the performance of the appliance.

Care must be taken during the transportation and installation of the appliance that no parts of the cooling system are damaged. Leaking coolant can damage the eyes.

In the event of any damage:

- Avoid open flames and anything which creates a spark,
- Disconnect from the mains,
- Air the room in which the appliance is located for at least an hour.
- Contact the BUSH Service Department for advice.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,



Safety information

Important - Please read these instructions fully before installing or operating

- Whilst carrying and positioning the appliance care must be taken not to damage the cooler gas circuit at the rear of the appliance
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- This appliance is not designed for commercial use. It is intended for use in domestic households only.
- This appliance is not intended for outdoor use. It must only be used as a domestic appliance to cool and store food & drinks.
- If the socket does not match the refrigerator plug, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to prevent any hazard occurring.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- Before connecting the appliance, make sure that the connection data on the data plate (voltage and frequency) matches the mains electricity supply. This data must correspond in order to avoid the risk of damage to the appliance. Consult a qualified electrician if in any doubt.
- Do not cover the body or top of fridge. This affects the performance of your fridge.
- Ensure the accessories are secured during transportation to prevent damage.



Safety information

Important - Please read these instructions fully before installing or operating

Before using your appliance

- Before switching on your appliance for the first time, ensure it is positioned in its desired final location and is in its upright position for at least 3 hours before plugging in and switching on the power. Otherwise you may damage the compressor.
- You may experience an odour from the appliance when it is operated for the first time. This is normal and will fade when your appliance starts to cool.



- **Warning: Risk of fire / flammable materials**
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- Children aged from 3 to 8 years are allowed to load and unload refrigerating appliances.
- To avoid contamination of food, pay attention to the following:
 - Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance;
 - Clean regularly surfaces that can come in contact with food and accessible drainage systems;
 - Clean water tanks if they have not been used for 48 hours; flush the water system connected to a water supply if water has not been drawn for 5 days;
 - Store raw meat and fish in suitable containers in the refrigerator so that it is not in contact with or drip onto other food;
 - Two-star frozen-food compartments are suitable for storing pre-frozen food, storing or making ice-cream and making ice cubes;
 - One, two and three-star compartments are not suitable for the freezing of fresh food;
 - If the refrigerating appliance is left empty for long periods, switch off, defrost, clean, dry and leave the door open to prevent mould developing within the appliance.

**Getting to know your
Table Top Beverage
Chiller**

2



Getting to know your

You'll be up and running in no time

Ready? Let's begin...


Please read these instructions carefully. They contain important information which will help you get the best from your Table Top Beverage Chiller and ensure safe and correct installation and operation.

If you require any further assistance, our technical experts are happy to help. For full details, refer to the product support section at the end of these instructions.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,


Getting to know your Table Top Chiller

You'll be up and running in no time



Controls

Image shows the back of the unit



- To start the drinks chiller, turn the temperature control to the position corresponding to the desired cooling. The temperature of the chiller is controlled by adjusting/setting the thermostat control knob, this is located at the back of the unit as shown in the diagram above.
- The settings 1 - 5 (MAX) regulate the interior temperature of the refrigerator. Setting 1 (MIN) = lowest setting (warmest internal temperature) Setting 5 (MAX) = highest setting (coldest internal temperature)

THE TEMPERATURE VARIATION IS 0-10°C

- **If the thermostat (dial) is set too cold, beverages may become frozen. In extreme cases, glass containers may even break. Please adjust temperature to the product manufacturer's recommendation.**

Getting to know your Table Top Chiller

Accessories



Chrome Shelf x 1

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,

Installing your Table Top Beverage Chiller

3



Installing your Table Top Chiller

Bringing it all together

Installation requirements

Before starting to use your drinks chiller, you should pay attention to the following points:

- Operating voltage for your chiller is 220-240V at 50Hz.
- We do not take the responsibility of the damages that occur due to ungrounded usage.
- Do not place your appliance in direct sunlight.
- Your appliance should be at least 50 cm away from stoves, Gas ovens and heaters, and should be at least 5 cm away from electrical ovens.
- Your drinks chiller should never be used outdoors or left out in the rain.
- When your drinks chiller is placed next to a deep freezer, there should be at least 2 cm between them to prevent humidity on the outer surface.
- Do not place anything on your drinks chiller, and install your drinks chiller in a suitable place so that there is at least 15cm clearance at the top.
- Before using your drinks chiller, wipe all parts with warm water ,then dry. Place all parts back in the appliance after cleaning.
- This appliance should be placed against a wall with a free distance of at least 75mm.

Unpacking

- Please make sure that when unpacking your appliance that it is carried out in a safe manner.
- Ensure the packaging is disposed of in accordance to local regulation.
- Do not allow children to play with the packaging material, e.g. plastic bags and wrappings. **Danger of suffocation.**

Levelling Feet

- The appliance must be installed level in order for it to work properly. If the unit is not level, the doors and magnetic seal alignments will not be covered properly.
- To level the unit, adjust one or both levelling feet at the base of the unit.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,

Installing your Table Top Chiller

Bringing it all together

Electrical connection



Any electrical work that is required to install this appliance **MUST** be carried out by a qualified electrician.



Warning: THIS APPLIANCE MUST BE EARTHED

Before making any electrical connections, ensure that:

- Electrical safety is only guaranteed when the earth system of your house in accordance with the related local regulations.
 - Do not bend, stretch or pull the supply cable to avoid electric shock.
 - Ensure the power socket is suitable for the Maximum power of the machine (fuses in the power circuit must be 13 amp).
 - The supply voltage should be the same as that indicated in the technical specifications and the appliance rating plate.
 - The appliance should be earthed and in compliance with the applicable law.
 - When installed, the power socket must be within easy reach.
 - If the socket outlets in your home are not suitable for the plug supplied with this unit check with a qualified electrician for replacement.
 - To avoid the risk of overloading your plug socket, the use of adapters, multiple connectors or extension cables are not recommended. The appliance must be connected to a 220-240 volt 50Hz AC supply by mean of a three pin socket, suitably earthed and protected by a 13 amp fuse.
- Should the fuse need to be replaced, a 13 amp fuse approved to BS1362/A must be used.
- The plug contains a removable fuse cover that must be refitted when the fuse is replaced. If the fuse cover is lost or damaged, the plug must not be used until a replacement cover has been fitted or the plug is replaced.
 - A damaged plug should be cut off as close to the plug body as possible, the fuse should be removed and the plug disposed of safely.

Plug replacement (UK & Ireland only)

Should you need to replace the plug; the wires in the power cable are coloured in the following way:

Blue - Neutral ' N '

Brown - Live ' L '


Green & Yellow - Earth ' E '

The green & yellow wire must be connected to the terminal in the plug that is marked with the letter E or by the earth symbol.


The blue wire must be connected to the terminal that is marked with the letter N.

The brown wire must be connected to the terminal that is marked with the letter L.

If power supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.



If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.



4 Using your Table Top Beverage Chiller

Using your Table Top Chiller

Getting the most from your appliance

Arranging drinks in your Table Top Chiller

Fridge compartment

- To reduce humidity and consequent increase of frost, never place liquids in unsealed containers in the mini chiller. Frost tends to concentrate in the coldest parts of the evaporator and in time will require more frequent defrosting.
- Never place warm drinks in the refrigerator. Warm drinks/liquids should be allowed to cool at room temperature and should be arranged to ensure adequate air circulation in the fridge compartment.
- Nothing should touch the back wall as it will cause frost and the packages can stick on the back wall. Do not open the chiller door too frequently.
- Always store drinks and liquids in an upright position to avoid spillages.
- Always make sure drinks are sealed to the manufacturers' recommendation.


Reversing the Door Swing

Tools required: Phillips style screwdriver / Flat bladed screwdriver




- Ensure the unit is unplugged and empty.
- To take the door off it is necessary to tilt the unit backwards. You should rest the unit on something solid, e.g. a chair just below the top panel.
- All parts removed must be saved to do the reinstallation of the door.
- Do not lay the unit flat as this may damage the coolant system.
- We recommend that 2 people handle the unit during assembly.


1. Remove the top right hinge cover.




2. Undo the screws. Then remove the hinge bracket.




- Remove the top left screw cover.
Place it on the other side of the unit.




- Lift the door and place it on a padded surface to prevent it from scratching.




- Remove the adjustable foot, and remove the screws of the bottom hinge.



- Remove the adjustable foot and the screws of the other side.



- Screw the bottom hinge into place on the new side. Also screw in the levelling foot.



The longer adjustable foot must be assembled to bottom hinge bracket, and the shorter foot is for the support of the other side.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Care and maintenance 5



Care and maintenance

Looking after your appliance

Cleaning your appliance

- Make sure you unplug the fridge before starting to clean it.
- Do not pour water directly over your appliance.
- You can wipe the inner and outer sides with a soft cloth or a sponge using warm soapy water.
- Remove parts individually and clean by hand with soapy water. Do not place in dishwashers.
- Never use flammable, explosive or corrosive material for cleaning your appliance
- You should clean the condenser periodically to keep your appliance running efficiently. Make sure your appliance is unplugged before cleaning.
- Dusts behind the chiller and on the ground shall be timely cleaned to improve the cooling effect and energy saving.
- The interior of the appliance should be cleaned regularly to avoid odor.
- Check the door gasket regularly to make sure there are no debris.
- Please turn off the power before cleaning, remove all food, shelves, drawers, etc.
- Clean the door gasket with mild soap and water.
- Use a soft cloth or sponge to clean the inside of the chiller, with two tablespoons of baking soda and a quart of warm water. Then rinse with water and wipe clean, and open the door and dry it naturally before the power is turned on.
- For areas that are difficult to clean in the chiller (such as narrow sandwiches, gaps or corners), it is recommended to wipe them regularly with a soft rag, soft brush, etc. and when necessary, combined with some auxiliary tools (such as thin sticks) to ensure no contaminant accumulation in these areas.
- Do not use soap, detergent, scrub powder, spray cleaner, etc., as these may cause odors in the interior of the refrigerator.
- Clean the wire shelf with a mild detergent and dry with a soft cloth.
- Wipe the outer surface of the chiller with a soft cloth dampened with soapy water, detergent, etc., and then wipe dry.
- Do not use hard brushes, clean steel balls, wire brushes, abrasives, such as toothpastes, organic solvents (such as alcohol, acetone, banana oil, etc.), boiling water, acid or alkaline items to clean refrigerator considering that this may damage the chiller surface and interior. Boiling water and benzene may deform or damage plastic parts.
- Do not rinse with water so as not to affect the electrical insulation properties.

Care and maintenance

Looking after your appliance

Technical specification

Model	TTCHILL0
Storage volume	48L
Voltage and frequency	220-240V AC/50Hz
Climate class	N
Energy consumption	0.282k.Wh/24h
Rated current	0.5A
Refrigerant	R600a/17g
Energy rating	A+
Size WxDxH (mm)	430x475x510

We apologise for any inconvenience caused by minor inconsistencies within these instructions that may occur due to product improvements and development.

All images and drawings are for illustration purposes only.

This page is left intentionally blank

Product support

6



Product support

Help is always at hand

Troubleshooting

**DO NOT ATTEMPT TO REPAIR THIS TABLE
TOP CHILLER YOURSELF. CALL BUSH
PRODUCT SUPPORT ON 01759 487838**

PROBLEM	SOLUTION
SMELL/ODOURS	<ul style="list-style-type: none">-Check all the food and drink that are in the fridge is in date and correctly packaged. If it isn't then it should be removed immediately or repackaged.-Check for spillages on each shelf, rack and drawer. You may need to remove the drawers to check that no spillages have settled underneath them. Spillages that have not been cleaned and have been left can cause smells and unwanted odours.
THE DOORS DO NOT CLOSE PROPERLY	<ul style="list-style-type: none">-Ensure there are no obstructions preventing door closure.-Check the door compartments and shelves are correctly in place.-Check the door seal is not warped or torn.-Check the appliance is level.
UNUSUAL NOISES	<ul style="list-style-type: none">-Check that the appliance is on a flat, level surface and is stable.-Check the spacing's around the appliance and ensure it is not touching other items.-Bubbling and gurgling sound:<ul style="list-style-type: none">• This noise is emitted as the coolant fluid flows through the pipes within the system.• This is the normal sound of water flowing into the drain trough during the defrosting process. If the appliance is operating noisily (compressor noise): This is normal. This noise indicates that the compressor is operating normally . As the compressor is being energized, it might run a bit more noisily for a short period of time.-Contraction and expansion of the inside walls may cause popping and cracking noises.
THE FRIDGE DOOR WILL NOT OPEN	<ul style="list-style-type: none">-If the door has just been opened, leave it for a few minutes to allow the air pressure to equalise before trying again.
THE COMPRESSOR RUNS CONSTANTLY	<ul style="list-style-type: none">-The temperature is set too cold: select a lower (warmer) setting.-The door is open, or something is obstructing proper door closure.-The door gaskets are worn, dirty or damaged.-Large quantities of food have been added to the fridge.-The room temperature is hotter than usual.
THE EXTERNAL FRIDGE SURFACE IS WARM	<p>The exterior walls can be warmer than room temperature. This is normal while the compressor works to transfer heat from inside the fridge cabinet.</p>

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,

Product support

Help is always at hand

Help and assistance

If you require any technical guidance or find that your Table Top Chiller is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions or online at www.bush-support.co.uk

If you still require further assistance, call one of our experts on **01759 487838***. To help give us give you a fast and efficient service please have the following information ready:

Model Ref.	<input type="text"/>	You can find these on the rating plate - a small information panel (usually a sticker or metal plate) on the rear of your appliance
Serial number	<input type="text"/>	
Date of purchase	<input type="text"/>	This will be shown on your receipt

Local call rates applies*

Lines open 8am-7pm Monday to Saturday and 10am-4pm Sunday.

*Calls to BUSH enquiry lines may attract a charge and set up fee from residential lines depending on your call plan/tariff. Mobile and other providers costs may vary, see www.bt.com/pricing for details.

For Security and training purposes, telephone calls to and from customer service centres maybe recorded and monitored. Calls from Republic of Ireland will attract international call charges.

or online at www.bush-support.co.uk If you still require further assistance, call one of our experts on **01759 487838**.

Product support

Help is always at hand

Declaration of conformance to product standards

This appliance conforms to all relevant standards applicable to domestic appliances sold in the UK

Old fridges and freezers contain isolation material and refrigerant with CFC. Therefore, take care not to harm the environment when you are discarding your old fridges.

Disposal



This appliance/fitting is marked according to the European directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE).

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol on the product, or on the documents accompanying the product, the **crossed out wheeled bin** symbol, indicates that this appliance/fitting may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery and recycling of this product, please contact your local authority, your household waste disposal service or the retailer where you purchased the product.

Old fridges and freezers contain isolation material and refrigerant with CFC. Therefore, take care not to harm the environment when you are discarding your old fridges.



Call us now and activate your 12 month guarantee

Thank you for choosing Bush. Your new product is guaranteed against faults and breakdowns for 12 months. Don't forget to register it with us today so we can provide you with our best possible after-sales service and useful updates.

www.bushregistration.co.uk

FREEPHONE*

0800 597 8548

Lines are open 8am - 8pm, 365 days a year. *Calls may be recorded and monitored.

Your Bush Guarantee

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from who your purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the manual.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- Bush disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

Important Data Protection Information

To find out how we and Domestic & General Insurance PLC use your data, please refer to the guarantee registration material or visit www.bushregistrations.co.uk

Guarantor: Argos Limited - 489 - 499 Avebury Blvd. - Milton Keynes - MK9 2NW

or online at www.bush-support.co.uk If you still require further assistance, call one of our experts on **01759 487838**.

BUSH

Contact:

www.bush-support.co.uk

Helpline: **01759 487838**