

COZYTEK

Washable Electric Blanket

CZEBD CZEBK

CZEBS

Please read and
retain for future
reference



www.futura-direct.co.uk

Search for
***futura*direct**
on You**Tube**

**For in-depth
user guides &
tutorials**

Follow Us @:



COZYTEK Washable Electric Blanket

Thank you for choosing our Washable Electric Blanket which has been designed to give many years of service under normal use. Please be sure to read this user's manual carefully before using the unit. If you should encounter any problems, please contact a qualified service technician for help.

SPECIFICATIONS

Voltage: 220 - 240V~ 50Hz

Model: CZEBS

Rated Power: 1 x 35W

CZEBS Size: 135 x 65 cm (Single size)

Model: CZEBD

Rated Power: 1 x 70W

Size: 120 x 135 cm (Double size)

Model: CZEBK

Rated Power: 1 x 80W

Size: 165 x 137 cm (King Double size)

How to use

1. Unfold your electric blanket and place directly onto the mattress with the power lead near the edge of the pillow. If using a mattress protector this goes over the electric blanket.
2. Use the support ties to secure the blanket to the mattress.
3. Once securely attached to the mattress, connect the controller to the mattress, plug in to a power point, and switch on.
4. It is recommended that the controller is set to either position "2" or "3" for 15 – 20 minutes before going to bed and then can be turned down to setting "1" or off altogether depending on your own requirements whilst in bed.

COZYTEK Washable Electric Blanket

Controller Heat Settings

0 = OFF

1 = LOW HEAT

2 = MEDIUM HEAT

3 = HIGH HEAT

Overheat protection

All electric blankets are fitted with our overheat safeguard system. This offers protection against overheating or damage to the element by disengaging the power to the heating element before any overheat hazards occur.

SAFETY INSTRUCTION

Important

Check daily that your blanket is flat, fully spread out and secured before switching on.

Failure to observe these instructions will cause overheating. This will activate our overheat safeguard system, thus leaving the blanket inoperative, voiding all warranties.

1. Use as an under blanket only. Not recommended for Futon or similar bedding system.
2. This blanket is not recommended to be used on an adjustable bed. If used on an adjustable bed, check that the blanket or cord cannot become caught or rucked.
3. Make sure that the heating area (element) on any side of the bed does not hang over the edge of the mattress, that means of attachment are adequate and suitable for the particular mattress, and that the instructions which follow are read carefully before using the blanket.
4. The appliance is not intended for use by young children or infirm persons without supervision. For human use only, not pets.
5. Young children should be supervised to ensure that they do not play with the appliance.
6. Prolonged application at the high setting can result in minor skin burns.
7. Do not tuck in.

COZYTEK Washable Electric Blanket

8. Do not use tucked or folded.
9. Keep the control unit away from an open window.
10. Do not use pins-they may damage the electric wiring.
11. Be sure that this blanket is used only on an alternating current supply circuit of the proper voltage.
12. The supplied flexible cord and switch must, as far as practicable, be kept outside the bed.
13. Do not switch the power on if the blanket is wet or in folded state.
14. Switch off at the power outlet and remove plug when this blanket is not in actual use.
15. This blanket must be kept in the fully spread condition at all times during use to avoid overheating. It is imperative that the blanket be frequently inspected to ensure that this condition is being maintained.
16. Bed clothes should not be folded back when unit is switched on. Do not leave heavy objects on the bed when the unit is switched on, e.g. folded blankets or suitcases.
17. Do not dry clean this blanket.
18. Persons suffering from bed-wetting should not use this electric blanket.
19. If any abnormality or defect in operation of this blanket is observed, discontinue its use immediately and consult the manufacturer or the supplier regarding its repair.
20. The blanket should be examined frequently for signs of wear, either of the blanket, controller or flexible cord. If wear is visible, the blanket should be returned immediately to manufacturer or supplier for inspection and overhaul. Servicing, by law, must be undertaken by a qualified and registered person.
21. It is recommended you follow washing instructions for localized soiling if a small amount of soiling occurs.
22. The blanket must not be used over or under a water bed.
23. It is recommended that your electric blanket is inspected by a qualified and registered person after 3 years of use.
24. When storing, fold neatly but not tightly (or roll) without sharp bends in the heating element and store where no other objects will be placed upon it.
25. Avoid pressing creases into the appliance.
26. This appliance is for household use only. Not intended for use in hospitals.

Compulsory warning

If the supply cord is damaged, it must be discarded.

CARE AND MAINTENANCE

Before cleaning

Disconnect the blanket from the mains supply, and then disconnect the controller from the blanket. Store the controller away carefully.

Cleaning

Do not dry clean this blanket.

The blanket has waterproof heating elements making it safe to immerse in water and wash by hand or machine. Always remove the controller first – do not allow any part of the controller to be immersed in any liquid.

Machine Wash

With the controllers detached the blanket can be washed in a machine (size permitting).

Wash on WOOL or DELICATES cycle with a neutral detergent or mild soap powder at a wash temperature of 40°C. Do not use high speed or extra spin cycles.

Drying

Drape the blanket over a clothes line to dry – do not use pegs to secure the blanket.

Allow to dry naturally – do not use any form of direct heat such as a hair dryer or heater. Ensure that the blanket and its connector are fully dry before re-connecting the controller and using.

Damage Check

The blanket, controller and cable must be regularly checked for damaged. If any damage or wear is found, the product must be checked by a qualified engineer before use.

Environmental Protection



Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

DECLARATION OF CONFORMITY

We Futura Direct Ltd, England declare that the Heated Electric Blanket has been manufactured according to our full quality assurance procedures.

The declaration is to certify that it conforms to CE, EMC, WEEE and RoHS directives.



Mr. Paul Kaye, UK QA Manager

Please read the following carefully
FUTURA Direct Ltd. and/or its distributor have
provided the parts list and assembly diagram
as a reference tool only.

Neither FUTURA Direct Ltd. or its distributor makes any representation or warranty of any kind to the buyer that he or she is qualified to do any repairs or replace any parts of this product. FUTURA Direct Ltd. and its distributor expressly state that all repairs or parts replacement should be done by certified or licensed technicians. The buyer assumes all risk and liability arising out of his or her repairs or parts replacement to the original product.

24 MONTHS LIMITED WARRANTY

Here at Futura we are confident that you will enjoy many hours of pleasure from your product. However, if within 24 months from the date of purchase you experience any problems due to defects in materials or manufacture, please connect us directly on 01302332030.

Should your product develop a fault please follow these steps immediately:

- ✧ Call our technical helpline on 01302332030.
- ✧ We will replace any defective product that is in warranty due to defective materials or workmanship.
- ✧ We will NOT replace any product that has faults due to accidental damage, abuse or from failure to follow the instructions.
- ✧ This does not affect your statutory right.

www.futura-direct.co.uk

We FUTURA Direct Ltd, England DN6 7AY declare that the washable electric blanket is exclusively manufactured for FUTURA Direct Ltd and has been manufactured according to our fully quality assurance procedures.