

Assembly & Operation Instructions

Good Housekeeping*
Tried&Tested

Good Housekeeping Expandable 3 tier ailer - 820/3919 (LYJ162/4205)

Operation

Open & lock:

- Place the ailer on the floor with clips facing upwards (fig 1).
- Lift up either side, locate retention clips and slide collars forward as far as they go to lock the ailer open (fig 2,3,4).
- Ailer can be used either non-expanded or expanded. To expand the ailer for more drying space, place hands on opposite sides and pull out.




fig 1




fig 2




fig 3




fig 4

Unlock & close:

1. Place hands on opposite side and push inwards.
2. Slide locking collars backwards, release from clips and fold down flat.

Warning

- Always set up and stand this item on a flat even surface.
- Ensure product is stable and load evenly.
- Do not exceed max.load of 10 kgs.
- Ensure locking mechanism is engaged before use.
- Wipe clean with damp cloth.
- Please retain this information for future reference.
- This is not a children's toy. Do not allow children to play with this product.