


GUILD

Double Barrel Foot Pump

Max pressure: 100psi 866/3999

Operating Instructions

1. Unclip hose from base of unit.
2. With pump on ground, compress the pedal.
With pressure applied to pedal, remove storage clips and slowly release the pressure on the pedal.
3. Attach the thumb lock connector (opposite) to the valve or adaptor (ensure that the thumb lock is pushed on firmly).
4. You can now use the pedal to pump air into your tyre/inflatable product (such as footballs, air beds and inflatables).



Footpump Closure / Storage Instructions

After use, place footpump on the ground and depress the pedal. Hook storage clips over frame to hold closed.

Argos Ltd, 489-499 Avebury Boulevard,
Milton Keynes, MK9 2NW
TEL:0345 6400800 www.argos.co.uk