

# New Hallingford 4 Door 3 Drawer Wardrobe

Assembly Instructions - Please keep for future reference


2478441

2497714

2574242

2377700

2588771



## Dimensions

Width - 197,9cm

Depth - 60,3cm

Height -205,7cm

**Tip : To prevent damage, we recommend that you build your unit on the carton(s) it was packed in.**

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, please visit: [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)

Alternatively, call the Spares Helpline on: **0370 112 1928**

For any other queries please contact the Customer Helpline on: **0345 640 2020**



# Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

**Warning:** Only use a manual screwdriver to attach the hinges.

- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Instruction video



- This manual is provided with an additional instruction video. If the icon on the right is displayed at a particular step in the manual, Follow the link: <http://nlink.nu/vid01> Or scan the QR code on the left with your phone.




See page 1 for link to instruction video!

**Note:** if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


# Components - Panels

For damaged or missing parts, please visit:  
[www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)


Please check you have all the panels listed below




**1** Left side  
 (205.6 x 58cm)  
*P2349b*



**2** Right side  
 (205.6 x 58cm)  
*P2349b*




**3** Upright x2  
 (196.9 x 57.7cm)  
*P2354b*



**4** Left mirror door  
 (151.2 x 48.8cm)  
*PS3725*




**5** Right mirror door  
 (151.2 x 48.8cm)  
*PS3719*




**6** Top/Bottom x 2  
 (194.9 x 57.7cm)  
*P1349*



**7** Large horizontal  
 (96.7 x 57.6cm)  
*P1342*



**8** Small horizontal x2  
 (47.6 x 57.6cm)  
*P1343*



**9** Drawer base x 3  
 (94.5 x 34.9cm)  
*BO33956*



**10** Drawer wrap x 3  
 (35 x 95.8 x 10cm)  
*LA1868*



**11** Drawer front x 3  
 (97.9 x 15.7cm)  
*P4316*



**13** Back x2  
 (199.3 x 48.8cm)  
*BO33902*



**14** Foldy back  
 (152.3 x 98cm)  
*BO33934*



**15** Door x 2  
 (199.2 x 48.8cm)  
*P3724*



**16** Plinth front  
 (194.8 x 14cm)  
*P7338C*



**17** Plinth back  
 (194.8 x 5.4cm)  
*P7339C*



**18** Pelmet  
 (198.1 x 4.5cm)  
*FA249*















# Components - Fittings

For damaged or missing parts, please visit: [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk)


Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


## Fittings Drawers

<b>B</b>  20mm Screw x 12 <small>FK1980</small>	<b>C</b>  9mm Srew x 6 <small>FK1981</small>	<b>H</b>  24mm locking screw x 6 <small>FK1011</small>
<b>J</b>  Small locking nut x 6 <small>FK1010</small>	<b>N</b>  Drawerbase Support x 12 <small>FK1250</small>	<b>X</b>  Glue x 1 <small>FA1510</small>
<b>Fittings Carcase</b>		
<b>A</b>  40mm Screw x 11 <small>FK1324</small>	<b>B</b>  20mm Screw x 8 <small>FK1980</small>	<b>D</b>  15mm Screw x 45 <small>FK1400</small>
<b>E</b>  10mm Fixing screw drawer x 12 <small>FK1301</small>	<b>F</b>  12.5 mm Screw x 6 <small>FK1309</small>	<b>G</b>  L-Bracket x 1 <small>FK1235</small>
<b>H</b>  24mm locking screw x 34 <small>FK1011</small>	<b>I</b>  Large locking nut x 34 <small>FK1012</small>	<b>K</b>  Nail x 60 <small>FA1515</small>
<b>L</b>  Nail holder x 1 <small>FK1419</small>	<b>M</b>  Hanger rail support x 6 <small>FK1217</small>	<b>P</b>  Hinge back x 12 <small>FK1269</small>
<b>Q</b>  Hinge door x 12 <small>FK1268</small>	<b>R</b>  Runner x 6 <small>PM16951</small>	<b>S</b>  Peg x 2 <small>FK1234</small>
<b>T</b>  Door/Drawer handle x 10 <small>GR1975</small>	<b>V</b>  Hanger rail large x 1 <small>PM1884</small>	<b>W</b>  Wall plug and parkerscrew x 1 <small>PM1873</small>

## Tools required



Ruler - Use this ruler to help correctly identify the screws




# Assembly Instructions

## Step 1

### Drawer assembly x 3


**a:** Insert two small locking nuts **J** into drawer wrap **10**.

Make sure the 'arrow' on **J** is pointing towards the hole in the edge of **10**.




**b:** Screw 24mm locking screws **H** into holes shown on back of drawer front **11**.

Make sure 24mm locking screws **H** are tightened right up against drawer front **11**.




**c:** Slide drawer base **10** into grooves shown on drawer wrap **10**.




# Assembly Instructions

## Step 1 - continued

**d:** Insert glue in drawer front **11** groove.  
Turn the drawer wrap assembly over and push onto drawer front **11**. Use a philips or flatblade screwdriver, that is a good fit, to turn small locking nut **J** as far as it will go - more than 1/2 turn.





**d**



**e:** Fix drawer handle **T** onto drawer front **11** using 30mm screw **B**.  
Turn over drawer and slide Drawerbase supports **N** in corner as shown and fix them, using the attached screws.

**e:**



## Step 2




### Attaching runners

**a:** Slide top of runners **R** forward and fix on upright **3** as shown using 10mm fixing screw drawer **E**.



**Attention!**  
There are two uprights **3** one is the right side **3R**, the other is the left side **3L**, either of them can be used as **3R** or **3L**!

**a:**



# Assembly Instructions


## Step 2 - continued

**b:** Slide top of runners **R** back.

Fix through 3rd hole of runner **R** and pre-drilled holes of upright **3** using 10mm fixing screw drawer **E**.

Fix through 1st and 9th hole of runners **R** using 15mm screw **O**.

**Note:** there are no pre-drilled holes for 15mm screw **O**.



## Step 3

### Insert fittings

**a:** Screw 24mm locking screw **H** into 1 upright **3**, this will be the right upright.

**Note:** Insert 24mm locking screw **H** as far as shown. **Do not over tighten.**

Attach hinge back **P** onto upright **3**.

Attach hanger rail support **M** using 12.5mm screw **F** onto upright **3**.

### Flip panel

**b:** Screw 24mm locking screw **3** into upright **N**, this will be the right upright.

Attach hanger rail support **M** using 12.5mm screw **F** onto upright **3**.







### Attention!

There are two uprights **3** one is the right side **3R**, the other is the left side **3L**, either of them can be used as **3R** or **3L**!



**Warning:** Do not use an electric screwdriver to attach the hinges as this can weaken the fixing.



# Assembly Instructions


## Step 4

### Attaching panels

Position large horizontal **7** onto upright **3R**.

Insert two large locking nuts **1** into large horizontal **7** as shown.

Use a screwdriver to turn locking nuts **1** clockwise to lock.



## Step 5


### Attaching panels

Position large horizontal **7** onto upright **3L**.

Insert two large locking nuts **1** into large horizontal **7** as shown.

Use a screwdriver to turn locking nuts **1** clockwise to lock.

**Note:** Internal Uprights are identical. Large holes for locking nuts **should not** face each other”.




## Step 6

### Insert fittings

Screw 24mm locking screw **H** into top/bottom **6**, this will be the top.

**Note:** Insert 24mm locking screw **H** as far as shown. **Do not over tighten.**



# Assembly Instructions

## Step 7


### Attaching plinths

Align the sides of plinth front **16** with bottom **6** as shown and attach using 40mm screw **A**.

**Note:** there are no predrilled holes for 40mm screw **A**.

**Note:** top and bottom panels **6** are identical. Only prepare one of the panels at this stage. This will be the bottom panel


Repeat with plinth back **17**.



## Step 8

### Insert locking screws

Screw 24mm locking screw **H** into bottom **6**.




## Step 9

### Attaching panels

Position bottom **6** and top **6** onto uprights **3**.

Insert four Large locking nuts **1** into uprights **3** as shown.

Use a screwdriver to turn locking nuts **1** clockwise to lock.



# Assembly Instructions


## Step 10

### Attaching panels

Position small horizontals **8** onto uprights **3**.

Insert three large locking nuts **1** into small horizontals **8** as shown.

Use a screwdriver to turn locking nuts **1** clockwise to lock.



**Warning:** Do not use an electric screwdriver to attach the hinges as this can weaken the fixing.

## Step 11


### Insert fittings

**a:** Screw 24mm locking screw **H** into left side **1** and right side **2**.

**Note:** Insert 24mm locking screw **H** as far as shown. Do not over tighten.

Attach hinge back **P** onto left side **1** and right side **2**.

Attach hanger rail support **M** using 12.5mm screw **F** onto left side **1** and right side **2**.




## Step 12

### Attaching panels

Position left side **1** and right side **2** onto the unit.

Insert large locking nuts **1** into top/bottoms **6** and small horizontals **8** as shown.

Use a screwdriver to turn locking nuts **1** clockwise to lock.



# Assembly Instructions

## Step 13

### Fitting back panels



Attach back **13** and foldy back **14** to back of wardrobe with the coloured surface facing the inside of the unit using nails **K** and 15mm screws **D**.

Use nail holder **L** to hold the nails **K** vertical and at correct distance as you secure the back **13** and foldy back **14**. Nails **K** should be spaced about 150mm apart.



Important:  
Cabinet **MUST** be 'square' when back is attached.

*Stand up the unit!*  
*2 people required.*





## Step 14

### Attaching pelmet & hanger rails

Position pelmet **18** onto top **6** as shown, fix by using three 40mm screws **A**.

Place hanger rails **U** and **V** onto hanger rail support **M**.





# Assembly Instructions

## Step 15

### Inserting drawers

**a:** Pull runners out. Slide drawers onto runners so they butt up against back of drawer front.

**b:** Fix through drawer sides into runners using 9mm screws **C**.



## Step 16


### Fitting hinges & door handles to doors

Fix three hinge doors **Q** to each door **3 5 15** using 15mm screws **D**.

Attach door handles **T** using 30mm screws **B**.



**Warning:** Do not use an electric screwdriver to attach the hinges as this can weaken the fixing.



# Assembly Instructions

## Step 17

### Hanging doors & attaching L-bracket

**a:** With help, slot hinge door **Q** onto hinge back **P**.

**b:** Tighten screw shown to lock hinges in position.

Repeat **a** and **b** for other doors.

See 'Hinge adjustment' in step 18 if the doors need adjusting.





**c:** Position L-Bracket **G** onto top **6** as shown, fix by using 15mm screw **D**.

Note: there are no pre-drilled holes for 15mm screw **D**.


Use **W** to fix on the wall, please see last page for more information.

**d:** Before adjusting the doors, use a spirit level to check if the base of this unit is level front-to-back and side-to-side in the three positions shown.

Use pegs **S** to square your unit. Knock peg **S** in, as far as you require, under the ends of the unit and then snap off flush with the panel.



See page 1 for link to instruction video!



# Assembly Instructions

## Step 18

### Hinge adjustment

**a:** To move doors up or down: loosen screws shown and move doors to suit.

Once doors are aligned, re-tighten.

**b:** To move doors in or out: loosen screw shown and move doors to suit.



Re-tighten screws.

**c:** To move doors left or right: loosen screw shown and move doors to suit.





Re-tighten screws.



**Warning:** Do not use an electric screwdriver to adjust the hinges as this can weaken the fixing.



See page 1 for link to instruction video!



# A Guide to - Wall Mounting & Fixings

## Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: **General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.