

New Hallingford - Dresser, Stool & Mirror

Assembly Instructions - Please keep for future reference


346/9727

330/6086

357/1268

356/3537

357/0290



Dresser Dimensions

Width - 99.5cm

Depth - 40cm

Height - 78.5cm

Stool Dimensions

Width - 51.5cm

Depth - 35.5cm

Height - 45cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 34kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the overbalance kit supplied.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the panels listed below

Dresser



1 Left Side (DF1861)
(762 x 372mm)



2 Right Side (DF1862)
(762 x 372mm)



3 Divider (DF1865)
(162 x 355mm)




4 Left Mirror Support (DF1868)
(147 x 250mm)



5 Right Mirror Support (DF1968)
(147 x 250mm)




6 Modesty (DF1864)
(960 x 163.5mm) x 2




7 Top (DF1863)
(995 x 396mm)



8 Mirror Back (DF1869)
(496 x 327mm)



9 Left Drawer Front (DF1866)
(489 x 162mm)



10 Right Drawer Front (DF1967)
(489 x 162mm)



11 Left Drawer Side (W350-124LH)
(350 x 124mm) x 2



12 Right Drawer Side (W350-124RH)
(350 x 124mm) x 2




13 Drawer Back (W423-124)
(423 x 124mm) x 2




14 Drawer Base (T434-347)
(434 x 347mm) x 2


Stool




15 Stool Left Side (D2333A)
(395 x 350mm)



16 Stool Right Side (D2334A)
(395 x 350mm)



17 Stool Top (D2332A)
(513 x 353mm)




18 Stool Base (D2336A)
(478 x 308mm)




19 Stool Rail (D2335A)
(478 x 124mm) x 2




20 Stool Drawer Front (D2338A)
(472 x 126mm)



21 Stool Left Drawer Side (W300-95LH)
(300 x 95mm)



22 Stool Right Drawer Side (W300-95RH)
(300 x 95mm)



23 Stool Drawer Back (W445-95)
(445 x 95mm)



24 Stool Seat Pad (FHALPAD)
(458 x 300mm)



25 Stool Drawer Base (T456-297)
(456 x 297mm)









Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0870 112 1928** or **email: Help@ClickSpares.co.uk** (quoting your original order number and the reference numbers below)

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 11</p>	<p>B </p> <p>Metal dowel (F901) x 36</p>	<p>C </p> <p>Small locking nut (F3) x 6</p>
<p>D </p> <p>Large locking nut (F900) x 30</p>	<p>E </p> <p>Knock-in Peg (F171GY) x 12</p>	<p>F </p> <p>Wedgex (F639) x 6</p>
<p>G </p> <p>25mm Screw (F50) x 4</p>	<p>H </p> <p>19mm Screw (F461) x 4</p>	<p>I </p> <p>13mm Screw (F63) x 12</p>
<p>J </p> <p>9mm Screw (F74) x 2</p>	<p>K </p> <p>9mm Screw (F73) x 16</p>	<p>L </p> <p>Plastic Nail (F91) x 8</p>
<p>M a  L Runner (F159) x 2 ← 350mm long →</p> <p>M b  R Runner (F160) x 2</p> <p>M c  L Runner (F161) x 2</p> <p>M d  R Runner (F162) x 2</p>		<p>N  Mini block (F25) x 4</p> <p>O  Handle (F278) x 2</p>
<p>P  Strap</p> <p> Screw</p> <p> Washer x 2</p> <p>Overbalance protector kit (F269) x 1</p>		<p>Q  ← 280mm long → Drawer runner (F1004) x 2</p>

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the
Customer Helpline: 08456 400800 quoting the reference
numbers below

Step 1

Prepare the 2 drawer fronts

Screw 2 metal dowels **B** into the left drawer front **9** and the right drawer front **10**.

Note: Tighten the metal dowels up fully against the panels.




Note: The small right drawer fronts have an identification mark hole.

Step 2

Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **11** and the right drawer side **12**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer fronts

Push the left drawer sides **11** and right drawer sides **12** onto the back of the drawer fronts **9** and **10**.

Turn the small locking nuts **C** on the left drawer side **11** and right drawer side **12**.

Note: Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **14** down the grooves in the drawer sides **11** and **12** and down into the groove in the drawer front **9** and **10**.




Step 5

Fit the drawer back

Fit the drawer back **13** between the drawer sides **11** and **12**. Make sure that the drawer base **14** fits into the groove in the drawer back **13**.


Hold the drawer back **13** in position and tap the knock-in pegs **E** through the holes in the drawer sides **11** and **12**.



Step 6

Attach the handles


Attach a handle **O** to each of the drawer fronts **9** and **10** using screw **H**.



Step 7

Fit the wedgexes

Turn the drawer assemblies over and slide 2 wedgexes **F** into the front and back grooves, as shown, and tighten up the screws.




Assembly Instructions

Step 8

Fit runners to the drawers

Fit runner **Md**, marked with 'R', to the bottom edge of the right drawer side **12**, as shown, making sure that it is pushed up against the back of the drawer fronts **9** and **10**. Use a bradawl to mark the fixing positions, then secure with 2 screws **I**.

Fit runner **Mc**, marked 'L', to the bottom edge of the left drawer side **11** using the same method.




Step 9

Prepare the 2 modesty panels

Insert 4 large locking nuts **D** into each modesty panel **6**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.



Assembly Instructions

Step 10

Prepare the left side

a: Fit a runner **Ma** to the left side **1**.

The 1st screw **K** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **K** use the holes that line up with the other panel holes.





b: Fit a screw **I** into the 2nd hole in at the top of the runners **Ma**.

Tap a wooden dowel **A** into the left side **1**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Insert 2 large locking nuts **D** into the left side **1**.

c: Screw 4 metal dowels **B** into the left side **1**.



Assembly Instructions

Step 11

Prepare the right side

a: Fit a runner **Mb** to the right side **2**.

The 1st screw **K** uses the 1st hole in from the front of the runners.






The 2nd and 3rd screws **K** use the holes that line up with the other panel holes.

b: Fit a screw **I** into the 2nd hole in at the top of the runners **Mb**.

Tap a wooden dowel **A** into the right side **2**.

Insert 2 large locking nuts **D** into the right side **2**.

c: Screw 4 metal dowels **B** into the right side **2**.



Assembly Instructions


Step 12

Fit the modesty panels to the right side

Push the 2 modesty panels **6** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each of the modesty panels **6**.

Note: Turn the large locking nuts **D** as far as they will go - more than 1/2 a turn.




Step 13

Fit the left side

Push the left side **1** onto the 2 modesty panels **6**.


Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each of the modesty panels **6**.



Step 14

Prepare the top

Screw 6 metal dowels **B** into the top **7**.



Assembly Instructions

Step 15

Prepare the divider

a: Fit a runner **M a** to the divider **3**.

The 1st screw **K** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **K** use the holes that line up with the other panel holes.

b: Fit a screw **I** into the 2nd hole in at the top of the runners **M a**.

Tap a wooden dowel **A** into the divider **3**.

Turn the divider over

c: Fit a runner **M b** to the divider **3**.





The 1st screw **K** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **K** use the holes that line up with the other panel holes.





d: Fit a screw **I** into the 2nd hole in at the top of the runners **M b**.

Insert 2 large locking nuts **D** into the divider **3**.

Note: Due to the manufacturing process, the 2 holes for the large locking nut can be on either surface of the divider.



Turn the divider over



Assembly Instructions


Step 16

Fit the divider onto the top

Push the divider **3** onto the top **7**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the divider **3**.

Reminder: The 2 large locking nuts may be on either surface of the divider




Step 17

Fit the top

Push the top **7** onto the sides **1** and **2**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the left side **1** and the right side **2**.



Step 18


Fit the 4 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the sides **1** and **2**.

Carefully stand the unit up for the next step.



Warning: The unit is heavy. Lift with care.




Assembly Instructions

Step 19

Fit the drawers

Slide the wheels of the runners fitted to the drawers, over the wheels of the runners fitted to the side panels and push the drawers into position.




Remember: The small right drawer front has an identification mark hole.

Step 20

Prepare the left and right mirror supports

Gently tap 2 mini blocks **N** into the holes on the left mirror support **4** and the right mirror support **5**, orientated as shown.




Step 21

Fit the mirror supports to the mirror back

Place the left mirror support **4** and right mirror support **5** onto the mirror back **8**.

Tighten up the screws in the mini blocks **N** into the holes in the mirror back **8**.




Warning:
Glass! Handle with care

Assembly Instructions

Step 22

Prepare the stool drawer front

Screw 2 metal dowels **B** into the stool drawer front **20**.




Step 23

Prepare the stool drawer sides

Insert a small locking nut **C** into the hole shown on the stool left drawer side **21** and stool right drawer side **22**.

Note: Arrow on locking nut **must** point towards hole in edge of panel.




Step 24

Attach the stool drawer sides to the stool drawer front

Push the stool left drawer side **21** and stool right drawer side **22** onto the back of the stool drawer front **20**.

Turn the small locking nuts **C** on the stool left drawer side **21** and stool right drawer side **22**.




Assembly Instructions

Step 25

Fit the stool drawer base

Slide the stool drawer base **25** down the grooves in the stool drawer sides **21** and **22** and down into the groove in the stool drawer front **20**.




Step 26

Fit the stool drawer back

Fit the stool drawer back **23** down onto the stool drawer base **25**.

Make sure that the stool drawer base **25** fits into the groove in the stool drawer back **23**.



Hold the stool drawer back **23** in position and tap the knock-in pegs **E** through the holes in the stool drawer sides **21** and **22**.



Step 27

Fit the wedgifixes

Turn the drawer assembly over and slide 2 wedgifixes **F** into the front and back grooves, as shown, and tighten up the screws.




Assembly Instructions

Step 28

Prepare the stool rails

Tap 2 wooden dowels **A** into each of the stool rails **19**.

Insert 4 large locking nuts **D** into each of the stool rails **19**.



Step 29

Prepare the stool left side


a: Place a runner **Q** onto the stool left side **15**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **K**.

b: Slide the runner back the other way and use the 2nd hole from the back to fit the 2nd screw **K**.


c: Screw 6 metal dowels **B** into the stool left side **15**.

d: Tap a wooden dowel **A** into the stool left side **15**.



Insert 2 large locking nuts **D** into the stool left side **15**.




a:



b:



c:



d:

Assembly Instructions

Step 30

Prepare the stool right side

a: Place a runner **Q** onto the stool right side **16**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **K**.



b: Slide the runner back the other way and use the 2nd hole from the back to fit the 2nd screw **K**.

c: Screw 6 metal dowels **B** into the stool right side **16**.



d: Tap a wooden dowel **A** into the stool right side **16**.

Insert 2 large locking nuts **D** into the stool right side **16**.


a:




b:



c:



d:




Assembly Instructions

Step 31

Fit a stool rail to the stool left side

Push a stool rail **19** onto the stool left side **15**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool rail **19**.




Step 32

Prepare the stool base

Tap 2 wooden dowels **A** into the stool base **18**.

Insert 4 large locking nuts **D** into the stool base **18**.




Step 33

Fit the stool base

Push the stool base **18** onto the stool left side **15**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool base **18**.




Assembly Instructions

Step 34

Fit the other stool rail

Push the other stool rail **19** onto the stool left side **15**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool rail **19**.




Step 35

Fit the stool right side

Push the stool right side **16** onto the stool base **18** and the 2 stool rails **19**.

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to each of the stool rails **19**.




Step 36

Secure the stool base

Use a screwdriver to tighten the 2 large locking nuts **D** fitted to the stool base **18**.

Stand the stool up for the next step.




Assembly Instructions

Step 37

Fit the 4 plastic nails


Tap 2 plastic nails **L** into the bottom edge of each of the stool sides **15** and **16**.



Step 38

Prepare the stool top

Screw 4 metal dowels **B** into the stool top **17**.




Step 39

Fit the stool seat pad

Fit the stool seat pad **24** to the stool top **17** using 4 screws **G**.

Note: Make sure that you screw into the hard surface of the stool seat pad.




Assembly Instructions

Step 40

Fit the stool top

Lower the stool top **17** down onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **D** fitted to the stool left side **15** and stool right side **16**.





Step 41

Fit the stool drawer

Slide both the runners **Q** forward and locate the drawer sides **21** and **22** between them, lining up the holes in the drawer sides with the 2nd 'threaded' holes in the runners **Q**.

Working from the inside of the drawer, insert 2 screws **J** through the drawer sides and out into the 2nd threaded hole in the runner.

Note: Do not overtighten the screws **J**. If they catch on the runner you may need to loosen them slightly.



Assembly Instructions

Step 42



Fit the overbalance protector

To prevent possible overbalancing we recommend that the dresser is secured to a suitable wall by use of the overbalance protector kit **P** fitted to the unit or, an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.


Example



Assembly Instructions

Step 43

Assembly is complete



IMPORTANT INFORMATION ABOUT THIS PRODUCT

This product complies with the requirements of BS 7449:1991 and has been manufactured by DECORATIVE PANELS FURNITURE LTD, TEESIDE INDUSTRIAL ESTATE, THORNABY-ON-TEES, CLEVELAND, TS17 9LT.

The product code for this unit and the item code(s) for the glass components are listed in the Assembly Instructions along with a description of the type of glass used. All clear/tinted glass complies with the requirements of BS 6206 Class A. All mirrors comply with the requirements of BS 6206 Class C. If the glass component contained in this unit is chipped or broken consult the furniture manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the unit description and batch number or date of manufacture.

Do not place very hot or very cold items against or in close proximity to glass surface(s) unless adequately thick insulating material is used to prevent such items coming in contact with the glass.

Do not strike the glass with hard or pointed items.

Do not sit or stand upon horizontal glass surfaces.

When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary - do not use washing powders or any other substance containing abrasives since these substances scratch glass.

If stated in the instruction leaflet, it is essential that this unit is fixed to a wall.

KEEP THESE INSTRUCTIONS FOR FUTURE USE

If you need help or have damaged or missing parts, call the **Customer Helpline: 0870 112 1928** or email: **Help@ClickSpares.co.uk** (quoting your original order number and the reference numbers on the component pages)
Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

