


# 6FT TRAMPOLINE WITH ENCLOSURE

Assembly & User Instructions - Please keep for future reference

367/5511



## Important

Age: 3 - 6 years  
Maximum user weight: 45kg

Tips: It will take around 30 minutes to assemble it.  
2 people may be required


**Important** - Please read these instructions fully before assembly or use.

These instructions contain important information which will help you get the best from your product and ensure safe and correct assembly, use and maintenance.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0843-5034455**

# Contents

Safety Information	2
Parts	3
Assembly Instructions	4-21
Attach Support	4
Attach frame	4
Attach the Corner Top Rail with Socket	4
Attach lower tubes	4
Attach the Top Rail	4
Attach mat	5-8
Attach frame pad	9
Attach Safety Instruction	9
Attach upper tubes	10-12
Fit enclosure net	13-15
Tie the elastic straps	16
Attach hook	17
User Instructions	19-20
Rules of using the trampoline	19
Using	19
Basic bounces	19-20
Care and Maintenance	21
General	21
Inspect regularly	21
Windy conditions	21
Moving the trampoline	21





# Safety Information

**Important** –Please read these instructions fully before assembly or use.




## WARNING

- Max. weight limit : 45kg
- Warning! Not suitable for children under the age of 36 months as small part(s) may be generated and because of long cord(s)-choking and entanglement/stangulation hazards.
- Inspect the trampoline before each use.
- Make sure the frame padding is correctly and securely positioned.
- Replace any worn, defective, or missing parts.
- Climb on and off the trampoline, it is a dangerous practice to jump from the trampoline to the floor or ground when dismounting, or to jump onto the trampoline when mounting. Do not use the trampoline as a springboard to other objects.
- Stop bounce by flexing knees as feet come in contact with the trampoline bed. Learn this skill before attempting others.
- Learn fundamental bounces and body positions thoroughly before trying more advanced skills. A variety of trampoline activities can be carried out by performing the basic fundamentals in various series and combinations, performing and fundamental after another, with or without feet bounces between them.
- Avoid bouncing too high. Stay low until bounce control and repeated landing in the center of the trampoline can be accomplished.
- Control is more important than height.
- While keeping the head erect, focus eyes on the trampoline toward the perimeter. This will help control bounce.
- Avoid bouncing when tired. Keep turns short.
- Properly secure the trampoline when not in use. Protect it against unauthorized use. If a trampoline ladder is used, the supervisor should remove it from the trampoline when leaving the area to prevent unsupervised access by children under 6 years of age.
- Keep objects away which could interfere with the performer. Maintain a clear area around the trampoline.
- Do not use the trampoline while under the influence of alcohol or drugs.
- For further information or additional instruction materials on skill training, contact a competent trampoline instructor.
- Bounce only when the surface of the bed is dry. Wind or air movement should be calm and gentle. The trampoline must not be used in gusty or severe winds.
- Read all instructions before using the trampoline, warnings and instructions for the care, maintenance, and use of this trampoline are included to promote safe, enjoyable use of this equipment.
- Always start your jump at the broken circle printed on the center of the trampoline mat.
- When you land more than 1 foot away from the edge of the broken circle, stop your jump immediately!! Restart your jump at the broken circle.
- Use trampoline only with mature, knowledgeable supervision.
- Secure the trampoline against unauthorized use.
- Keep objects away which could interfere with the performer.
- For equipment information, contact the manufacturer.
- For skill training information, contact a trainer certification organization.
- Do not use when trampoline is wet or in windy conditions.
- Read instructions before use.
- Check all nuts and bolts for tightness and tighten when required.
- Check all spring loaded (pit pin) joints are still intact and cannot come undone during play.
- Check all coverings for bolts and sharp edges and replace when required.
- Check for evidence of wear or deterioration and replace if needed in accordance with the manufactures instructions.
- Please do not hang on the top ring, this action may cause injury.
- Packaging materials are not toys. Please remove all packaging and packing tags / wires before giving this toy to your child. DO NOT let children use this equipment until it has been properly assembled, Place equipment on level ground not less than 2M from any structures or obstacles such as fences, overhanging branches, laundry or electrical line, garages, sheds or houses.
- Keep the instruction manual for further reference.
- Warning. Only for domestic use.


# Parts

If you have damaged or missing parts, call the **Customer Helpline: 0843-5034455**


Please Check you have all the parts fittings listed below




**1** Trampoline Mat, stitched with Triangle-Rings x1



**2** Frame Pad x 1




**3** Top Rail with Leg Sockets x 3




**4** Top Rail x 3




**5** Leg Base x 3




**6** Safety Instruction Placard x 1



**7** Upper Frame Tube with Foam x 3




**8** Lower Frame Tube with Foam x 3



**9** Cable Wire x 8




**10** Cord x 4



**11** Enclosure Netting x 1



**12** End Cap x 3













**13** Plastic Cap x 3




**14** Cap x 3

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b></p>  <p>Galvanized Spring – 28N(5-1/2") x 36</p>	<p><b>B</b></p>  <p>Spring Loading Tool x 1</p>	<p><b>C</b></p>  <p>Wrench x 1</p>	<p><b>D</b></p>  <p>Gap Spacer x 6</p>	<p><b>E</b></p>  <p>Self-Locking Screw x 3</p>
<p><b>F</b></p>  <p>Lock Nut x 12</p>	<p><b>G</b></p>  <p>Clamp x 6</p>	<p><b>H</b></p>  <p>U-Screw x 6</p>	<p><b>I</b></p>  <p>Nut Cover x 12</p>	<p><b>J</b></p>  <p>Allen Wrench x 1</p>

**Ruler - Use this ruler to help correctly identify the bolts/screws**



# Assembly Instructions

## Step 1

There are a total of 9 pieces of tubing parts that are needed to assemble the frame. All parts with the same part number are interchangeable.

To connect the parts, simply slide a section (male) of tubing that is smaller on one end into the adjacent section (female) that has a larger opening. These joints are called “connector points”.

Lay out all parts according to the diagram.




FIGURE 1

## Step 2

**A.** Two people will be necessary at this point to assemble the trampoline. Lift the support assembly from Step 1 to a standing (vertical) position as shown in FIGURE 2. Insert the Top Rail with Leg Socket into the one end of the support assembly. Insert opposite end of the Top Rail with Leg Socket into a second support assembly. Make sure holes on metal pieces are facing the outside of the trampoline, this is important for installing the enclosure.

Repeat the above step until all the support assemblies have been attached to the Top Rail with Leg Socket.

**B.** Install the Top Rail (#4) into the gaps between the Vertical Leg Extensions by inserting them into the slots as shown in FIGURE 3.




FIGURE 2




FIGURE 3

# Assembly Instructions

## Step 3

### Trampoline Mat Assembly

Lay out the Trampoline Mat (# 1) inside the frame with warning labels facing up as shown in FIGURE 4.

There are total of 36 Triangle-Rings sewn on the mat and 36 holes on the Top Rail Frame. None are numbered, so please follow the instructions carefully to ensure proper installation.

- Two adults are required in this assembling step.
- CAREFUL - When attaching the springs, please do not put your hands, legs or body close to the connector points. The connector points can become pinch points since the trampoline is tightening up.
- Wear heavy duty working gloves to protect your hand.
- Use the special spring loading tool included.





FIGURE 4

SPRING LOADING TOOL



## Step 4

Select an arbitrary point on the Top Rail Frame (call it ZERO) as shown in FIGURE 5.




FIGURE 5

# Assembly Instructions

## Step 5

Hold the spring loading tool underhand and pull spring hook towards the point "ZERO" on the Top Rail Frame as shown in FIGURE 6. Drop hook into frame hole until it latches on completely and tap it down if hook is not completely in the hole.




FIGURE 6

## Step 6

Count holes 18 on the Top Rail and corresponding Triangle-Rings, you should be at point 18. Attach a spring at this point as shown in FIGURE 7.




FIGURE 7

# Assembly Instructions

## Step 7

From point 36, count back 9 holes on the Top Rail and Triangle-Rings, you should be at point 9. Attach a spring at this point, as shown in FIGURE 8.




FIGURE 8

## Step 8

Count another 9 holes from point 18 on the Top Rail and Triangle-Rings, you should be at point 27. Attach a spring at this point, as shown in FIGURE 9. At this point in assembly, you should have 4 springs install at ZERO, 9, 18 and 27.

This even disbursement of tension is critical to proper assembly of the rest of the trampoline mat as shown in FIGURE 9.




FIGURE 9



# Assembly Instructions

## Step 9

Attach a spring at every 3 holes and corresponding Triangle-rings. For even distribution of tension and ease of assembly, springs should be placed on opposite sides of the mat/frame. i.e. 3 then 21, 33 then 15, etc. In addition to the previously installed springs, you should have springs at 3, 6, 12, 15, 21, 24, 30 and 33 as shown in FIGURE 10.



If you notice that you have miscount a hole and Triangle-rings connection, recount and remove or attach any springs required to maintain the count of springs.




FIGURE 10

## Step 10

Then, attach the remaining 24 springs by using the same theory of counting equal holes as shown in FIGURE 11.




FIGURE 11

# Assembly Instructions

## Step 11

### Safety Placard Attachment

Using the tie wrap, attach the Safety Instruction Placard (# 7) to the trampoline as shown in FIGURE 12. The tie wrap should go around the Vertical Frame Joint and the Top Rail to ensure that it doesn't slide off the trampoline.




FIGURE 12

## Step 12

### Frame Pad Assembly



#### WARNING

use the trampoline without attaching the frame pad. Properly tie down the frame pad before each use!!

Lay the Frame Pad (# 2) over the trampoline so that the springs and the steel frame are covered. Please ensure that the Frame Pad covers all metal parts. Line up the elastic tie straps as shown below in FIGURE 13 aligning alternate straps over leg socket.




FIGURE 13

# Assembly Instructions

## Step 13

### Frame Pad Assembly

Tie straps around leg socket as shown below in FIGURE 14.

#### **IMPORTANT NOTICE:**

Make sure the safety pad is securely attached to the frame and completely covers the frame and all springs before using this trampoline. Do not use trampoline if even one spring or Triangle-Ring is damaged or missing.



#### **CAUTION**

TWO ADULTS ARE REQUIRED TO ASSEMBLE THIS ENCLOSURE.




FIGURE 14

## Step 14

### Frame Pad Assembly

Attach End Cap (#12) to the Lower Frame Tube with Foam (#8), please make sure the End Cap (#N) is inserted to the end with two holes as shown in FIGURE 15.




FIGURE 15

# Assembly Instructions

## Step 15

Pull the foam downward a little bit to locate the hole at the edge of the curved end of Upper Frame Tube with Foam (#7). Attach Plastic Cap (#13) to Upper Frame Tube with Foam (#7), secure by using Self-Locking Screw (#E) and Allen Wrench (#J) as shown in FIGURE 16. Then push the foam back to its original position. Repeat this step for all other Upper Frame Tubes and Plastic Caps.




FIGURE 16

## Step 16

Please have someone helping you to hold the Frame Tube. Be steady when you do this step. Attach U-Screw (#H) to the Lower Frame Tube with Foam (#8), Gap Spacer (#D) and Clamp (#G), then to the Leg Base of the trampoline, secured by using Lock Nut (#F) and Nut Cover (#I) as shown in FIGURE 17. Please make sure Gap Spacer (#D) is inserted into the Leg Frame as this is an important safety feature to the structure.





FIGURE 17

# Assembly Instructions

## Step 17

Connect the thread to the nut of Cable Wire (#9) by using Wrench (#C) as shown in FIGURE 18.

**HINT:** Please make sure every Cable Wire is securely and completely fasten to each other.



**FIGURE 18**

# Assembly Instructions

## Step 18



### CAUTION:

TWO ADULTS ARE REQUIRED.

**A.** Insert the assembled CABLE WIRES into sleeve on the top part of the 11 Enclosure Netting as shown in FIGURE 19.




FIGURE 19

**B.** Connect the two end of CABLE WIRES together by connecting the thread to the nut using Wrench (#C) after all cable wires are inserted into the Enclosure Sleeve as shown in FIGURE 20.

**HINT:** Please make sure the cable wires are securely fasten to each other.

Now, place CABLE WIRES and ENCLOSURE NETTING assembly on trampoline mat for the next step.




FIGURE 20

# Assembly Instructions

## Step 19



### CAUTION:

TWO ADULTS ARE REQUIRED. Place the CABLE WIRE with ENCLOSURE NETTING to the PLASTIC CAP assembled on the UPPER FRAME Tube with Foam (#A) to make a "RING" as shown in FIGURE 21. Make sure the cable wire fits into the slot properly. Please repeat for all the Cable Wires and Plastic Cap.

Now, place the assembled "RING" (together with 7, 9 and 11) onto the trampoline mat. Put Cap (#14) on the Plastic Cap as show in FIGURE 22 for further use.




FIGURE 21




FIGURE 22

# Assembly Instructions

## Step 20

Attach the assembled "RING" (together with 7, 9 and 11) to the Lower Frame Tube with Foam (#B) as shown in FIGURE 23.

**IMPORTANT NOTICE:**

Please squeeze the foam of Upper Frame Tube with Foam (#7) and Lower Frame Tube with Foam (#8) a little bit to locate the hole.




FIGURE 23



# Assembly Instructions

## Step 21

Tie one end of one CORD (#10) to trampoline mat ring first, pull the CORD through net edge and trampoline mat ring until the end. Tie new CORD to the same trampoline mat ring where the previous CORD finished. Pull the CORD through net edge and trampoline mat ring. Repeat this step until you have tied all the CORD to the trampoline mat ring as shown in FIGURE 24.






FIGURE 24



# Assembly Instructions

## Step 22

Pull the zipper of Enclosure Netting at the door which should be located within one leg base of the trampoline as shown in FIGURE 25. Attach buckle sewn on the enclosure netting as shown in FIGURE 25 (one may be hidden under the pad of the trampoline).




FIGURE 25

# Assembly Instructions

## Step 23

Use the included plastic tie to attach 6 Safety Placard to the netting near the door as shown in FIGURE 26.

Read this entire manual and make sure all jumpers completely understand all of the safety rules printed in the manual and on the various warning signs. Instruct all jumpers in the basic bounces described in the manual.

**CARE AND MAINTENANCE AND USE INSTRUCTIONS MUST BE READ CAREFULLY BEFORE USING THE TRAMPOLINE!**

### **DISASSEMBLY**

To disassemble, simply follow assembly STEP 1 thru STEP 23 in reverse order, until you have disassembled the enclosure.



### **IMPORTANT WARNING ABOUT ENCLOSURE NETTING:**

Your trampoline enclosure netting is manufactured with UV resistant material. Please carefully read the following to ensure the enclosure is safe to use, if the enclosure has been exposed to weather for more than 6 months.

Please inspect enclosure netting before EACH use for worn or tear by pinching a section of fabric between fingers and pulling downward. Please see diagram below.

This should be done every month, if it produces a tear or if it produces a continuous ripping sound, then the net is unsafe and **MUST** be taken down immediately. **STOP USING THE TRAMPOLINE ENCLOSURE IF YOU FIND WORN OR TEAR ON THE NETTING.**

It is recommended to replace enclosure netting every **SIX MONTHS**. A new netting can be purchased through service center.




FIGURE 26

# User Instruction

## Rules of using the trampoline



**Important:** Ensure all bolts and retaining fixings are tight and correctly located prior to using the trampoline and enclosure.

1. **ALWAYS** ensure the door in the enclosure net is closed and the fixing hooks are in place.
2. **NEVER** allow more than 1 child on the trampoline at once.

3. Follow the age recommendation.
4. **ALWAYS** supervise children.
5. **Do not** perform somersaults of any type.
6. Never bounce to dismount from the trampoline.

## Using


- The child should familiarize themselves with the feel of the bounce of the trampoline.
- Master the 'brake bounce' technique by sharply flexing knees before contact with the mat. Use whenever balance or control is lost.
- Always start and finish a bounce on the centre of the mat indicated by the printed logo.

- Look forward while bouncing.
- Do not bounce for extended periods of time; fatigue can increase the risk of injury.
- Dismount from the trampoline in a controlled manner.
- Maximum user weight should not be exceeded.

## Basic bounces-Master end bounce before moving to the next


### The basic bounce

1. Start from the standing position, feet shoulder width apart, with head up and eyes on the mat.
2. Swing arms forward and up and around in a circular motion.
3. Bring feet together while in mid-air and point toes downward.
4. Keep feet shoulder width apart when landing on the mat.



### The seat bounce


1. Land in a full sitting position.
2. Place hands on the mat beside hips.
3. Return to the erect position by pushing with hands.



# User Instruction


## The Front bounce

1. Start with a low bounce.
2. Land in the prone position (face down) and keep hands and arms extended forward on the mat.
3. Push off the mat with arms to return to the standing position.



## The Front bounce

1. Start with front bounce position.
2. Push off with left or right hands and arms (depending on which way you wish to turn).
3. Keep head and shoulders in the same direction, keep back parallel to mat and head up.
4. Land in the prone position (face down) and return to the standing position by pushing up with hands and arms.



**Warning:** Advanced techniques such as somersaulting **MUST NOT** be attempted on this trampoline. To further develop skills a certified trampoline instructor should be contacted.

# Care and Maintenance

## General

This 6FT Trampoline was designed and manufactured with quality materials and craftsmanship.

If correct care and maintenance is provided, it will provide users with years of exercise, fun and enjoyment.

### Inspect regularly for:

- CHECK ALL NUTS AND BOLTS TWICE MONTHLY DURING THE USAGE SEASON FOR TIGHTNESS AND TIGHTEN AS REQUIRED. IT IS PARTICULARLY IMPORTANT THAT THIS PROCEDURE BE FOLLOWED AT THE BEGINNING OF EACH SEASON.
- Never use pliers to tighten up screws –these can cause damage to both the paintwork and the special anti-corrosion plating.
- Tighten all nuts and bolts securely. Replace as needed. If not checked regularly, bolts can be loose or missed and components can become detached and cause injuries.
- Check the unit at the beginning of the usage season and monthly thereafter for evidence of deterioration.
- Immediately remove and replace any items that appear to be weak or broken. Contact Customer Support for replacement parts.
- Check all covers designed for bolts and sharp edges regularly to be certain they are present and in good condition. Replace as needed. It is particularly important that all covers are checked prior to the first use each season.
- Inspect handle bar, hardware, and etc., for proper closure and for signs of wear, deterioration, rust and/or damage. Replace as needed.
- Check the unit at the beginning of the usage season and monthly thereafter for evidence of deterioration.
- Immediately remove and replace any items that appear to be weak or broken. Contact Customer Support for replacement parts.
- In windy conditions  
It is important that you secure your trampoline during windy conditions. Move the trampoline to sheltered area, secure the frame by the rim to the ground or, in extreme conditions, disassemble and store in a dry safe place.
- Moving the trampoline  
Care should be taken when moving the trampoline. It should be lifted by at least 2 people. Do not drag the trampoline.  
Holes and tears in the mat.  
Sagging mat.  
Loose stitching or deterioration to the mat.
- Bent or broken frame parts.
- Broken, damaged or missing springs.
- Sharp protrusions of any kind on frame, spring or the mat.
- To help maintain the products appearance, occasionally clean the seats and metal framework with a damp cloth lightly – but DO NOT use abrasive chemical cleaners.
- When the time comes to disassemble and dispose of this product, please completely disassemble the unit and discard of it in a safe place and manner so as not to present any hazard to any individual. It is important to check and maintain the main parts at regular intervals. If these checks are not carried out, the toy could overturn or otherwise become a hazard. Whenever practical, the instructions shall also be affixed to the toy.
- **IMPORTANT! KEEP FOR FUTURE REFERENCE.**

### WARNING!

- Assemble according to the manufacturer's instructions.
- Check regularly for wear and tear.
- Ensure fixings and anchorage is secure at all times.
- Check metal sections or components for signs of corrosion.
- Discontinue use if weakening or breakage is found.
- Failure to comply with these precautions may result in injury.
- Adult assembly is required.
- Not suitable for children under 36 months.
- Choking Hazard Not to be used by children over 6 years, insufficient strength.
- For outdoor and domestic use.
- Remove all packaging before giving to your child.
- Please keep this packaging for reference since it contains important information. Please read enclosed instructions before use.
- SPECIFICATIONS, COLOURS AND CONTENTS MAY VARY FROM ILLUSTRATIONS.
- Young children in play are unaware of potential dangers and hazards, therefore responsible adult supervision is essential.
- Jumpers should either wear socks, gymnastics shoes, or be barefoot when using the trampoline.



**WARNING! Not suitable for children under 3 years due to small parts, choking hazard.**



If you need help or have damaged or missing parts, call the Customer Helpline: 0843-5034455.  
Produced for Chad Valley Toys. Country of origin: China  
Address: 488 - 499 Avebury Boulevard, Central Milton Keynes, MK9 2NW.