

Black 7C.

PMS 7691

Art Release for Production (Mechanical)	
VRSE	
File Name:	01705_VRSEBATMAN_M_050117_G2A
Revision:	
License Approval Date:	
Production Release Date:	
Color:	5TH COLOR: PMS 7691C / BLACK 7C
Top Line:	
Notes:	
APPROVALS	
HALEY YONG:	_____
DAVID JARVIS:	_____
JOHN PROUDHIT:	_____
JOHN ABDELL:	_____
NELD LUCKICH:	_____

TROUBLESHOOTING

For more troubleshooting and tips, visit www.VRSE-VR.com

PROBLEM	SOLUTION
Adjusting the volume	Make sure to adjust the volume on your smartphone before inserting it into headset.
If the 3D effect is blurry	Use your adjustable lens sliders on the top of the headset to find the best focus settings for your eyes. Make sure smartphone is properly aligned in the tray.
Your controller is not being recognized by the App	Make sure Bluetooth setting is turned ON in your smartphone. Make sure controller is powered on with full batteries. If problem persists, attempt to close app and turn off controller, then launch app again and turn controller back on.
Smartphone buttons are pressed when the phone is clamped into the headset	Use included foam stickers on headset tray to prevent unwanted buttons being pressed during clamping.
Controller calibration	Occasionally the motion controller may need to be calibrated in app. Follow in-app instructions for more details.

Android and Google Play™ are trademarks of Google Inc.

Nexus is a trademark of Google Inc.

Apple, the Apple logo, the iPhone and the App Store are trademarks of Apple Inc., registered in the U.S. and other countries.

The App Store is a service mark of Apple inc.

Samsung Galaxy and Galaxy Note are trademarks of Samsung Electronics Co. Ltd.

LG and the LG logo are registered trademarks of LG Electronics, Inc. G3 and G4 are

trademarks of LG Electronics, Inc.

MOTOROLA, MOTO X and the Stylized M Logo are trademarks or registered

trademarks of Motorola Trademark Holdings, LLC. DROID is a trademark of

Lucasfilm Ltd. HTC, HTC ONE, and the HTC logo are trademarks of HTC Corporation.

WARNING! Not suitable for children under 36 months due to small parts. Choking hazard.

CAUTION ADULTS PLEASE NOTE: Adult supervision recommended. Please retain this instruction sheet for future reference. Colour and specification may vary from the product shown on this packaging.

We recommend that users who suffer from motion sickness or photosensitive epilepsy should take medical advice before using this product. If you experience discomfort or pain in a part of the body, such as head, eyes, ears, hands, arms, or legs, discontinue use of the system immediately. If symptoms persist, consult your doctor. Avoid prolonged use of VR. Take a 15-minute break during each hour of play. Avoid playing when you are tired or need sleep. IMMEDIATELY DISCONTINUE USE and consult your doctor before resuming gameplay if you or your child experience any of the following health problems or symptoms: Dizziness, altered vision, eye or muscle twitches, loss of awareness, disorientation, seizures, or any involuntary movement or convulsion. RESUME GAMEPLAY ONLY ON APPROVAL OF YOUR DOCTOR. Ensure that controllers are securely tethered on wrist during play to prevent damage to surroundings. Children should be supervised during play to keep them safely in the play area during use. Remember to stand in the same space and turn only on the spot, to prevent the user from straying in to objects or other people.

REQUIRES 2x **AAA (LR03) 1.5V** Not Included
Alkaline batteries recommended.

BATTERY SAFETY INFORMATION: Different types of batteries or new and used batteries are not to be mixed. Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged. Rechargeable batteries are only to be charged under adult supervision. Exhausted batteries are to be removed from the toy. Supply terminals are not to be short circuited.



The Wheelie bin symbol indicates that the product and the batteries must not be disposed of with other household waste as they may contain elements which can have a harmful effect on the environment and human health. Please use designated collection points or recycling facilities when disposing of the item and the batteries. To help locate your nearest facility see: www.recyclenow.com

SAFETY WARNINGS

- Never use the headset without a smartphone docked in the product.
- The product does not have UV protection; never look at the sun directly through the bare product.
- Some users may experience motion sickness while using this product. If you experience dizziness or disorientation, immediately discontinue use until the discomfort subsides.
- Vision of the user may be blocked by the product when in use. Always be aware of your surroundings and only use in a safe environment. Users should not walk or run while using this product and should remain stationary. Make sure you have adequate room to use your controller without it colliding with your surrounding area. Do not use this product in crowded areas. Use caution to avoid injury.
- Avoid prolong use. Take a 10 minute break every 10 minutes you play, even if you don't think you need it.
- Use the wrist safety strap at all times to prevent damage and injury.
- Headstraps or headset should be adjusted and properly fitted to user's head, to prevent headset displacements resulting in eye injuries.

Hereby, Skyrocket LLC declares that this toy is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The declaration of conformity may be consulted at:
<http://vividtoysandgames.co.uk/VRSE>.

For app compatibility, please check VRSE-VR.com

BATMAN and all related characters and elements © & ™ DC Comics. (s17)

Consumer Services: Vivid Toy Group Ltd., PO Box 164, Hockley, Essex, SS5 4BA, UK.

Imported by Vivid Toy Group Ltd, GU3 1LS, UK.

Manufactured by Skyrocket LLC, Los Angeles CA 90066 USA.

SKYROCKET

©2017 Skyrocket LLC, Los Angeles, CA 90066 USA.

All Rights Reserved. VRSE and the Skyrocket logo are trademarks of Skyrocket LLC. Other trademarks and trade names are those of their respective owners, and there is no relationship express or implied with Skyrocket LLC.

MADE IN CHINA.

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Google Play is a trademark of Google Inc.

SR10006



VRSE

VR ENTERTAINMENT SYSTEM

CONTENTS:

VRSE Headset


VRSE Motion Controller

Batarang™ Controller

Safety Wrist Strap

Foam Sticker Insert

Instruction Sheet



SMARTPHONE REQUIRED
(NOT INCLUDED).

Download the FREE
Batman VRSE Game



Download on the
App Store



GET IT ON
Google Play

VRSE-ATILITY

The VRSE VR headset can also be used to view VR movies and other VR media supported by your smart phone.



360° MOVIES



FPV DRONE
FLYING

VRSE-VR.com

AGES
8+

Compatible Smartphone Required

VRSE Headset works best with the following smartphones or newer (not included)


iPhone 7 Plus	Samsung Galaxy S7 Edge	LG G5	Google Nexus 5X
iPhone 7	Samsung Galaxy S7	LG G4	Google Nexus 6P
iPhone 6s Plus	Samsung Galaxy S6 Edge+		Google Pixel
iPhone 6s	Samsung Galaxy S6 Edge		Huawei P9
iPhone 6 Plus	Samsung Galaxy S6		OS Lollipop 5.0 and above
iPhone 6	Samsung Galaxy Note 5		
iOS 10 and above			

NOTE: VRSE™ may also work with some smartphones not listed above that have screens between 5 and 6 inches.

INSTRUCTIONS


INSTALL BATTERIES

- 1** Batteries to be replaced by an adult. Open the battery compartment on the back of VRSE Motion Controller using a cross-head screwdriver.




- 2** Place batteries into the battery compartment (note correct polarity).

- 3** Place the compartment door back on VRSE Motion Controller and secure in place. Do not over tighten the screw.




ASSEMBLE CONTROLLER

- 1** Thread wrist strap through opening in Batarang™ front.




- 2** Place Motion Controller into front section of Batarang™.


- 3** Attach back of Batarang™ to the front.



- 4** Place your hand through the wrist strap and hold the VRSE Motion Controller and tighten strap. Hold firmly so that controller will not fall or fly off during play.




HOW TO USE CONTROLLER




LOAD PHONE INTO TRAY


- 1** Slide out smartphone tray from headset. Launch the VRSE App on your smartphone and make sure your device's Bluetooth setting it turned ON.




- 3** Align smartphone so that the headphone port is accessible and plug in headphones now.



- 2** Insert your smartphone into the tray by securely positioning it under the clamp and align the middle of the phone with the midline on the tray clamp. Make sure the phone screen is facing forward.
NOTE: You may need to adhere included Foam Stickers to the tray to prevent the clamp from pressing down on your smartphone's side buttons.




- 4** Slide tray back into headset.



ADJUST HEADSET AND LENSES

- 1** Adjust head straps on top and sides to secure your fit.



- 2** Adjust lenses by moving the sliders forward and back and side to side. Keep adjusting and trying different positions until the screen image is in focus.
NOTE: Make sure to remove protective films from lenses.

