


FEATURING THE ECLIPSE® PRO DARTBOARD AS USED AT
THE PDC WORLD CHAMPIONSHIPS




The official dartboards
of the Professional
Darts Corporation





PLEASE NOTE:
Experience has shown that
machined points will
greatly reduce the life of
this dartboard.



SILVER FINISH CABINET WITH SHAPED DOORS FEATURING FOUR WORLD CHAMPION SIGNATURES AND CHALK SCOREBOARD

- ECLIPSE® PRO DARTBOARD**
- Championship quality bristle board
 - PDC endorsed
 - Designed to maximise averages
 - Unicorn high technology wiring design
 - Completely staple-free construction
 - Ultra-slim segmentation system - 30% thinner than conventional round wire boards
 - Increased target area - especially in Doubles and Trebles
 - Ultra high visibility number ring and spider - rotate the number ring regularly to even out areas of wear
 - Staple-free Bullseye

NATURAL COMBED SISAL BOARD
Sisal's properties make it uniquely suitable for Dartboards:-

- Naturally lubricated fibres
- Self-healing individual bristles
- Immediate shape recovery
- Consistent overall density
- Resilient and durable

TWO SETS OF PROFESSIONAL DARTS WITH JOHN LOWE & RAYMOND van BARNEVELD WORLD CHAMPION FLIGHTS

CHALK & WIPER INCLUDED



ALSO INCLUDES:

- WORLD CHAMPION WAYS TO FINISH POSTER
- SELF ADHESIVE OCHE LINE
- RULES OF DARTS BOOKLET
- TAPE MEASURE

© 2015 Unicorn Products Limited
N62 4DS England
www.unicorn-darts.com

Designed by Unicorn in England
Crisé en Angleterre
In England entwickelt
Disegnato in Inghilterra

Made in China
Fabriqué en Chine
Hergestellt in China
Fabricado en China




#46155

WARNING: The packaging of this product contains silica gel desiccant. Discard safely away from babies and children. Do not allow it to be eaten.
ATTENTION: L'emballage de ce produit contient un agent déshydratant au gel de silice. Veuillez l'éliminer en toute sécurité et le tenir à l'écart des bébés et des enfants. Ne le laissez pas être mangé.
AVISO: El empaque de este producto contiene gel de sílice desecante. No permita que sea ingerido.

HANGING INSTRUCTIONS AND COMPONENTS

- Unpack dartboard cabinet and if applicable remove dartboard from inside.
- Measure from floor a distance of 1972mm and make a mark on the wall/surface to which the cabinet is to be mounted. This forms the vertical centre line of the cabinet and dartboard.
- From this centre point, measure out 232mm on either side. This indicates the position of the screws to hang the cabinet onto the wall. These two points need to be horizontal otherwise the cabinet will hang at an angle. To achieve this we suggest you use either a Spirit Level or measure independently from the floor to these fixing points so the distance is the same, and should be the same as the centre point.
- As a check, measure the distance between these two outer points and check it against the distance between the two hanging slots on the cabinet. These distances should be the same.
- We have deliberately not supplied Raw Plugs and Fixing Screws because different wall constructions require different fixings. We suggest you consult your local DIY or hardware store to obtain the correct fixings for your particular construction of wall.
- Having obtained the correct fixings we suggest the minimum of a Number 8 Screw, 48mm (long), drill the appropriate size hole to take the fixings/Raw Plugs and screw the screws into the fixings (Raw Plugs). The screws should be almost completely screwed in, leaving approximately 5mm between the underside of the head and the surface of the wall.
- Line up the cabinet with the screws and drop the cabinet onto the screws. You may require to take the cabinet off to adjust the clearance between the wall and the underside of the screws.
- Fix the dartboard hanger plate to the inside back of the cabinet using the bolts, washers and nuts (washers and nuts on the wall side of the cabinet). Ensure the slot in the hanger plate is pointing upwards.
- Screw the screw into the centre of the back of the dartboard. This is marked with a dot or a drill point.
- Place a tack through a black foot and hammer into the back of the board at one of the three other marks on the back of the board (these three marks could be black dots or drilled points). Repeat two more times at the remaining markers.
- Fix the cabinet to the wall. Place the dartboard as high in the cabinet as possible, slide the dartboard down allowing the screw in the back of the board to engage in the dartboard hanger plate.

- ADJUSTABLE NUMBER RING.**
Rotate the number ring regularly to even out areas of wear.



If you have any missing parts or damaged items, please contact assist@unicorngroup.com in the first instance before any return to the store of purchase

GENERAL RULES OF DARTS APPLICABLE TO ALL GAMES

- To decide who plays first, each player or one from each side throws one dart, the player hitting nearer the centre starts the game.
- Players throw three darts each throw.
- Darts only score that remain in the board on completion of a throw.

TOURNAMENT DARTS

- There are many different games which can be played on the dartboard. By far the most universally played game worldwide is Tournament Darts. The rules below are the standard rules but may be varied locally by established usage or agreement.
- Each side starts with 301 or 501 points. The method of scoring is to subtract each score from the remaining total.
 - The first side to reduce their score exactly to zero is the winner.
 - Games must be started by throwing any double.
 - No darts count to a side until they have thrown a double.
 - Rule 3 is often waived so that all darts thrown count from the beginning. This procedure is called 'straight start'. Rule 5 is never waived.
 - To finish, a double (or bullseye) which exactly reduces the remaining score to zero must be thrown.
 - For the purposes of Rules 3 and 5 'Bullseye' counts as double 25.
 - If a greater score is thrown than is required to reduce the remaining score exactly to zero, the whole throw of three darts does not count and the score remains as it was before that particular throw was taken.
 - Each game is called a 'leg'. 3 legs make a match and the ultimate winner is the player who first wins 2 legs.
 - The score of 301 is used mainly for games between two individuals. For team play the opening score should be increased to 501 or 1001 depending on team size.


For further information on this and other Unicorn products please visit www.unicorn-darts.com

C1685HSE

BARCODE 054722461557



PLEASE NOTE:
Experience has shown that
machined points will
greatly reduce the life of
this dartboard.



SILVER FINISH CABINET WITH
SHAPED DOORS FEATURING FOUR
WORLD CHAMPION SIGNATURES
AND CHALK SCOREBOARD

- ECLIPSE® PRO DARTBOARD**
- › Championship quality
bristle board
 - › PDC endorsed
 - › Designed to maximise averages
 - › Unicorn high technology
wiring design
 - › Completely staple-free
construction
 - › Ultra-slim segmentation system –
30% thinner than conventional
round wire boards
 - › Increased target area – especially
in Doubles and Trebles
 - › Ultra high visibility number ring
and spider - rotate the number
ring regularly to even out areas
of wear
 - › Staple-free Bullseye

NATURAL COMBED SISAL BOARD
Sisal's properties make it uniquely
suitable for Dartboards:-

- › Naturally lubricated fibres
- › Self-healing individual bristles
- › Immediate shape recovery
- › Consistent overall density
- › Resilient and durable

**TWO SETS OF PROFESSIONAL
DARTS WITH JOHN LOWE &
RAYMOND van BARNEVELD
WORLD CHAMPION FLIGHTS**

CHALK & WIPER INCLUDED




ALSO INCLUDES:

- › **WORLD CHAMPION
WAYS TO FINISH POSTER**
- › **SELF ADHESIVE OCHE LINE**
- › **RULES OF DARTS BOOKLET**
- › **TAPE MEASURE**



HANGING INSTRUCTIONS AND COMPONENTS

1. Unpack dartboard cabinet and if applicable remove
dartboard from inside.
2. Measure from floor a distance of 1972mm and make a mark on the
wall/surface to which the cabinet is to be mounted. This forms the
vertical centre line of the cabinet and dartboard.
3. From this centre point, measure out 232mm on either side. This
indicates the position of the screws to hang the cabinet onto the wall.
These two points need to be horizontal otherwise the cabinet will hang
at an angle. To achieve this we suggest you use either a Spirit Level or
measure independently from the floor to these fixing points so the
distance is the same, and should be the same as the centre point.
4. As a check, measure the distance between these two outer points and
check it against the distance between the two hanging slots on the
cabinet. These distances should be the same.
5. We have deliberately not supplied Raw Plugs and Fixing Screws
because different wall constructions require different fixings. We
suggest you consult your local DIY or hardware store to obtain the
correct fixings for your particular construction of wall.
6. Having obtained the correct fixings we suggest the minimum of a
Number 8 Screw, 40mm (long), drill the appropriate size hole to take the
fixings/Raw Plugs and screw the screws into the fixings (Raw Plugs).
The screws should be almost completely screwed in, leaving
approximately 5mm between the underside of the head and the surface
of the wall.
7. Line up the cabinet with the screws and drop the cabinet onto the
screws. You may require to take the cabinet off to adjust the clearance
between the wall and the underside of the screws.
8. Fix the dartboard hanger plate to the inside back of the cabinet using
the bolts, washers and nuts (washers and nuts on the wall side of the
cabinet). Ensure the slot in the hanger plate is pointing upwards.
9. Screw the screw into the centre of the back of the dartboard. This is
marked with a dot or a drill point.
10. Place a tack through a black foot and hammer into the back of the
board at one of the three other marks on the back of the board (these
three marks could be black dots or drilled points). Repeat two more
times at the remaining marks.
11. Fix the cabinet to the wall. Place the dartboard as high in the cabinet as
possible, slide the dartboard down allowing the screw in the back of the
board to engage in the dartboard hanger plate.



12. **ADJUSTABLE NUMBER RING.**
Rotate the number ring regularly
to even out areas of wear.

If you have any missing parts or damaged items,
please contact assist@unicorngroup.com in the first
instance before any return to the store of purchase

GENERAL RULES OF DARTS APPLICABLE TO ALL GAMES

1. To decide who plays first, each player or one from each side throws
one dart, the player hitting nearer the centre starts the game.
2. Players throw three darts each throw.
3. Darts only score that remain in the board on completion of a throw.

TOURNAMENT DARTS

- There are many different games which can be played on the dartboard.
By far the most universally played game worldwide is Tournament
Darts. The rules below are the standard rules but may be varied locally
by established usage or agreement.
1. Each side starts with 301 or 501 points. The method of scoring is to
subtract each score from the remaining total.
 2. The first side to reduce their score exactly to zero is the winner.
 3. Games must be started by throwing any double.
 4. No darts count to a side until they have thrown a double.
 5. Rule 3 is often waived so that all darts thrown count from the
beginning. This procedure is called 'straight start'.
Rule 5 is never waived.
 6. To finish, a double (or bullseye) which exactly reduces the
remaining score to zero must be thrown.
 7. For the purposes of Rules 3 and 5 'Bullseye' counts as double 25.
 8. If a greater score is thrown than is required to reduce the
remaining score exactly to zero, the whole throw of three darts
does not count and the score remains as it was before that
particular throw was taken.
 9. Each game is called a 'leg'. 3 legs make a match and the ultimate
winner is the player who first wins 2 legs.
 10. The score of 301 is used mainly for games between two individuals.
For team play the opening score should be increased to 501 or
1001 depending on team size.



For further information on this and
other Unicorn products please visit
www.unicorn-darts.com

C1685W


BARCODE 054722461557



RIGHT SIDE



LEFT SIDE



BOTTOM



TOP