


Under Basin Unit

Assembly Instructions- please keep for future reference

833/2763



Dimensions

Width - 48cm
Depth - 30cm
Height - 60 cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 1 and 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.




- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




1 Top x 1
(48(w)cm x 30(d)cm)




2 Left side x 1
(58.5(h)cm x 28.5(d)cm)




3 Right side x 1
(58.5(h)cm x 28.5(d)cm)




4 Base x 1
(40(w)cm x 28(d)cm)




5 Bottom rail x 1
(6.9(h)cm x 40(w)cm)




6 Left door x 1
(49.2(h)cm x 19.7(w)cm)



7 Right door x 1
(49.2(h)cm x 19.7(w)cm)



8 Back panel x 2
(52(h)cm x 10(w)cm)















9 Internal shelf x 1
(42(w)cm x 25.6(d)cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  <p>35mm Male camlock x 8</p>	B  <p>Female camlock x 8</p>	C  <p>14mm Screw x 2</p>	D  <p>Magnetic catch x1</p>
E  <p>Back panel screw x 10</p>	F  <p>Wooden dowel x 5</p>	G  <p>Hinge x 4</p>	H  <p>Knob x 2</p>
I  <p>16mm Screw x 2</p>	J  <p>Catch plate x 2</p>	K  <p>10mm Screw x 2</p>	L  <p>Shelf bracket x 4</p>

Tools required



Phillips screwdriver
(medium & large)

Ruler – Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Screw 4 x 35mm male camlock **A** into the underside of the top panel **1** as shown.


Connect the magnetic catch **D** using 2 x 14mm screw **C**.




Additional Components

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



30mm Screw x 1



Rawl plug x 1




Safety strap x1



20mm Screw x 1

Tools required




Drill
(for wall drilling only)

Supplementary Assembly Instructions

Step 1

In order to prevent accidental toppling it is recommended to secure the unit to a wall using the supplied safety strap.

Connect safety strap **O** to rear of the unit as shown using 1 x 20mm screw **P** (**note:** this screw replaces the back panel screw **E** detailed in the main instructions).




Step 2

Secure safety strap to wall using 30mm screw **M** and rawl plug **N** as shown.

Note: please refer to the reverse of this instruction sheet for additional wall fixing options.




Warning:
Before drilling,
check wall for
hidden pipes
and cables.



Assembly Instructions

Step 2


Insert 4 x female camlock **B** into the underside of base **4** as shown.



Step 3


Screw 2 x 35mm male camlock **A** into the holes at the bottom of the left side **2** and right side **3** as shown.

Insert 2 x female camlock **B** into the holes at the top of the left side **2** and right side **3** as shown.



Step 4


Insert 5 x wooden dowel **F** into the bottom rail **5** as shown.



Assembly Instructions

Step 5

Connect bottom rail **5** to underside of base **4** as shown.




Step 6

Connect assembly completed in Step 5 to left side **2** as shown.

Tighten female camlocks in underside of base **2** with a screwdriver (**a:**).

Note: you should feel a click when the camlocks are secured.




Step 7

Connect right side **3** to other end of assembly completed in Step 5 as shown.

Tighten female camlocks in underside of base **2** with a screwdriver (see Step 6 **a:**).

Note: you should feel a click when the camlocks are secured.

Note: it may be helpful to have assistance from another person with this stage.



Assembly Instructions

Step 8

Connect knobs **H** to doors **6** and **7** using 16mm screws **I** as shown.


Connect catch plates **J** to doors **6** and **7** using 10mm screws **K** as shown.

Insert a hinge **G** into the top and bottom of doors **6** and **7** as shown.

Note: it may be helpful to have assistance from another person with the next stage.

Locate door hinges in place in base as shown, then connect the top panel **1** ensuring that top hinges of doors slot into place (**b:**), and tighten female camlocks on inside of left and right side with a screwdriver (see Step 6 **a:**).


Note: you should feel a click when the camlocks are secured.



Assembly Instructions


Step 9

Connect back panels **8** using 10 x back panel screw **E** as shown.



Step 10

Insert 4 x shelf bracket **L** inside the unit at the desired height as shown and set internal shelf **9** in place.



Assembly complete.

If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800

A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.



Important: when drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule: always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: always check the fitting and location to ensure your safety in and around the home.

Fitting: from time to time check the fitting to ensure the wall plugs or screws do not become loose.