


Wall Cabinet

Assembly Instructions- please keep for future reference

833/4431

hygena



Dimensions

Width - 30cm

Depth - 15cm

Height - 50cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 1 and 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.




- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels


Please check you have all the panels listed below




1 Top x 1
(30(w)cm x 15(d)cm)




2 Base x 1
(27(w)cm x 13.5(d)cm)




3 Right side x 1
(47(h)cm x 13.5(d)cm)




4 Left side x 1
(47(h)cm x 13.5(d)cm)




5 Support rail x 1
(24(w)cm x 6(h)cm)



6 Back panel x 1
(47.8(h)cm x 24.8(w)cm)



7 Door x 1
(46.5(h)cm x 23.5(w)cm)

















8 Shelf x 1
(23.8(w)cm x 9.8(d)cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  35mm Male camlock x 8	B  Female camlock x 8	C  16mm Bolt x 2	D  Handle x 1
E  14mm Screw x 2	F  Magnetic catch x 1	G  10mm Screw x 9	H  Hinge x 2
I  30mm Wooden dowel x 4	J  Catch plate x 1	K  Shelf bracket x 4	L  40mm Wall screw x 2
M  Washer x 2	N  Rawl plug x 2		


Tools required



Phillips
screwdriver
(medium &
large)



Drill (for wall
drilling only)



Spirit level


Ruler – Use this ruler to help correctly identify the screws



Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 3


Push the male camlock into the entry hole.



Step 2

Insert the female camlock as shown in the instructions.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.




Assembly Instructions

Step 1


Fix 4 x 35mm male camlock **A** into underside of top **1** as shown.

Connect magnetic catch **F** to underside of top **1** using 2 x 14mm screw **E** as shown (**a**).



Step 2


Fix 4 x 35mm male camlock **A** base **2** as shown.



Assembly Instructions


Step 3

Insert 2 x 30mm wooden dowel **1** into each end of support rail **5** as shown.



Step 4


Insert 4 x female camlock **B** into right side **3** and left side **4** as shown.



Step 5

Connect left side **4** and right side **3** to support rail **5** as shown.


Note: the unit is upside down at this point.



Assembly Instructions

Step 6


Connect top **1** to assembly completed at Step 5 as shown and tighten the female camlocks inside the unit with a screwdriver.



Step 7

Slide back panel **6** into the slots of left and right sides and push firmly down to locate.


Note: the holes in the back panel should point downwards at this stage and should line up with the holes in support rail **5** when back panel is fully inserted.



Step 8

Connect base **2** to the assembly as shown and tighten the female camlocks inside the unit with a screwdriver.

Turn the unit right way up to complete the remaining steps.



Assembly Instructions


Step 9

Connect door **7** to the unit using 2 x hinge **H** and 8 x 10mm screw **G** as shown (**b:**).

Connect handle **D** to door using 2 x 16mm bolt **C**.

Connect catch plate **J** to door using 1 x 10mm screw **G**.


Note: catch plate **J** must be attached with the countersink facing outwards so as to accommodate the screw head.



Step 9

Insert 4 x shelf bracket **K** into holes inside the unit at the desired heights ensuring that each set of shelf brackets are level with each other.

Set shelf **8** onto shelf brackets as shown.



Assembly Instructions

Step 10

Note: you may find it easier to have help from another person at this stage.

To fix the unit to a wall hold the unit in the desired position against the wall, using a spirit level to ensure the unit is horizontal/vertical.

Mark the wall through the holes in the back panel of the unit to establish the screw positions.

Set the unit aside and drill the wall at the mark locations using an appropriate drill bit.

Insert 1 x rawl plug **N** into each hole.


Screw the unit to the rawl plug using 2 x 40mm wall screw **L** inserted through 2 x washer **M**.

Note: see the back cover for more information on wall mounting and the suitable use of the supplied rawl plugs.




Warning:
Before drilling, check wall for hidden pipes and cables.

Assembly complete.




A Guide to Wall Mounting & Fixings



IMPORTANT:

When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


HINTS:

- 1) General Rule  Always use a larger screw and wall plug if you are not sure.
- 2) Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3) Ensure you drill the hole horizontally, do not force the drill or enlarge the holes.
- 4) Take extra care when drilling high walls, ceilings and ceramic tiles.
Ensure the plug is fitting below the ceramic tile to avoid splitting or cracking.
- 5) Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of Wall


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone, wood or plaster board.

No.1 "Standard" Wall Plug General Wall Materials




These come in various sizes and are made from plastic or sometimes wood fiber.

No.2 "General Purpose" Wall Plug Aerated / Breeze Block




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, a General Purpose Plug can be used.

No.3 "Shield Anchor" Wall Plug Heavy loads




For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.

No.4 "Cavity Fixing" Wall Plug




For use with plaster board partitions or hollow wooden doors.

No. 5 "Cavity Fixing - Heavy Duty" Wall Plug



For use when fitting or supporting heavy loads such as shelving wall cabinets, coat racks.

No.6 "Hammer Fixing" Wall Plug



For use with walls stuck with plaster board. The hammer fixing allows it to be fixed to the wall rather than the plaster board. Always check the fixing is secure to the retaining wall.

CARE AND MAINTENANCE

SAFETY

Always check the fitting and location to ensure your safety in and around the home.

FITTING

From time to time check the fitting to ensure the wall plugs or screws do not become loose.

If you need help or have damaged or missing parts, call the Customer Helpline: 0845 640 0800
Home Retail Group, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, Bucks, MK9 2NW