


# nuband



## NUBAND ACTIVE 3 NU-G0040

User Manual Version 1.3



**INDEX**


---

DEVICE ACTIVATION AND CHARGING	P. 2
PRODUCT QUICK USE	P. 3
PAIRING BRACELET	P. 4
PERSONAL DATA SETTINGS	P. 6
SYNCHRONOUS DATA	P. 7
FUNCTION ICONS	P. 8
SLEEP MONITOR	P. 9
CALL AND NOTIFICATION REMINDER	P. 10
SEDENTARY REMINDER	P. 11
ALARM SETTING	P. 12
REMOTE CAMERA CONTROL	P. 13
SET YOUR GOALS	P. 14
NUBAND ACTIVE 3 FAQ	P. 15
FIRMWARE UPDATE	P. 16
SHARING FUNCTION	P. 17
UNPAIR	P. 18
PRODUCT SPECIFICATION / EU DECLARATION OF CONFORMITY	P. 19
WARRANTY	P. 20
DISCLAIMER & RETURNS	P. 21

## 1.DEVICE ACTIVATION AND CHARGING


### A) How to charge it

1. Built-in USB Charger. No additional charger needed.
2. Pull out the band (the side without wristband buckle, both sides can be pulled out).
3. Plug the device (the side with chip) directly into any USB port, Laptop or an Adaptor to charge the battery.




### B) Activate the Device

Before use, please connect the battery charger to charge the device for activation. The progress bar will change from empty to full to indicate full activation. After activation, the device will start charging the battery.



### C) Battery Indicator

The battery indicator is displayed on the home screen of the device. When the battery of the device is lower than 10%, all functions are closed and only lower battery icon will show to remind you to charge the battery.



Low  
battery

Fully  
charged  
battery

## EN

When using this band for the first time, please charge 2-3 hours prior to use. When charging, the battery symbol will appear and the band will automatically switch on, time and date will automatically update when the phone is synced and connected.

### Notice:

1. Press the front touch button, the band screen will lit up, and it will enter the clock interface by default
2. Open '*Lift wrist to light on screen*' under app setting, the screen would lit up when the wrist is turned over.

## 2.PRODUCT QUICK USE






### Download and install

You have to download and install the “**Nuband Health**” App from the App store or Google Play store.

### 3. PAIRING BRACELET

1. Open the Bluetooth on the phone
2. **Open App** > Select **Nuband Active 3** > click **“Pair Device”** > **“Searching Device”** > click the **device code** when it is searched > **pair** successfully.
3. After pairing , it will show **“Bluetooth Pairing Request”** , click **“Pair”**.







## 4.PERSONAL DATA SETTINGS



Under Home Screen click on the left top **Menu Bar** , then click **Setting** > **Personal Info** to enter personal information. This will then personalize information on your band for more accurate data.

(Menu Bar)



## 5.SYNCHRONOUS DATA

The band automatically synchronizes the data after pairing/connecting with the smart phone or you may hold and swipe down the interface to manually synchronize. Data includes steps, calories, distance, date and time. You can check the history data by the menu bar .






## 6.FUNCTION ICONS

Touch the screen to cycle through each function display.





Set vertical or horizontal display from the APP.





## 7.SLEEP MONITOR

You need to wear the band during sleep, and the band will analyze the quality of your sleep according to your nocturnal movements and monitor your entire sleep schedule. You can view this information daily or check the History Data by the menu bar.



## 8. CALL AND NOTIFICATION REMINDER




**8.1** After connecting the band to your smart device, enter the notification page under setting to turn on the incoming call and message reception, and the band will receive the message, phone call, Facebook messages and/or selected chat apps.

**Please accept phone app permission under the Phone Setting.**




## 9. SEDENTARY REMINDER

To set a sedentary reminder, go under the notification page, go to **Sedentary Reminder** > **Start Date** > **Set Your Time**. If you are not active within the set time, the band will vibrate to remind you to move.




## 10.ALARM SETTING

Under the notification screen, select 'Wakeup Alarm' to set the alarm; the band will vibrate at the preset times. The alarm clock can be set daily, by a day of the week, alarm type, and you can create up to 5 alarm clocks.




## 11.REMOTE CAMERA CONTROL

Go to **Setting > Camera Control**, turn on the phone camera > then shake the band to take a photo. The screen will display taking photo. Remember to accept the app to access your camera.





## 12.SET YOUR GOAL

You can set your goals by selecting 'Work Out Plan' under homepage, then select 'Setting' and select your customize workout plan.




## 13.NUBAND ACTIVE 3 FAQ

There are “FAQ” under the **About** page, it will answer the most common questions about the application, including setting and using additional functions.





## 14.FIRMWARE UPDATE

There is a “**Firmware upgrade**” section under the **About** page, which will show the current firmware version and new update for the latest firmware version.





## 15.SHARING FUNCTION

Click on the Sharing icon to share your information via Facebook, Twitter , Instagram or other social media.



## 16.UNPAIR

If you need to disconnect the band , click ‘Setting’, click “About Device”, press “Unpair”.



## PRODUCT SPECIFICATION

Size: Main body: 42 X 10 X 247mm

Wristband: 210\*16.8 mm

Weight: 22g

Battery: 55mAh Rechargeable

lithium polymer battery

Display: 0.91' OLED

Data Memory: 30 days

Walking distance: Max 999.99km

Calories burned: Max 9999.9kcal

Activity time: 99h59min

Waterproof Level: IP65

Bluetooth: 4.0

Working condition: -10°C~50°C

## EU DECLARATION OF CONFORMITY

This product conforms with Radio Equipment Directive (RED) 2014/53/EU. You can download the full declaration letter from our website. See below URL link for details.

<https://www.nutechdesign.com/pages/declaration-of-conformity>

## Nuband Active 3, 12 Month Warranty

Nuband Active 3 is covered by a 12 months (1 year) warranty against defects in materials and workmanship under normal use.

If a hardware defect occurs within the warranty period of 12 months Nuband Active 3 will either replace defective part or provide a replacement product, providing proof of purchase is sent with the item. A replacement product or part assumes the remaining warranty of the original product or 12 months from the date of replacement or repair, whichever is longer.

When a product is exchanged or part of product is exchanged, any replacement becomes your property and replaced item becomes Nuband Active 3 property. Parts provided by Nuband Active 3 in fulfillment of this warranty obligation must be used in products for which warranty services is claimed. When returning product under warranty, item must be returned along with original packaging and retailer receipt. Without the receipt, the warranty will be considered invalid.

It is your responsibility to back any data up. If in repair or replacement, goal data is lost Nuband Active 3 claim no responsibility for this. Nuband Active 3 is not responsible for product failure caused by none compliance with product instructions. The warranty does not cover the cost of returning the product, this must be born by the customer.

No Nuband Active 3 reseller, agent or employee is authorized to make any modification, extension or addition to this limited warranty. If any term is held to be illegal, or unenforceable, the legality or enforceability of the remaining terms shall not be affected or impaired.

## Nuband Active 3 Product Disclaimer

Nuband Active 3 is a device developed to assist monitoring aspects of your health but should never replace the professional advice of your Doctor or Physician. Nuband Active 3 are not a licensed medical conditions or any kind, or determining the effect of any specific exercise on a medical condition.

We strongly recommend that you should consult a Doctor or Physician before partaking in any type of physical exercise fitness plan or diet.

## Returns

If your Nuband Active 3 should ever need to be replaced under warranty, send your Nuband Active 3 along with proof of purchase to the following address:

Dartmouth Brands Ltd  
C/O Ibex Fulfilment Logistics  
Unit 15 Hearder Court  
Beechwood Way  
Plymouth PL7 5HH  
UK  
Email : [info@nutechdesign.com](mailto:info@nutechdesign.com)

Because of possible loss, we recommend insuring your Nuband Active 3 , return receipt requested, when using the mail. If you do not obtain the proper receipt within a reasonable time, start a tracer through the originating post office. Please allow 2 to 3 weeks from the date we receive your package for your replacement Nuband Active 3 to arrive.

RoHS  
COMPLIANT



For more information please visit  
[www.nuband.co.uk](http://www.nuband.co.uk)

Follow us on



Facebook



Twitter



Instagram