

# FRONT

Argos

CONSTANT



— GUARANTEE —

Your watch is guaranteed against any manufacturing defects for five years from the date of purchase. The guarantee covers labour and any necessary parts. This guarantee does not cover the glass, strap or battery, or any damage caused by accident or carelessness. Should it be necessary during the guarantee period to return your watch for repair please return it well packed by registered post, as we are unable to accept responsibility for watches lost in transit. Please do not return any presentation boxes. Please enclose receipt as proof of purchase and a cheque / Postal Order for £3.50 Sterling for return postage.

### Battery replacement

If your watch stops it is more than likely to require a new battery. DO NOT attempt to replace the battery yourself, as this will invalidate the guarantee. Please take the watch to a qualified watch repairer, or return it to the Service Centre with a £5.75 (Sterling) cheque / P.O. to cover the new battery and return postage.

### Instructions for use...

#### Regular watch movement...

- A)** Normal running position. If watch is water resistant, it must be in position 'A' when in contact with water.
- B)** GENTLY pull the crown to position 'B' and turn to adjust time.
- C)** When required position of hands has been achieved, GENTLY push back crown so that watch will automatically start, and continue normally.



#### Calendar watch movement

- A)** Normal running position.
- B)** GENTLY pull the crown one 'click' from the normal running position, and turn anti-clockwise to adjust the date.
- C)** Gently pull the crown two 'clicks' from the running position and turn to the required time.



### Bracelet/Strap Adjustment

Should links need to be removed, then the watch needs to be professionally adjusted and should be returned to our service centre.

Please refer to the enclosed bracelet adjustment strip for details on returning your watch for length adjustment.

### Watches with adjustable clasp

The bracelet has a small adjustment on the clasp. It is supplied on the largest adjustment. To relocate, depress the spring with a fine point to release it. Relocate to correct position and fit by depressing the spring and guiding it into the locating hole.



2

3

4

# BACK

### Self adjusting bracelets

This bracelet is fitted with self-adjusting clasps. These allow you to remove up to three links. Between the minimum and maximum tolerance adjustments, you should find a suitable fitting for most wrist sizes.



### Water Resistance

Dial or Caseback Marking	Light shower or splash	Swimming	Shower (Shower with/OUT straps)	Shower (Shower with/OUT straps)	With Crown pulled out
Water Resistant 30m	✓	✓	✓	✓	✓
Water Resistant 50m	✓	✓	✓	✓	✓
Water Resistant 100m	✓	✓	✓	✓	✓

5

6

### Note

Pressure shown should not be considered as corresponding to actual diving depth, as movement through water will increase the pressure at a given depth. Diving also increases the pressure. This explains why you MUST NOT 'dive' in water with a 50 metre watch as the pressure may be greater than the watch seals can tolerate.

### How to identify if your watch is water resistant

Water resistant markings, if applicable, will be shown on the dial or case back. If your watch does not have any water resistant markings then it will NOT be water resistant and should not be placed in or near water.

### Care of your watch...

- Keep your watch away from strong magnets as accuracy will be affected. Normal accuracy will return when moved away from the magnet.
- To prevent rusting of the case caused by dust, moisture and perspiration, wipe periodically with a soft dry cloth.
- Any dirt left on a watch may cause skin rashes.
- Avoid wearing your watch near strong chemicals, solvents or gases, spray cosmetics, nail polish, nail polish remover; these substances may cause discolouration or damage, and consequently are NOT covered in the guarantee.

- Keep your stone set watch away from water, perfume and other liquids which may discolour the stones.

### Additional care for stone set watches

- Please note multi-stone set watches are dress watches and not suitable for everyday use.
- Please avoid impact with surfaces as this may loosen or damage the stone setting.
- Should your watch require bracelet alteration please follow the details on the bracelet shortening strip and do not attempt yourself as this may invalidate your guarantee.

Date of purchase \_\_\_\_\_

Product ID Reference No. \_\_\_\_\_

This ID Ref. is your receipt of purchase and must be supplied.

Supplied by \_\_\_\_\_

Should it be necessary during the guarantee period to return your watch for repair, please return it well packed by registered or recorded post, as we are unable to accept responsibility for any watches lost in transit. Please enclose a cheque or P.O. for £3.50 to cover post, handling and insurance.

7

Address clearly and do not return any presentation boxes. Please state nature of complaint. Return to:

C.I. Services  
P.O. Box 2016  
Bolton, West  
BLS 3YH

Service Centre No: 01942 845 614.

