


Ohio - Coffee Table

Assembly Instructions - Please keep for future reference

309/5256



Dimensions

Width - 120cm

Depth - 49.5cm

Height - 37.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 25kgs. Please lift with care.

- Check you have all the components and tools listed on pages 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** If there is any chance of this unit being pulled over by children etc. it is recommended that the unit is secured to a wall using suitable fixings (not supplied).

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.


- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below


Please check you have all the panels listed below



1 Left Side (D1773B)
(350 x 419mm)




2 Right Side (D1774B)
(350 x 419mm)




3 Divider (D1775B)
(255 x 417mm)



4 Fascia (D1781A)
(350 x 70mm) x 4




5 Top (D1772A)
(1200 x 495mm)




6 Horizontal (D1776A)
(499 x 415mm) x 2




7 Plinth (D1778A)
(1020 x 95mm)



8 Back (D1777A)
(499 x 146mm) x 2



9 Left Drawer Front (D1779A)
(504.5 x 160mm)



10 Right Drawer Front (D1780A)
(504.5 x 160mm)



11 Drawer Base (T462-347)
(462 x 347mm) x 2



12 Left Drawer Side (W370-95LH)
(370 x 95mm) x 2



13 Left Drawer Side (W370-95RH)
(370 x 95mm) x 2



14 Drawer Back (W451-124)
(451 x 124mm) x 2


















Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 08456 400800** quoting the reference numbers below

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 16</p>	<p>B </p> <p>Metal dowel (F901) x 32</p>	<p>C </p> <p>Large locking nut (F900) x 28</p>
<p>D </p> <p>Small locking nut (F3) x 4</p>	<p>E </p> <p>Knock-in Peg (F171) x 8</p>	<p>F </p> <p>Handle (F287) x 2</p>
<p>G </p> <p>19mm Screw (F461) x 4</p>	<p>H </p> <p>9mm Screw (F73) x 12</p>	<p>I </p> <p>13mm Screw (F63) x 12</p>
<p>J a  L Runner (F159) x 2</p> <p>J b  R Runner (F160) x 2</p> <p>J c  L Runner (F161) x 2</p> <p>J d  R Runner (F162) x 2</p>	<p>K </p> <p>Wedgefix (F639) x 4</p> <p>L </p> <p>Plastic Nail (F91) x 5</p>	

Tools required



Rule



Cross-head screwdriver



Scissors




Hammer



Eye protection (when using a hammer or drill)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the Customer Helpline: 08456 400800 quoting the reference numbers below

Step 1

Prepare the drawer fronts

Screw 2 metal dowels **B** into the holes shown on the back of the left drawer front **9** and the right drawer front **10**.

Note: Tighten the metal dowels up fully against the panels.




Note: The left drawer front **9** has a small identification hole.

Step 2

Prepare the drawer sides

Insert a small locking nut **D** into the hole shown on the left drawer side **12** and right drawer side **13**.

Note: Arrow on locking nut **must** point towards hole in edge of panel.




Step 3

Attach the drawer sides to the drawer front

Push the left drawer side **12** and right drawer side **13** onto the back of the drawer fronts **9** and **10**.

Turn the small locking nuts **D** on the left drawer side **12** and right drawer side **13**.

Note: Turn the locking nuts **D** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **11** down the grooves in the drawer sides **12** and **13** and down into the groove in the drawer front **9** and **10**.




Step 5

Fit the drawer back

Fit the drawer back **14** between the drawer sides **12** and **13**.

Make sure that the drawer base **11** fits into the groove in the drawer back **14**.


Hold the drawer back **14** in position and tap the knock-in pegs **E** through the holes in the drawer sides **12** and **13**.



Step 6

Attach the handles


Attach a handle **F** to each drawer front **9** and **10** using 2 screws **G**.



Step 7

Fit the wedgexes

Turn the 2 drawer assemblies over and slide 2 wedgexes **K** into the front and back grooves, as shown, and tighten up the screws.



Assembly Instructions


Step 8

Fit runners to the drawers

Turn the drawer assemblies over.

Fit the runner **Jc** to the bottom edge of the left drawer side **12**, as shown, making sure that it is pushed up against the back of the drawer front **9** and **10**. Use a bradawl to mark the fixing positions, then secure with 2 screws **I**.

Fit the runner **Jd** to the bottom edge of the right drawer side **13** using the same method.



Step 9


Prepare the 4 fascias

Check that the holes are in the same place as the diagrams, as each pair are prepared differently.

Screw 2 metal dowels **B** into each of the 4 fascias **4**.

Tap a wooden dowel **A** into each of the 4 fascias **4**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



Assembly Instructions

Step 10

Prepare the left side

a: Fit a runner **J a** to the left side **1**.

The 1st screw **H** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **H** use the holes that line up with the other panel holes.








b: Fit a screw **I** into the 2nd hole in at the top of the runner **J a**.

c: Insert 6 large locking nuts **C** into the left side **1**.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Tap a wooden dowel **A** into the left side **1**.

d: Screw 4 metal dowels **B** into the left side **1**.



Assembly Instructions

Step 11

Fit 2 fascia panels to the left side





a: Push the left side **1** down onto a fascia panel **4**.

b: Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the left side **1**.

Note: Turn the large locking nuts **C** as far as they will go - more than 1/2 a turn.

c: Push a fascia panel **4** down onto the left side **1**.

d: Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the left side **1**.



Assembly Instructions

Step 12

Prepare the right side

a: Fit a runner **Jb** to the right side **2**.

The 1st screw **H** uses the 1st hole in from the front of the runner.


The 2nd and 3rd screws **H** use the holes that line up with the other panel holes.

b: Fit a screw **I** into the 2nd hole in at the top of the runner **Jb**.


c: Insert 6 large locking nuts **C** into the right side **2**.

Tap a wooden dowel **A** into the right side **2**.



d: Screw 4 metal dowels **B** into the right side **2**.




a:




b:



c:



d:



Assembly Instructions

Step 13





Fit 2 fascia panels to the right side

a: Push the right side **2** down onto a fascia panel **4**.

b: Use a screwdriver to tighten the 2 large locking nuts **c** fitted to the right side **2**.

c: Push a fascia panel **4** down onto the right side **2**.

d: Use a screwdriver to tighten the 2 large locking nuts **c** fitted to the right side **2**.




Assembly Instructions

Step 14

Prepare the 2 horizontals

Insert 4 large locking nuts **C** into each of the 2 horizontals **6**.

Tap 2 wooden dowels **A** into each of the 2 horizontals **6**.




Step 15

Fit a horizontal onto the left side

Push a horizontal **6** onto the left side **1**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the horizontal **6**.




Step 16

Prepare the 2 backs

Insert 2 large locking nuts **C** into each of the 2 backs **8**.

Tap 2 wooden dowels **A** into each of the 2 backs **8**.



Assembly Instructions

Step 17

Prepare the divider

a: Fit a runner **J a** to the divider **3**.





The 1st screw **H** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **H** use the holes that line up with the other panel holes.

b: Fit a screw **I** into the 2nd hole in at the top of the runner **J a**.

Insert 2 large locking nuts **C** into the divider **3**.

Screw 3 metal dowels **B** into the divider **3**.



Turn the divider over

Turn the divider over





c: Fit a runner **J b** to the divider **3**.

The 1st screw **H** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **H** use the holes that line up with the other panel holes.

d: Fit a screw **I** into the 2nd hole in at the top of the runner **J b**.

Screw 3 metal dowels **B** into the divider **3**.




Assembly Instructions

Step 18

Fit a back

Push a back **8** onto the left side **1**.

Use a screwdriver to tighten the large locking nut **C** fitted to the back **8**.




Step 19

Fit the divider

Push the divider **3** onto the horizontal **6** and back **8**.

Use a screwdriver to tighten the 3 large locking nuts **C** fitted to the horizontal **6** and back **8**.




Step 20

Fit the other horizontal

Push the horizontal **6** onto the divider **3**.

Use a screwdriver to tighten the 2 large locking nuts **C** fitted to the horizontal **6**.




Assembly Instructions

Step 21

Prepare the plinth

Insert 2 large locking nuts **C** into the plinth **7**.

Tap 2 wooden dowels **A** into the plinth **7**.




Step 22

Fit the back

Push the other back **8** onto the divider **3**.

Use a screwdriver to tighten the large locking nut **C** fitted to the back **8**.




Step 23

Fit the plinth

Push the plinth **7** onto the left side **1**.

Use a screwdriver to tighten the large locking nut **C** fitted to the plinth **7**.




Assembly Instructions

Step 24

Fit the right side

Push the right side **2** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **C** fitted to the horizontal **6**, plinth **7** and back **8**.




Step 25

Fit the 5 plastic nails

Tap 2 plastic nails **L** into the bottom edge of each of the sides **1** and **2**.

The other plastic nail **L** taps into the the bottom edge of the plinth **7**.




Assembly Instructions

Step 26

Prepare the top

Screw 6 metal dowels **B** into the top **5**.




Step 27

Fit the top

Carefully stand the unit up for this step.

Push the top **5** down onto the assembly.

Use a screwdriver to tighten the 6 large locking nuts **C** fitted to the left side **1**, right side **2** and divider **3**.



Assembly Instructions

Step 28



Fit the drawers

Slide the wheels of the runners fitted to the drawers, over the wheels of the runners fitted to the side panels and push the drawers into position.

Assembly is complete



Warning: The unit is heavy. Lift with care.



Note: The left drawer front has a small identification hole. Please refer back to Step 1.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800** and quote the reference numbers on the component pages.

Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW

