


PEIO

habitat



Spare Parts

 www.argos-support.co.uk

 Help@ClickSpares.co.uk

 0370 112 1928

Customer Support

 0345 640 2020



Safety and Care Advice

Product Details


Peio cane 1Drw bedside 5643558 black

Peio cane 1Drw bedside 3296787 oak

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- This product has been constructed to be used in the domestic environment only and not for commercial purposes.

- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.
- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.
- Use a dry cloth to clean the product, furniture polish is not recommended.
- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightened properly.
- Maximum loading weight 20kg.
- This product is compliant EN14749, BS4875-7.
- Any additional or replacement parts are obtained from the manufacturer.

Fittings (Shown to scale)


Bag 1



Tools required




Phillips screwdriver
(small)



Phillips screwdriver
(small & medium)


Panels



1 Back Frame x 1
(356 x 95mm)




2 Back Panel x 1
(356 x 95mm)



3 Top Panel x 1
(356x 330mm)




6 Rail (356 x 45mm) x 1




7 Drawer Front x 1
(350 x 105mm)




10 Drawer Back x 1
(303 x 67mm)




4 Left Side Frame x 1
(530 x 360mm)



5 Right Side Frame x 1
(530 x 360mm)



8 Drawer Left Side x 1
(280 x 67mm)




9 Drawer Right Side x 1
(280 x 67mm)



11 Drawer Bottom Panel x 1
(314x 273mm)


1

B



Metal Dowel x14

F




Ø25mm Foot Pad x 4

D




30mm Wooden Dowel x 12




1

Peel off the back



F

2



F

1

2

3

6


7

A



Locking Nut x14

B




Metal Dowel x14

C



M6*25mm Bolt x 2

D



Ø8*30mm Wooden Dowel x 12

E



35mm Screw x 4

F



Ø25mm Foot Pad x 4

G



M4 Allen Key x 1

D


2

A



Locking Nut x2

C




M6*25mm Bolt x 1

G



M4 Allen Key x 1




3



A





Locking Nut x 3




4




5



6



7



Assembly is complete.