


# B100

## User Guide



Please keep the packing materials in case you later need to return or transport your B100.

Please keep your sales (till) receipt, which is your guarantee.

**LAST NUMBER REDIAL**  
press this to make a repeat call to the last number dialled

**RECALL button**  
you may need this if you are using your Trend LCD on a PBX or with BT's SelectServices

**SECURECY button**  
press and hold down this button to mute the mouth-piece (during a call so the person on the other end can't hear you)



## 1 Making and answering calls

### To make a call

- 1 Lift the handset and wait for Dial tone
- 2 Dial the telephone number using the keypad

### Last Number Redial

To make a repeat call to the last number you dialled (up to 32 digits):

- 1 Lift the handset and wait for Dial tone
- 2 Press LNR

### Secrecy

While you are on a call, to mute the mouthpiece so that your voice cannot be heard

- 1 Press and hold SEC

### Use on a PBX

If you are using your B100 on a PBX, and the PBX User Guide tells you to press RECALL, press the button on your B100 .

### To make a call:

- 1 Key In the outside line access digit then press LNR
- 2 Dial the telephone number

### Technical details

<b>Temperature range</b>	Operating 0°C to 40°C	
	Storage -20°C to 60°C	
<b>Approvals standards</b>	EN55022	EN55024
	EN60950	
	iCTR37	CTR38
<b>PBX compatibility</b>	Pause length: 3 seconds. Signalling type: DTMF (dual tone multifrequency), also called tone dialling.	

### Binatone Helpline (for UK only)

Monday to Friday from 8.00am to 8:00pm  
Saturday from 8.30am to 2.00pm  
Tel: 0844 557 9677

Calls cost up to 5p per minute from a BT landline, but other providers and mobile operators may charge more.  
Or visit our website:

[www.binatoneglobal.com](http://www.binatoneglobal.com)

## 2 Troubleshooting

**!** The B100 must be serviced by trained engineers. NEVER attempt any repairs or adjustments yourself - you could invalidate the Guarantee.

*If the phone does not ring ...*

Make sure your B100 is fully plugged into the telephone line socket.

Check that the total REN value of all equipment connected to your telephone line is no more than 4. Disconnect one or more telephones and see whether that helps.

*If you cannot make Calls ...*

Make sure your B100 is fully plugged into the telephone line socket.

Disconnect all other instruments connected to the same line as the B100 and see whether you can make a call.

Disconnect the B100 from the telephone line and plug a different phone into the socket. Try making a call. If this works, the line is OK.

If you are using a two-way socket adapter, remove it and plug a telephone directly into the socket. If the call now works, the adapter may be faulty.

If you think the fault may be on the exchange line, contact the service provider

BINATONE TELECOM PLC  
1 Apsley Way London NW2 7HF United Kingdom  
Tel: +44(0) 20 955 2700 Fax: +44(0) 20 9344 9877  
e-mail: binatoneuk@binatoneglobal.com

# Binatone

### EC Declaration of Conformity

We the manufacturer / Importer : Binatone Telecom Plc  
1 Apsley Way London  
NW2 7HF, United Kingdom.

Declare under our sole responsibility that the following product

Type of equipment: Corded phone  
Model Name: B100

Country of Origin: China  
Brand: Value

complies with the essential protection requirements of R&TTE Directive 1999/5/EC on the approximation of the laws of the Member States relating to **Radio Spectrum Matters**, the Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to **electromagnetic compatibility (EMC)** and the European Community Directive 2006/95/EC relating to **Electrical Safety**.  
Assessment of compliance of the product with the requirements relating to the essential requirements according to Article 3 R&TTE was based on Annex III of the Directive 1999/5/EC and the following standard:

Radio Spectrum: EN 55022:2010  
EMC: EN 55024:2010

Electrical Safety: EN 60950-1:2006+A11:2009+A12:2011

The product is labelled with the European Approval Marking CE as show. Any Unauthorized modification of the product voids this Declaration.



Manufacturer / Importer  
(signature of authorized person)

Signature: (K.H. Mueller, C70)

London,

Signature:

Place & Date: 05- May, 2015

### 3

## Guarantee and service

This product is guaranteed against manufacturing defects for a period of 1 Year.

This does not cover the product where the fault is due to misuse, abuse, use in contravention of the instructions, or where the product has been the subject of unauthorised modifications or alterations, or has been the subject of commercial use.

In the event of a problem with the product within the guarantee period please return it to your nearest Argos store.

If the item is shown to have had an inherent defect present at the time of sale, the store will provide you with a replacement.

Your statutory rights remain unaffected.

Guarantor; Argos Ltd  
489 - 499 Avebury Boulevard  
Central Milton Keynes  
MK9 2NW

### Connection and conditions for use

You can connect your B100 to public networks in the UK; or to an approved PBX using DTMF signalling.

Each item of telephone equipment (phones, fax machines etc.) has a ringer equivalence numbers (REN). The RENs of all equipment connected to an exchange line **must not add up to more than 4** otherwise, one or more phones may not ring and/or answer calls correctly.

B100 has a REN of 1, and most other telephones have a REN of 1 unless marked otherwise.

### Care of your B100

- Do not clean your B100 with solvent chemicals abrasives or spray cleaners which might get inside the case and cause damage not covered by the Guarantee. When necessary, clean it with a damp cloth.
- Keep your B100 away from hot, humid conditions or strong sunlight.
- Every effort has been made to ensure high standards of reliability for your B100. However, if something does go wrong, please do not try to repair it yourself - consult your supplier or the Binatone Help Line.

### Electrical safety

- DO NOT** install the Trend 1 near a sink, bath or shower or anywhere it could get wet. Electrical equipment can cause serious injury used while you are wet or standing in water.
- If the unit ever falls into water, **DO NOT** retrieve it until you have unplugged the telephone line plug from the telephone socket; then pull it out by the unplugged cable.


DI Argos Ver 3.0 Nov-09

## Wallmounting instructions

Please read the instructions on this template carefully before you start to wall mount your telephone. If you prefer, you can stand your telephone on a level surface

**BE CAREFUL** - check that there are no electrical wires hidden in the wall.

- Use this template for wallmounting, marking the wall at the fixing centres. The marks should be **83 mm** apart
- Using screws (not supply with the unit) screw in at the two marked locations, leaving approx. 7mm (1/4") between the wall and underside of screw head.
- Tuck the telephone line cord into the grooves on the cradle. Make sure that the parking hook lever is pushed to the top position.
- Hang the cradle unit on the screws using the wallmounting slots on the underside of the unit. You may need to remove the telephone from the wall and tighten the screws so that the cradle is securely fixed and does not wobble.
- Rest the handset on the cradle using the parking hook on the cradle and the parking recess under the earpiece on the handset



### Binatone Helpline (for UK only)

Monday to Friday from 8.00am to 8:00pm

Saturday from 8.30am to 2.00pm

Tel: **0844 557 9677**


Calls cost up to 5p per minute from a BT landline, but other providers and mobile operators may charge more.

Or visit our website:

[www.binatoneglobal.com](http://www.binatoneglobal.com)

### Reset the hook on the cradle.

This hook is designed to keep the handset in place when the telephone is vertical on the wall. The hook on the upper part of the cradle is there to support the handset if you need to leave the phone temporarily during a call.



Help Line: **0844 557 9677**