


# Kensington - 3 Drawer 2 Door Robe

Assembly Instructions - Please keep for future reference

414/6946

4111335



## Dimensions

Width - 85.9cm

Depth - 49.5cm

Height - 198.8cm



**MADE IN  
BRITAIN**

**Important** - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



# Safety and Care Advice

**Important - Please read these instructions fully before starting assembly**

- **Warning:** This unit weighs approximately 59kgs. Please lift with care.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Parts of the assembly will be easier with 2 people.

- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.
- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Tools required

Scissors / Rule / Hammer / Cross-head screwdriver / Square / Spirit level / Step ladder

Eye protection (when using a hammer or drill) / Electric drill (only use when drilling into walls)


## Components - Panels

If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


**Please check you have all the panels listed below**



**1** Drawer Front (DF2414)  
(79.1 x 19.2cm) x 3



**2** Left Drawer Side (W370-124LH)  
(37 x 12.4cm) x 3



**3** Right Drawer Side (W370-124RH)  
(37 x 12.4cm) x 3



**4** Drawer Back (W765-124)  
(76.5 x 12.4cm) x 3



**5** Drawer Base (T776-367)  
(77.6 x 36.7cm) x 3


# Components - Panels

If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020


Please check you have all the panels listed below




**6** Left Side (DF2410)  
(197.3 x 47.5cm)



**7** Right Side (DF2411)  
(197.3 x 47.5cm)



**8** Top (DF2409)  
(85.9 x 49.5cm)



**9** Shelf (DF2413)  
(79.7 x 47.4cm)



**10** Hanging Rail (FHR791)  
(79.1cm long)




**13** Side Plinth (DF2431)  
(47.5 x 9.1cm) x 2




**11** Rail (DF2412)  
(79.7 x 8.9cm) x 5




**12** Front Plinth (DF2417)  
(85.9 x 9.2cm)



**14** Left Door (DF3874)  
(120.6 x 39.4cm)



**15** Right Door (DF3780)  
(120.6 x 39.4cm)



**16** Back (X1914-823)  
(191.4 x 82.3cm)



# Components - Fittings






If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p><b>A</b> </p> <p>Metal dowel (F901) x 26</p>	<p><b>B</b> </p> <p>Large locking nut (F900) x 20</p>	<p><b>C</b> </p> <p>Small locking nut (F3) x 6</p>
<p><b>D</b> </p> <p>Wooden dowel (F22) x 20</p>	<p><b>E</b> </p> <p>Nail (F51) x 34</p>	<p><b>F</b> </p> <p>Knock-in Peg (F171GY) x 12</p>
<p><b>G</b> </p> <p>25mm Screw (F50) x 6</p>	<p><b>H</b> </p> <p>19mm Screw (F461) x 8</p>	<p><b>I</b> </p> <p>9mm Screw (F74) x 6</p>
<p><b>J</b> </p> <p>9mm Screw (F73) x 12</p>	<p><b>K</b> </p> <p>13mm Screw (F63) x 16</p>	<p><b>L</b> </p> <p>Plastic Nail (F91) x 4</p>
<p><b>M</b> </p> <p>Drawer runner (F1004) x 6</p>		<p><b>N</b> </p> <p>Wedgex (F639) x 12</p>
<p><b>O</b> </p> <p>Rail Holder (F891) x 2</p>	<p><b>P</b> </p> <p>Hinge plate (F523) x 6</p>	<p><b>Q</b> </p> <p>Hinge (F522) x 6</p>
<p><b>R</b> </p> <p>Handle (F220) x 8</p>	<p><b>S</b> </p> <p>Shelf stud (F110) x 2</p>	<p><b>T</b> </p> <p>Strap</p> <p> Screw  Washer x 2</p> <p>Overbalance protector kit (F269) x 1</p>

Ruler - Use this ruler to help correctly identify the screws




# Assembly Instructions

## Step 1

### Prepare the 3 drawer fronts

Screw 2 metal dowels **A** into each of the 3 drawer fronts **1**.

**Note:** Tighten the metal dowels up fully against the panels.




## Step 2

### Prepare the drawer sides

Insert a small locking nut **C** into the hole shown on the left drawer side **2** and the right drawer side **3**.

**Note:** The arrow on the locking nut **must** point towards the hole in the edge of the panel.




## Step 3

### Attach the drawer sides to the drawer fronts

Push the left drawer sides **2** and right drawer sides **3** onto the back of the drawer fronts **1**.

Turn the small locking nuts **C** on the left drawer side **2** and right drawer side **3**.

**Note:** Turn the locking nuts **C** clockwise to secure panels - more than 1/2 a turn.




# Assembly Instructions

## Step 4

### Fit the drawer base

Slide the drawer base **5** down the grooves in the drawer sides **2** and **3** and down into the groove in the drawer front **1**.




## Step 5

### Fit the drawer back

Fit the drawer back **4** between the drawer sides **2** and **3**. Make sure that the drawer base **5** fits into the groove in the drawer back **4**.


Hold the drawer back **4** in position and tap the knock-in pegs **F** through the holes in the drawer sides **2** and **3**.



## Step 6

### Attach the handles


Attach 2 handles **R** to each drawer front **1** using screws **H**.



## Step 7

### Fit the wedgifixes

Turn the drawer assemblies over and slide 4 wedgifixes **N** into the front and back grooves, as shown, and tighten up the screws.



# Assembly Instructions

## Step 8

### Prepare the left side

**a:** Place 3 runners **M** on the left side **6** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

Fit 3 hinge plates **P** onto the left side **6**, making sure that the slot is facing towards the finished front edge.

**b:** Slide the runners **M** back the other way and fit the 2nd screw **J** into the corresponding holes in the left side **6**.





Insert 2 large locking nuts **B** into the left side **6**.

**Note:** The arrow on the locking nuts **must** point towards the hole in the edge of the panel.

Tap 2 wooden dowels **D** into the left side **6**.

**c:** Screw 7 metal dowels **A** into the left side **6**.

To fit the rail holder **O** screw through the top hole with screw **K** and into the mark hole drilled in the left side **6**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **K** using the lower hole.



# Assembly Instructions

## Step 9

### Prepare the right side

**a:** Place 3 runners **M** on the right side **7** as shown. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.

Fit 3 hinge plates **P** onto the right side **7**, making sure that the slot is facing towards the finished front edge.





**b:** Slide the runners **M** back the other way and fit the 2nd screw **J** into the corresponding holes in the right side **7**.

Insert 2 large locking nuts **B** into the right side **7**.

Tap 2 wooden dowels **D** into the right side **7**.

**c:** Screw 7 metal dowels **A** into the right side **7**.

To fit the rail holder **O** screw through the top hole with screw **K** and into the mark hole drilled in the right side **7**. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **K** using the lower hole.




# Assembly Instructions

## Step 10

### Prepare the shelf

Insert 4 large locking nuts **B** into the shelf **9**.

Tap 4 wooden dowels **D** into the shelf **9**.




## Step 11

### Fit the shelf to the right side

Push the shelf **9** onto the right side **7**.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the shelf **9**.

**Note:** Turn the large locking nuts **B** as far as they will go - more than 1/2 a turn.




## Step 12

### Prepare the 5 rails

Insert 2 large locking nuts **B** into each of the 5 rails **11**.

Tap 2 wooden dowels **D** into each of the 5 rails **11**.




# Assembly Instructions

## Step 13

### Fit the 5 rails

Push the 5 rails **11** onto the right side **7**.

Use a screwdriver to tighten the large locking nut **B** fitted to each of the 5 rails **11**.




## Step 14

### Fit the left side

Push the left side **6** onto the assembly.

Use a screwdriver to tighten the 2 large locking nuts **B** fitted to the shelf **9** and the 5 rails **11**.




# Assembly Instructions

## Step 15

### Prepare the top

Screw 4 metal dowels **A** into the top **8**.



## Step 16

### Fit the top


**Note:** To make it easier to fit the top and plinths, place polystyrene blocks from the packaging underneath the side panels to raise the assembly.

Push the top **8** onto the assembly.

Use a screwdriver to tighten the 4 large locking nuts **B** fitted to the sides **6** and **7**.




**Warning:** The unit is heavy. Lift with care.



## Step 17

### Secure the top rail to the top

Screw through the 2 holes in the top **11** and into the top rail **8** using 2 screws **G**.



# Assembly Instructions

## Step 18

### Fit the back


**a:** Square up the unit by making sure that measurement **x** to **x** equals **y** to **y**.

**b:** Place the back **16** onto the unit.

Nail **E** around the outside edges of the back **16**.

**Note:** Nails should be spaced about 150mm apart.


**a:** The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



## Step 19

### Fit the 4 plastic nails

Tap 4 plastic nails **L** into the bottom edge of each of the sides **6** and **7**.




# Assembly Instructions

## Step 20

### Prepare a side plinth

Insert a large locking nut **B** into 1 of the side plinths **13**.

Tap a wooden dowel **D** into the side plinth **13**.




## Step 21

### Prepare the other side plinth

Insert a large locking nut **B** into the side plinth **13**.


Tap a wooden dowel **D** into the side plinth **13**.



## Step 22

### Prepare the front plinth

Screw 2 metal dowels **A** into the front plinth **12**.




## Step 23

### Fit the plinths together

Push the 2 side plinths **13** onto the front plinth **12**.

Use a screwdriver to tighten the large locking nuts **B** fitted to the side plinths **13**.



# Assembly Instructions

## Step 24

### Fit the plinths


Position the 3 plinths around the outside of the assembly, ensuring that the bottom edge of the plinths are flush with the bottom edge of the sides, as shown.

Secure the 2 side plinths **13** through the left end **6** and right end **7** using screws **G**.

**Carefully stand the unit up for the next step.**



**Warning:** The unit is heavy. Lift with care.





## Step 25

### Fit the drawers

Starting with the bottom drawer, slide both the runners **M** forward and locate the drawer sides **2** and **3** between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners **M**.

Working from the inside of the drawer, insert 2 screws **I** through the drawer sides and out into the 2nd threaded hole in the runner.

**Note:** Do not overtighten the screws **I**. If they catch on the runner you may need to loosen them slightly.




# Assembly Instructions

## Step 26

### Fit the hanging rail and shelf studs

Push the hanging rail **10** into the rail holders **O** fitted to the side panels.

Push the 2 shelf studs **S** down into the holes in the shelf **9** to act as door buffers.




## Step 27

### Prepare the 2 doors

Push fit 3 hinges **Q** into each of the 2 doors **14** and **15**.

Secure each hinge with 2 screws **K**.

**Note:** Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



# Assembly Instructions

## Step 28

### Fit doors and handles

**Note:** The easiest way to attach each door **14** and **15** is to fit the top hinge first, then align and fit the other hinges.



**a:** Push the hinge **Q** onto the front part of the hinge plate **P**. The recess at the bottom of screw B goes into the slot in the hinge plate.

**b:** Keep the hinge **Q** FLAT against the hinge plate **P** as you slide it across as far as it will go. Tighten screw A.

**c:** The hinge **Q** must be flat against the hinge plate **P** prior to any adjustment.

**d:** The hinge **Q** must NOT be AT AN ANGLE to the hinge plate **P** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

**e:** Attach a handle **R** to each door **14** and **15** using screws **H**.



# Assembly Instructions

## Step 29

### Adjust the doors if needed

**a:** Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

### **b:** Height adjustment.


Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

### **c:** Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.

### **d:** Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



# Assembly Instructions

## Step 30


### Fit the overbalance protector

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by fitting of the overbalance protector kit **T** to the unit, or an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

**Note:** Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

**Assembly is complete**



If you need help or have damaged or missing parts, please visit [www.argos-support.co.uk](http://www.argos-support.co.uk) or email: [Help@ClickSpares.co.uk](mailto:Help@ClickSpares.co.uk) (quoting your original order number)  
Alternatively, call the Spares Helpline on: 0370 112 1928.  
For any other queries please contact the Customer Helpline on: 0345 640 2020



