


# SAN DIEGO - Bookcase

**Assembly Instructions** - Please keep for future reference

414/9376



## Dimensions

Width - 90cm

Depth - 35cm

Height - 180cm

**Important – Please read these instructions fully before starting assembly**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**




# Safety and Care Advice

**Important** – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

- This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.
- The product has been treated with a wax and oil finish to prevent dirt ingress and preserve moisture.
- On unpacking the furniture you may notice an odour due to this treatment; this will disappear once the furniture is unpacked and assembled after a period of time.
- This process may leave some staining on the packaging material; please take care to ensure this does not transfer to clothing or carpeted surfaces during assembly.



- We do not recommend the use of power drill/drivers **for inserting screws**,

as this could damage the unit. Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.

## Care and maintenance

- Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.
- Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.


- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


**Note:** If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

# Components - Panels

Please check you have all the panels listed below



**1** Right side panel (177.2 x 32cm)




**2** Left side panel (177.2 x 32cm)



**3** Back panel x 2 (173 x 41cm)



**4** Right front frame (177.2 x 6.5cm)



**5** Left front frame (177.2 x 6.5cm)



**6** H profile (165 x 2cm)



**12** Larger drawer front (71 x 15cm)



**13** Larger drawer back (68.6 x 14cm)




**14** Cross rail (81 x 6.5cm)



**15** Front frame x 5 (75.6 x 6.5cm)



**16** Middle front frame x 2 (75.6 x 6.5cm)



**17** Smaller drawer front x 2 (32 x 15cm)



**18** Smaller drawer back x 2 (29.6 x 14cm)




**19** Smaller drawer bottom x 2 (30.6 x 24.6cm)



**20** Drawer sides x 6 (26 x 14cm)



**21** Middle drawer runner (28 x 8.1cm)



**22** Side drawer runner x 4 (30 x 5.5cm)



**23** Side plinth x 2 (32.8 x 9.2cm)




**24** Vertical frame (19.8 x 6.5cm)




**25** Back column (14.2 x 6.5cm)



**26** Block x 7 (10 x 2cm)



**7** Top panel (90 x 33.8cm)



**8** Base panel x 2 (81 x 30cm)



**9** Shelf x 2 (81 x 30cm)



**10** Larger drawer bottom (69.6 x 24.6cm)







**11** Front plinth (88.6 x 9.2cm)

# Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**

Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

|   |  |   |
|---|--|---|
| <b>A</b> <br>Wooden dowel x 44 | <b>B</b> <br>14mm Screw x 3   | <b>C</b> <br>30mm Screw x 32   |
| <b>D</b> <br>35mm Screw x 33   | <b>E</b> <br>50mm Screw x 12 | <b>F</b> <br>16mm Bolt x 8     |
| <b>G</b> <br>Metal dowel x 8   | <b>H</b> <br>Locking nut x 8  | <b>I</b> <br>Drawer handle x 4 |
| <b>J</b> <br>Nail x 46         | <b>K</b> <br>Washer x 2       | <b>L</b> <br>Wall strap x 1    |

## Tools required




Phillips screwdriver  
(small & medium)



Ruler/tape  
measure



Small  
hammer



Eye protection  
(when using a  
hammer or glue)

**Ruler** - Use this ruler to help correctly identify the screws




# Assembly Instructions

## Step 1

**Fixing right front frame to the right side panel**  
(Two people required for an easier assembly).


**a:** Insert right side panel **1** into right front frame **4** through joints.



**Note:** Before fixing blocks **26** into place it is important to ensure that the slot and groove of parts **1** and **4** are fully pushed together and lined up correctly at the top and bottom.

**b:** Place blocks **26** between the two marks as shown. First fix to the side panel using screws **D**.


**c:** Fix front frame through blocks **26** using screws **D**.



## Step 2

**Fixing left front frame to the left side panel**  
(Two people required for an easier assembly).


**a:** Insert left side panel **2** into left front frame **5** through joints.



**Note:** Before fixing blocks **26** into place it is important to ensure that the slot and groove of parts **2** and **5** are fully pushed together and lined up correctly at the top and bottom.

**b:** Place blocks **26** between the two marks as shown. First fix to the side panel using screws **D**.

**c:** Fix front frame through blocks **26** using screws **D**.



# Assembly Instructions

## Step 3


### Fitting Metal dowels.

Screw metal dowels **G** into right side panel **1** and left side panel **2**.




**Note:** Insert metal dowels as far as shown.

Do not over tighten.



## Step 4

Insert dowels **A** into the indicated parts.




# Assembly Instructions

## Step 5

### Assembling parts.


Put parts **16** and **24** together as shown in the diagram.



## Step 6


### Assembling the cabinet.

Insert assembled frame and front frames **15** into holes on right side panel **1**, as shown.



## Step 7

Fit cross rail **14** to the right side panel **1** then fix it using screw **D**.



# Assembly Instructions

## Step 8

### Inserting base panels and shelves.


With help, fit base panels **8** and shelves **9** to right side panel **1**.

**Attention!** Round edges on base panels and shelves must be facing front.

Insert 4 locking nuts **H** into base panels **8** where shown.

Use a screwdriver to turn locking nuts **H** clockwise to lock.

**Do not over tighten.**



## Step 9

### Fixing left side panel.


With help, place left side panel **2** properly ensuring dowels and front frames are all fit into their holes at the same time.

Insert 4 locking nuts **H** into base panels where shown.

Use a screwdriver to turn locking nuts **H** clockwise to lock.

**Do not over tighten.**


Fix cross rail **14** to the left side panel **2** using screw **D**.



# Assembly Instructions


## Step 10

Fix bottom front frame to the right and left front frames using screws **B** as shown in the diagram.



## Step 11

Attach middle drawer runner **21** to back column **25** using screw **D**.




## Step 12

**Fixing middle drawer runner.**

**a:** Fit middle drawer runner **21** in vertical frame and back column **25** in base panel.

**b:** Attach middle drawer runner and back column using screws **D**.




# Assembly Instructions

## Step 13

### Fixing side drawer runner.

Fit side drawer runners **22** to the side panels, then fix them using screws **E** as shown.


With help, carefully turn the product with its front facing up.



## Step 14

### Fixing top panel.

With help, fit top panel **7** to the cabinet then fix it using screws **E**.



# Assembly Instructions


## Step 15

**a:** Fix side plinths **23** to the side panels using screws **C**.

 **Note:** Make sure side plinths are aligned to the bottom and front edges of the side panels.

**b:** Fix front plinth **11** to the front frames **4** and **5** using screws **C**.


 **Note:** Make sure front plinth **11** is aligned to the bottom edge of the side panels and in line to the side plinths.



## Step 16

Fix block **26** to the front plinth and front frame using screws **D**.

 **Important!** After fixing the block, with help, carefully stand the product upright.



# Assembly Instructions

## Step 17

### Fixing back panels.






**Important:**

Cabinet **MUST** be 'square' when back panels are attached. Make sure back panels are in flush with the edge of the top panel prior to fixing.

**a:** Attach back panel **3** to the right side first using nails **J**.

**b:** Position profile **6** onto back panel (just attach).

**c:** Carefully slot the second back panel **3** into the profile and fix it to the cabinet using nails **J**.



# Assembly Instructions

## Step 18

### Smaller drawer assembly.



**a:** Attach drawer sides **20** to the drawer front **17** using screws **C**.

**b:** Slide drawer bottom **19** into slots on drawer sides and position drawer back **18** in place.

**c:** Holding the drawer back **18**, press the drawer sides and fix them using screws **C**.

**d:** Using bolts **F** attach drawer handle **I** to drawer front.

Repeat step 18 for the other drawer.



## Step 19



### Larger drawer assembly.

**a:** Attach drawer sides **20** to the drawer front **12** using screws **C**.

**b:** Slide drawer bottom **10** into slots on drawer sides and position drawer back **13** in place.

**c:** Holding the drawer back **13**, press the drawer sides and fix them using screws **C**.


**d:** Using bolts **F** attach drawer handles **I** to drawer front.



# Assembly Instructions

## Step 20

Insert drawers into unit. With the back of the drawers past the front frames, use a hammer to tap dowels **A** in flush to drawer sides. This is a safety catch to stop drawer falling out.





## Step 21

### Fixing to wall.

Furniture must be fixed to a wall. Fix wall strap **L** to top of furniture using washer **K** and screw **B**. With help, move furniture into position.

**Note:** Wall plugs not supplied. The correct type of fixing must be used for your wall, seek professional advice if in doubt.



**Assembly is complete.**

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400 800**

# A Guide to - Wall Mounting & Fixings

## Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



**Important:** When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


## Hints:

- 1: **General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** Always check the fitting and location to ensure your safety in and around the home.

**Fitting:** From time to time check the fitting to ensure the wall plugs or screws do not become loose.