

MISFIT RAY™

FITNESS + SLEEP MONITOR




ALWAYS ON

Ray Is Designed To
Be Always On You.


MISFIT RAY USER GUIDE

Misfit Move (Activity Reminder)


Subtle vibrations throughout the day encourage you to move more.




- 1 Launch the Misfit App.
Tap on "Devices."



- 2 On the Devices screen,
scroll down and tap
"Misfit Move."



- 3 Set the frequency and time
frame for your activity
reminders.




Misfit Move


If you haven't been
moving much, Ray will
blink red and vibrate.

Gentle Wake Up Alarm

The vibrating alarm in Ray silently wakes you at the right time.




- 1 Launch the Misfit App.
Tap on "Devices."



- 2 On the Devices screen, scroll
down and tap "Alarm."



- 3 Add an alarm for the time
you want to wake up.




Wake Up Alarm


When it's time to wake
up, Ray will blink purple
and vibrate.

Call and Text Notifications

Vibration alerts notify you of incoming calls and texts (Ray needs to be within wireless range of your phone)



- 1 Launch the Misfit App. Tap on "Devices."



- 2 On the Devices screen, scroll down and enable "Call and Text Notifications."



Call Notifications

If you're getting a phone call on your mobile device, Ray will blink green and vibrate.




Text Notifications

If you're getting a text message on your mobile device, Ray will blink light blue and vibrate.


Activity Goal Progress

Double-tap Ray to see your activity progress



Do More With The Misfit Link App


Use the Misfit Link App to make your Ray into a smart button



- 1 Launch the Misfit Link App. Find and sync your Ray. Select your device.



- 2 Tap the "+" to add a smart button feature to the triple tap motion.



- 3 Tap "LINK" to assign the smart button feature you want when you triple tap Ray. To remove the feature tap "UNLINK."



Triple Tap

Tap Ray quickly 3 times to activate the smart button feature.