

Malibu - 3 Drawer 2+2 Door Robe

Assembly Instructions - Please keep for future reference


563/6307

553/4038

544/3985

563/7038

544/3930



More help is available throughout this booklet by scanning
in the QR codes or typing in the links

Dimensions

Width - 145.9cm

Depth - 49.8cm

Height - 180.5cm



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk
or email: Help@ClickSpares.co.uk (quoting your original order number)


Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 102kgs. Please lift with care.
 - Check you have all the components and tools listed on pages 2, 3, 4 and 5.
 - Remove all fittings from the plastic bags and separate them into their groups.
 - Keep children and animals away from the work area, small parts could choke if swallowed.
 - Parts of the assembly will be easier with 2 people.
 - Make sure you have enough space to layout the parts before starting.
 - Do not stand or put weight on the product, this could cause damage.
 - Assemble the item as close to its final position (in the same room) as possible.
 - Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).
- 
 - We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- **Safety note:** To prevent possible overbalancing this unit **must be secured** to a wall using the 2 overbalance protector kits supplied or, an alternative fixing method of your choice.
 - Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

When applicable, remove any protective film from the panels before they are used

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the panels listed below

When applicable, remove any protective film before use



1 Drawer Front (DF5996)
(70.8 x 15.7cm) x 3




2 Left Drawer Side (WB450-130LH)
(45 x 13cm) x 3




3 Right Drawer Side (WB450-130RH)
(45 x 13cm) x 3



4 Drawer Back (W665-130)
(66.5 x 13cm) x 3




5 Drawer Base (T676-447)
(67.6 x 44.7cm) x 3




6 Top (DF7369)
(145.9 x 49.8cm)




7 Base (DF7370)
(142.5 x 49.4cm)




8 Left Side (DF7367)
(179 x 49.6cm)



9 Right Side (DF7368)
(179 x 49.6cm)



10 Left Divider (DF7373)
(168.25 x 47.4cm)



11 Right Divider (DF7374)
(168.25 x 47.4cm)



Components - Panels

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.

For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the panels listed below

When applicable, remove any protective film before use




12 Plinth (DF7375)
(142.5 x 9.2cm) x 2



13 Cross Rail (DF5858)
(71.4 x 6cm)



14 Back Rail (DF7376)
(34.05 x 9.2cm) x 2



15 Narrow Shelf (DF7372)
(34.05 x 47.2cm) x 2



16 Horizontal (DF5862)
(71.4 x 47.2cm) x 2



17 Top Rail (DF7356)
(34.05 x 6cm) x 2




18 Left Door (DF6012)
(119.6 x 35.25cm)




19 Right Door (DF6013)
(119.6 x 35.25cm)



20 Large Door (DF7377)
(167.6 x 35.25cm) x 2



21 Small Back (X1709-360)
(170.9 x 36cm) x 2



22 Large Back (X1709-727)
(170.9 x 72.7cm)



23 Long Hanging Rail (FHR708)
(70.8cm long)



24 Short Hanging Rail (FHR334)
(33.4cm long) x 2



Components - Fittings







If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0370 112 1928.
















For any other queries please contact the Customer Helpline on: 0345 640 2020

Please check you have all the fittings listed below


Drawer Fittings Bag marked 'drw kit'

A  Quickfit dowel (F545) x 6	B  Large locking cam nut (F607) x 6	C  Knock-in Peg (F171GY) x 12
D  19mm Screw (F461) x 6	E  15mm Screw (F284) x 6	F  13mm Screw (F63) x 12

Main Fittings Bag

A  Quickfit dowel (F545) x 28	B  Large locking cam nut (F607) x 36	D  19mm Screw (F461) x 4
F  13mm Screw (F63) x 18	G  9mm Screw (F73) x 18	H  40mm Screw (F910) x 4
I  Nail (F51) x 44	J  Plastic Nail (F91) x 6	K  Rail Holder (F891) x 6
L  Door Buffer (F137) x 6	M  Wooden dowel (F22) x 48	N  Large wooden dowel (F40) x 10
O  Double metal dowel (F566) x 4	P  Nail screw (F277) x 12	Q  Back holder (F276) x 12

Ruler - Use this ruler to help correctly identify the screws



Components - Fittings


Individual Fittings Bags

R




Overbalance protector
kit (F474) x 2

S



Handle (F418) x 10

T




Pre-mounted
hinge (F419) x 12

U



Drawer Brace (F427) x 3

Va



CL Runner (F608) x 3

Vb




CR Runner (F609) x 3

Vc




DL Runner (F610) x 3

Vd




DR Runner (F611) x 3

Tools required




Rule



Spirit
level



Eye protection
(when using a
hammer or drill)



Cross-head
screwdriver




Square



Scissors




Hammer



Bradawl



Electric drill
(only use
when drilling
into walls)



Step
ladder

Assembly Instructions

Step 1

Prepare the drawer sides

a: Insert a large locking cam nut **B** into the left drawer sides **2** and the right drawer sides **3**.

Note: The arrow on the locking cam nut **must** point towards the hole in the end of the panel.

b: Push 1 of the quickfit dowels **A** as far as it will go into the left drawer sides **2** and the right drawer sides **3**.


Note: Only the plastic thread of the quickfit dowel sticks out from the panel.

Use the Drawer Fittings Bag marked 'drw kit' for Steps 1 - 7



Standard Drawer Box Assembly

<https://www.youtube.com/watch?v=HclfJdkm-Lg>




Step 2

Fit the drawer sides to the 3 drawer fronts

Push the left drawer sides **2** and right drawer sides **3** down onto the back of the 3 drawer fronts **1**.

Turn the large locking cam nuts **B** clockwise as far as they will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.




Assembly Instructions

Step 3

Fit the drawer bases

Slide a drawer base **5** down the grooves in the drawer sides **2** and **3** and down into the groove in the drawer front **1**.




Step 4

Fit the drawer backs

Fit a drawer back **4** between the drawer sides **2** and **3**.

Make sure that the drawer base **5** fits into the groove in the drawer back **4**.


Hold the drawer back **4** in position and tap the knock-in pegs **C** through the holes in the drawer sides **2** and **3**.



Step 5

Fit the handles

Attach 2 handles **S** to each drawer front **1** using screws **D**.




Assembly Instructions

Step 6

Fit the drawer braces

Turn the 3 drawer assemblies over and hook a drawer brace **U** onto the bottom edge of the drawer back **4**.

Fix it to the drawer front **1** and drawer back **4** using 2 screws **E**.



Step 7

Fit runners to the drawers

Fit the DL runner **Vc** to the bottom edge of the left drawer side **2**, as shown, making sure that it is pushed up against the back of the drawer front **1**. Use a bradawl to mark the fixing positions, then secure with 2 screws **F**.


Fit the DR runner **Vd** to the bottom edge of the right drawer side **3** using the same method.



Fixing Bottom Mounted Runners

<https://www.youtube.com/watch?v=Z6lGMMy19h7Q>

Runners must be pushed up against the drawer front



Assembly Instructions

Step 8

Use the Main Fittings Bag for Steps 8 - end

Prepare the left divider

a: Fit 3 CL runners **Va** to the left divider **10**.

The 1st screw **G** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **G** use the holes that line up with the other panel holes.

b: Fit a screw **F** into the hole at the top of the runner **Va**.

Fit a rail holder **K** to the left divider **10** through the top hole with screw **F** and into the mark hole drilled in the left divider. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

c: Insert 2 large locking cam nuts **B** into the left divider **10**.

Push 2 of the quickfit dowels **A** as far as they will go into the left divider **10**.







Tap 6 wooden dowels **M** into the left divider **10**.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.



Fixing Bottom Mounted Runners

<https://www.youtube.com/watch?v=Z6lGMy19h7Q>



Assembly Instructions

Step 9

Prepare the right divider

a: Fit 3 CR runners **Vb** to the right divider **11**.

The 1st screw **G** uses the 1st hole in from the front of the runner.

The 2nd and 3rd screws **G** use the holes that line up with the other panel holes.







b: Fit a screw **F** into the hole at the top of the runner **Vb**.

Fit a rail holder **K** to the right divider **11** through the top hole with screw **F** and into the mark hole drilled in the right divider. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

c: Insert 2 large locking cam nuts **B** into the right divider **11**.

Push 2 of the quickfit dowels **A** as far as they will go into the right divider **11**.

Tap 6 wooden dowels **M** into the right divider **11**.



Assembly Instructions

Step 10


Prepare the other surface of the dividers

Turn the left divider and right divider over

Fit a rail holder **K** to the left divider **10** and the right divider **11** through the top hole with screw **F** and into the mark hole. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.




Turn both of the dividers over



Step 11

Prepare just 1 of the horizontals

Insert 4 large locking cam nuts **B** into 1 of the horizontals **16**.



Assembly Instructions

Step 12


Fit the horizontal to the right divider

Push the horizontal **16** onto the right divider **11**.

Tap 2 double metal dowels **O** through the right divider **11** and into the horizontal **16** until they "bottom out".

Turn the 2 large locking cam nuts **B** fitted to the horizontal **16** clockwise as far as they will go to secure the panels.


Important: Make sure there is no gap between the fitted panels.



Step 13

Fit 3 large wooden dowels

Tap 3 large wooden dowels **N** through the right divider **11** and into the horizontal **16** until they "bottom out".



Assembly Instructions


Step 14

Prepare the other horizontal

Insert 4 large locking cam nuts **B** into the horizontal **16**.

Push 4 of the quickfit dowels **A** as far as they will go into the horizontal **16**.

Tap 6 wooden dowels **M** into the horizontal **16**.



Step 15

Fit the horizontal to the right divider

Push the horizontal **16** onto the right divider **11**.


Turn the 2 large locking cam nuts **B** fitted to the horizontal **16** clockwise as far as they will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.



Carcase Assembly

<https://www.youtube.com/watch?v=9C7tgv5xnbE>




Step 16

Fit the cross rail

Push the cross rail **13** up against the right divider **11**.

Tap 2 large wooden dowels **N** through the right divider **11** and into cross rail **13** until they "bottom out".



Assembly Instructions

Step 17


Fit the left divider

Push the left divider **10** onto the assembly.

Tap 2 double metal dowels **O** through the left divider **10** and into the horizontal **16** at the top of the unit until they "bottom out".

Turn the 4 large locking cam nuts **B** fitted to the 2 horizontals **16** clockwise as far as they will go to secure the panels.


Important: Make sure there is no gap between the fitted panels.



Step 18

Fit 2 large wooden dowels


Tap 2 large wooden dowels **N** through the left divider **10** and into the cross rail **13** until they "bottom out".



Step 19

Fit 3 more large wooden dowels

Tap 3 large wooden dowels **N** through the left divider **10** and into the horizontal **16** until they "bottom out".




Assembly Instructions

Step 20

Prepare the 2 top rails

Tap 2 wooden dowels **M** into each of the 2 top rails **17**.




Step 21

Fit the 2 top rails

Push 1 of the top rails **17** onto the left divider **10**.

Push the other top rail **17** onto the right divider **11**.




Step 22

Prepare 1 of the narrow shelves

Insert 4 large locking cam nuts **B** into the narrow shelf **15**.

Push 2 of the quickfit dowels **A** as far as they will go into the narrow shelf **15**.

Tap 3 wooden dowels **M** into the narrow shelf **15**.



Assembly Instructions


Step 23

Fit the narrow shelf

Push the narrow shelf **15** onto the left divider **10**.

Turn the 2 large locking cam nuts **B** fitted to the narrow shelf **15** clockwise as far as they will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.




Step 24

Prepare the other narrow shelf

Insert 4 large locking cam nuts **B** into the narrow shelf **15**.

Push 2 of the quickfit dowels **A** as far as they will go into the narrow shelf **15**.

Tap 3 wooden dowels **M** into the narrow shelf **15**.




Step 25

Fit the narrow shelf

Push the narrow shelf **15** onto the right divider **11**.

Turn the 2 large locking cam nuts **B** fitted to the narrow shelf **15** clockwise as far as they will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.



Assembly Instructions


Step 26

Prepare the base

Insert 4 large locking cam nuts **B** into the base **7**.

Push 4 of the quickfit dowels **A** as far as they will go into the base **7**.


Tap 6 wooden dowels **M** into the base **7**.



Step 27

Fit the base

Push the base **7** onto the assembly and secure it using 4 screws **H**.



Note: To make it easier to fit the top and base panels, place polystyrene blocks from the packaging underneath the divider panels to raise the assembly.


Step 28

Prepare the back rails

Insert 2 large locking cam nuts **B** into each of the 2 back rails **14**.

Push 2 of the quickfit dowels **A** as far as they will go into each of the 2 back rails **14**.

Tap 2 wooden dowels **M** into each of the 2 back rails **14**.



x 2

Assembly Instructions

Step 29


Prepare the right side

Fit a rail holder **K** to the right side **9** through the top hole with screw **F** and into the mark hole drilled in the right side. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

C: Insert 2 large locking cam nuts **B** into the right side **9**.

Push 2 of the quickfit dowels **A** as far as they will go into the right side **9**.

Tap 3 wooden dowels **M** into the right side **9**.




Step 30

Fit the back rail to the right side

Push the back rail **14** onto the right side **9**.

Turn the large locking cam nut **B** fitted to the back rail **14** clockwise as far as it will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.




Assembly Instructions

Step 31

Fit the right side

Push the right side **9** onto the assembly.

Turn the 5 large locking cam nuts **B** clockwise as far as they will go to secure the panels.



Important: Make sure there is no gap between the fitted panels.


Step 32

Prepare the 2 plinths

Insert 2 large locking cam nuts **B** into the each of the 2 plinths **12**.

Push 2 of the quickfit dowels **A** as far as they will go into the each of the 2 plinths **12**.

Tap 2 wooden dowels **M** into the each of the 2 plinths **12**.



Assembly Instructions

Step 33


Prepare the left side

Fit a rail holder **K** to the left side **8** through the top hole with screw **F** and into the mark hole drilled in the left side. Make sure that it is fitted straight, in line with the panel edges and then fit another screw **F** using the lower hole.

C: Insert 2 large locking cam nuts **B** into the left side **8**.

Push 2 of the quickfit dowels **A** as far as they will go into the left side **8**.

Tap 3 wooden dowels **M** into the left side **8**.




Step 34

Fit the back rail to the left side

Push the back rail **14** onto the left side **8**.

Turn the large locking cam nut **B** fitted to the back rail **14** clockwise as far as it will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.




Assembly Instructions

Step 35

Fit the 2 plinths

Push the plinths **12** onto the right side **9**.

Turn the large locking cam nut **B** fitted to the to each of the plinths **12** clockwise as far as they will go to secure the panels.



Important: Make sure there is no gap between the fitted panels.

Note: Support the plinths until the left side has been fitted in the next step.

Assembly Instructions


Step 36

Fit the left side

Push the left side **8** onto the assembly.

Turn the 7 large locking cam nuts **B** clockwise as far as they will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.




Step 37

Fit the top

Push the top **6** onto the assembly.

Turn the 8 large locking cam nuts **B** clockwise as far as they will go to secure the panels.

Important: Make sure there is no gap between the fitted panels.



Assembly Instructions

Step 38



Squaring up a Robe and fitting the Back Panel
www.youtube.com/watch?v=udEKmXmPEW0

Fit the back panels

a: Square up the unit by making sure that measurement **x:x** equals **y:y**.



Place the large back **22** and the 2 small backs **21** down onto the unit as shown.

Make sure that the 3 backs are pushed up tight against each other and that they meet over the back edges of the dividers.

b: Nail **1** around the outside edges of the 3 backs.

Note: Do not nail where the backs meet. Nails should be spaced about 150mm apart.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y




Step 39

Secure the backs

Tap the nail screws **P** through the back holders **Q** and down between the backs **21** and **22** into the back edge of the divider.

Keep tapping the nail screws **P** in until the back holders **Q** dig into the small and large back.



Assembly Instructions

Step 40

Fit the 6 plastic nails


Tap 2 plastic nails **J** into the bottom edge of each side **8** and **9** as shown.

Tap 1 plastic nail **J** into each plinth **12** as shown.

Carefully stand the unit up for the next step.





Warning: The robe is heavy. Lift with care.



Step 41

Fit the hanging rails

Push the long hanging rail **23** and 2 short hanging rails **24** into the rail holders **K**.



Assembly Instructions

Step 42



Fit the drawers

Slide the wheels of the runners fitted to the drawers, over the wheels of the runners fitted to the side panels and push the drawers into position.



Fixing Bottom Mounted Runners

<https://www.youtube.com/watch?v=Z6lGMy19h7Q>



Step 43

Prepare the 4 doors


Push fit 3 hinges **T** into the left door **18**, the right door **19** and the 2 large doors **20**.

Secure each hinge by tightening up its 2 screws.



Pre-mounted Hinge Fitting & Adjustment

<https://www.youtube.com/watch?v=b4NeCGnpjP8>



Assembly Instructions

Step 44

Fit the doors and the handles

2 people are needed here

Fit 1 door **18**, **19** and **20** at a time, by lining up the 2 screws in the top hinge **T** with the 2 holes at the top of the panel and push them in. Tighten the 2 screws on the hinge.

Fix the bottom hinge next, followed by the other hinge.


Attach a handle **S** to each door using screws **D**.





Pre-mounted Hinge Fitting & Adjustment

<https://www.youtube.com/watch?v=b4NeCGnpjP8>

Press the screws into the holes in the panels



When the hinges have been pushed in, tighten up their screws



Assembly Instructions

Step 45

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.


d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



Pre-mounted Hinge Fitting & Adjustment

<https://www.youtube.com/watch?v=b4NeCGnpjP8>



Assembly Instructions


Step 46

Fit the 2 overbalance protector kits

To prevent possible overbalancing this unit **must be secured** to a suitable wall by fitting of the 2 overbalance protector kits **R** to the unit, or an alternative fixing method of your choice.

Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.



Assembly Instructions


Step 47

Fit the door buffers

Stick a door buffer **L** onto the top corner of each door **18**, **19** and **20** about 50mm in from the edge.

The other 2 door buffers are spare and you can use them wherever needed.

Assembly is complete



If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)
Alternatively, call the Spares Helpline on: 0370 112 1928.
For any other queries please contact the Customer Helpline on: 0345 640 2020

