


Anderson - 3+3 Sideboard

Assembly Instructions - Important: Retain these instructions
for future reference

609/6465

609/6458

HOME



WARNING!

In order to prevent overturning, this product must be
used with the 2 wall attachment devices provided

Dimensions

Width - 119.5cm

Depth - 40cm

Height - 77cm

More help is available throughout this
booklet by scanning in the QR codes
or typing in the links



MADE IN
BRITAIN

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk
or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0330 016 1114

For any other queries please contact the Customer Helpline on: 0345 640 2020



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 42kgs. Please lift with care.
- Assembly to be carried out by a competent adult only.
- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- During assembly children should be kept away from the product due to possible risk of injury.
- Installation shall only be carried out exactly according to the manufacturer's instructions - otherwise a safety risk can occur if incorrectly installed.

- Parts of the assembly will be easier with 2 people.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- **WARNING:** To prevent possible overbalancing this unit **must be secured** to a wall using the 2 overbalance protector kits supplied.
- Dispose of all packaging carefully and responsibly.
- Do not use this item if any components are missing or damaged.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- Regularly check all fastenings to ensure that they are properly tightened.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Tools required



Scissors



Flat-head screwdriver




Cross-head screwdriver



Hammer



Eye protection (when using a hammer or drill)



Electric drill (do not use for fitting screws)




Rule


Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


Please check you have all the panels listed below




1 Left Side (D2182A)
(74.7 x 37.5cm)



2 Right Side (D2183A)
(74.7 x 37.5cm)




3 Top (D2266A)
(119.3 x 39.6cm)




4 Base (D2268A)
(115.4 x 37.4cm)




5 Divider (D2260A)
(15 x 37.4cm)




6 Upright (D2267A)
(67.15 x 37.4cm)



7 Large Shelf (D2261A)
(76.2 x 36.8cm)



8 Small Shelf (D2271A)
(37.1 x 36.8cm)



9 Plinth (D2269A)
(115.4 x 6cm)



10 Drawer Front (D2263C)
(39 x 15.5cm) x 3



11 Left Drawer Side (WD330-115LH)
(33 x 11.5cm) x 3




12 Right Drawer Side (WD330-115RH)
(33 x 11.5cm) x 3




13 Drawer Back (W319-115)
(31.9 x 11.5cm) x 3



14 Drawer Base (T330-327G)
(33 x 32.7cm) x 3



15 Door (D2262A)
(52.4 x 39cm) x 3






















16 Back (X1181-705)
(118.1 x 70.5cm)



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A </p> <p>Wooden dowel (F22) x 4</p>	<p>B </p> <p>Metal dowel (F901) x 18</p>	<p>C </p> <p>40mm Screw (F910) x 1</p>	
<p>D </p> <p>Nail (F51) x 26</p>	<p>E </p> <p>Large locking cam nut (F900) x 12</p>	<p>F </p> <p>Small locking cam nut (F3) x 6</p>	
<p>G </p> <p>Knock-in Peg (F171) x 12</p>	<p>H </p> <p>13mm Screw (F63) x 24</p>	<p>I </p> <p>9mm Screw (F73) x 12</p>	
<p>J </p> <p>Shelf stud (F110) x 8</p>	<p>K </p> <p>Overbalance protector kit (F474) x 2</p>		
<p>L </p> <p>Hinge plate (F523) x 6</p>	<p>M </p> <p>Hinge (F518) x 6</p>		
<p>Oa  350mm long CL Runner (F422) x 3</p> <p>Ob  CR CR Runner (F424) x 3</p> <p>Oc  DL DL Runner (F425) x 3</p> <p>Od  DR DR Runner (F426) x 3</p>			<p>Na  Handle (F847a) x 6</p> <p>Nb  Handle Screw (F847b) x 12</p>

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1




Drawer Assembly

www.youtube.com/watch?v=3fYL5zB6ZYQ

Prepare the drawer fronts

Screw 2 metal dowels **B** into the holes shown on the back of each drawer front **10**.

Note: Tighten metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking cam nut **F** into the hole shown on the left drawer side **11** and right drawer side **12**.

Note: The arrow on the locking cam nut **must** point towards the hole in the edge of the panel.




Step 3

Attach the drawer sides to the drawer front

Push the left drawer side **11** and right drawer side **12** onto the back of the drawer front **10**.

Turn the small locking cam nuts **F** on the left drawer side **11** and right drawer side **12**.

Note: Turn the locking cam nuts **F** clockwise to secure panels - more than 1/2 a turn.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base **14** down the grooves in the drawer sides **11** and **12** and down into the groove in the drawer front **10**.




Step 5

Fit the drawer back

Fit the drawer back **13** between the drawer sides **11** and **12**.

Make sure that the drawer base **14** fits into the groove in the drawer back **13**.


Hold the drawer back **13** in position and tap the knock-in pegs **G** through the holes in the drawer sides **11** and **12**.



Step 6

Attach the handle

Attach a handle **N a** to each drawer front **10** using 2 screws **N b**.



Assembly Instructions

Step 7

Fit runners to the drawers


Turn the drawers over and fit the DL runner **Oc** to the bottom edge of the left drawer side **11**, as shown, making sure that it is pushed up against the back of the drawer front **10**. Use a bradawl to mark the fixing positions, then secure with 2 screws **H**.

Fit the DR runner **Od** to the bottom edge of the right drawer side **12** using the same method.



Fixing Bottom Mounted Runners

<https://www.youtube.com/watch?v=Z6lGMy19h7Q>



Step 8

Prepare the left side

Tap a wooden dowel **A** into the left side **1**.

Screw 3 metal dowels **B** into the left side **1**.

Insert a large locking cam nut **E** into the left side **1**.

Fit a CL runner **Oa** to the left side **1**.

The 1st screw **I** uses the 1st hole in from the front of the runner **Oa**.



The 2nd screw **I** uses the hole that lines up with the other panel hole.

Fit 2 hinge plates **L** onto the left side **1**, making sure that the slot is facing towards the finished front edge.





Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLBtg



Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.



Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Assembly Instructions

Step 9

Prepare the right side

Tap a wooden dowel **A** into the right side **2**.

Screw 3 metal dowels **B** into the right side **2**.




Insert a large locking cam nut **E** into the right side **2**.

Fit a CR runner **O b** to the right side **2**.

The 1st screw **I** uses the 1st hole in from the front of the runner **O b**.

The 2nd screw **I** uses the hole that lines up with the other panel hole.


Fit 2 hinge plates **L** onto the right side **2**, making sure that the slot is facing towards the finished front edge.



Step 10

Prepare the base

Insert 4 large locking cam nuts **E** into the base **4**.



Assembly Instructions


Step 11

Join the right side and base

Push the base **4** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking cam nuts **E** fitted to the base **4**.

Note: Turn the large locking cam nuts **E** as far as they will go - more than 1/2 a turn.




Step 12

Prepare the plinth

Tap 2 wooden dowels **A** into the plinth **9**.

Insert 2 large locking cam nuts **E** into the plinth **9**.




Step 13

Fit the plinth

Push the plinth **9** onto the right side **2**.

Use a screwdriver to tighten the large locking cam nut **E** fitted to the plinth **9**.




Assembly Instructions

Step 14

Fit the left side

Push the left side **1** onto the assembly.

Use a screwdriver to tighten the 3 large locking cam nuts **E** fitted to the base **4** and plinth **9**.




Step 15

Prepare the top

Screw 6 metal dowels **B** into the top **3**.

Fit the 2 brackets from the overbalance protector kits **K** to the shallow mark-holes drilled into the top **3** using 1 of their screws.

Note: Only fit 1 of the screws, the other 1 will be fitted later.



Assembly Instructions

Step 16

Prepare the divider

a: Insert 2 large locking cam nuts **E** into the divider **5**.

Note: The 2 holes for the large locking cam nuts may be drilled in either surface of the divider **5**.

b: Fit a CR runner **O b** to this surface of the divider **5**.


Note: Use the finished front edge to identify which runner to fit.

The 1st screw **I** uses the 1st hole in from the front of the runner.


The 2nd screw **I** uses the hole that lines up with the other panel hole.

c: Turn the divider **5** over and fit a CL runner **O a** to the other surface.

a:




b:



Turn the drawer divider over

c:



Assembly Instructions


Step 17

Fit the divider

Push the divider **5** onto the top **3**.

Use a screwdriver to tighten the 2 large locking cam nuts **E** fitted to the divider **5**.

Note: The 2 large locking cam nuts may be on either surface of the divider.



Step 18



Prepare the upright

a: Insert 2 large locking cam nuts **E** into the upright **6**.

Fit a CR runner **O b** to this surface of the upright **6**.

The 1st screw **I** uses the 1st hole in from the front of the runner.



The 2nd screw **I** uses the hole that lines up with the other panel hole.



Turn the upright over

b: Turn the upright **6** over and fit a CL runner **O a** to the other surface.

Fit 2 hinge plates **L** onto the upright **6**, making sure that the slot is facing towards the finished front edge.




Assembly Instructions

Step 19

Fit the upright

Push the upright **6** onto the top **3**.

Use a screwdriver to tighten the 2 large locking cam nuts **E** fitted to the upright **6**.




Step 20

Fit the top

Push the top **3** onto the side panels **1** and **2**.

Use a screwdriver to tighten the 2 large locking cam nuts **E** fitted to the side panels **1** and **2**.

Secure the upright **6** to the base **4** using screw **C**.



Assembly Instructions

Step 21

Fit back panel

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Place the back **16** down onto the unit, as shown.

Nail **D** around the outside edges of the back **16**.

Note: Nails should be spaced about 150mm apart.

Stand the unit up for the next step.




Warning: The unit is heavy. Lift with care.



Squaring up a Chest and fitting the Back Panel

www.youtube.com/watch?v=Feal6541z7o

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 22

Secure the unit to a wall

a: Before fitting the unit to a wall, use a spirit level to check the top of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level.

To prevent possible overbalancing this unit **must be secured** to a suitable wall by fitting of the 2 overbalance protector kits **K** to a wall.

b: Push the unit up against the wall and slide the brackets against the wall. Fit the 2nd screw into the underside of the top panel.


Mark the slot at the back of the brackets for drilling into the wall.

Wall fixings are not supplied as they will need to suit the wall type.


Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

WARNING!
In order to prevent overturning this product must be used with the 2 wall attachment devices provided


a:



b:




See the next page for a guide to wall mounting and fixings



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:  Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.


Assembly Instructions

Step 23

Fit the shelf

Insert 8 shelf studs **J** at the required height for the large shelf **7** and the small shelf **8**.

Lower the large shelf **7** and small shelf **8** down onto the shelf studs **J**.



Step 24

Prepare the doors

Push fit 2 hinges **M** into each of the doors **15**.


Secure each hinge with 2 screws **H**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.



Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLBtg



Assembly Instructions

Step 25

Drill the handle holes in the door

Important: Please follow these instructions carefully.

Lay the doors **15** down onto a smooth surface.

Important: Check that the holes and hinges are in the same place as the diagrams.


Note: We recommend the use of a small piece of waste wood, placed behind the hole while drilling, to reduce the possibility of any breakout.

Using the pilot hole in the rear face of the door **15**, drill through the holes indicated opposite, using a 2.5mm diameter drill.


Turn the door **15** over and open out the 2.5mm holes that you have just drilled by drilling back through them with a 5mm drill.

IMPORTANT
You will need to drill the doors to suit the handles supplied

You will need to drill 2 doors as shown in this diagram



You will need to drill 1 door as shown in this diagram



Assembly Instructions

Step 26

Fit doors and handles

Note: The easiest way to attach each door **15** is to fit the top hinge first, then align and fit the other hinge.

a: Push the hinge **M** onto the front part of the hinge plate **L**.
The recess at the bottom of screw B goes into the slot in the hinge plate.

b: Keep the hinge **M** FLAT against the hinge plate **L** as you slide it across as far as it will go. Tighten screw A.



c: The hinge **M** must be flat against the hinge plate **L** prior to any adjustment.

d: The hinge **M** must NOT be AT AN ANGLE to the hinge plate **L** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **Na** to each door **15** using 2 screws **Nb**.



Hinge Fixing and Door Adjustment
www.youtube.com/watch?v=wIMhUHeLBtg



Assembly Instructions

Step 27

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.


d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.



Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLbtg



Assembly Instructions

Step 28



Fit the drawers

Slide the wheels of the runners fitted to the drawers, over the wheels of the runners fitted to the side panels and push the drawers into position.




Fixing Bottom Mounted Runners

<https://www.youtube.com/watch?v=Z6lGMy19h7Q>



Assembly Instructions

Step 29



Assembly is complete

Please remove any blue protective film from panel edges and clear protective film from panel surfaces

