

Venetia - Shoe Storage

Assembly Instructions - Important: Retain these instructions for future reference

906/5716


323/9603

541/8745


709/8675

792/4543

HOME



Woodgrain
and Black



White
and Grey

WARNING!

In order to prevent overturning, this product must be used with the wall attachment device provided

Dimensions

Width - 80cm

Depth - 33cm

Height - 86cm

More help is available throughout this booklet by scanning in the QR codes or typing in the links



**MADE IN
BRITAIN**

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, please visit www.argos-support.co.uk or email: Help@ClickSpares.co.uk (quoting your original order number)

Alternatively, call the Spares Helpline on: 0330 016 1114

For any other queries please contact the Customer Helpline on: 0345 640 2020

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- **Warning:** This unit weighs approximately 28kgs. Please lift with care.
- Assembly to be carried out by a competent adult only.
- Check you have all the components and tools listed on pages 1, 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- During assembly children should be kept away from the product due to possible risk of injury.
- Installation shall only be carried out exactly according to the manufacturer's instructions - otherwise a safety risk can occur if incorrectly installed.

- Parts of the assembly will be easier with 2 people.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



- We do not recommend the use of power drill/drivers **for inserting screws**,


as this could damage the unit. Only use hand screwdrivers.

- **WARNING:** To prevent possible overbalancing this unit **must be secured** to a wall using the overbalance protector kit supplied.
- Dispose of all packaging carefully and responsibly.
- Do not use this item if any components are missing or damaged.


Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- Regularly check all fastenings to ensure that they are properly tightened.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Tools required



Rule



Bradawl



Flat-head screwdriver



Cross-head screwdriver



Scissors



Spirit level



Hammer



Square



Eye protection (when using a hammer or drill)




Electric drill (do not use for fitting screws)


Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


Please check you have all the panels listed below



1 Left Side (*D0844B*)
(83 x 31.2cm)




2 Right Side (*D0845B*)
(83 x 31.2cm)




3 Top (*D0846B*)
(79.7 x 32.9cm)



4 Base (*D0847B*)
(79.7 x 32.9cm)




5 Loose Shelf (*D0850B*)
(76 x 31.2cm) x 3




6 Woodgrain or Black
Drawer Front (*DF-00010116*)
(78.6 x 13.8cm)


OR



6 White or Grey
Drawer Front (*D3060B*)
(78.6 x 13.8cm)




7 Woodgrain or Black
Left Door (*DF-00010117*)
(68.3 x 39.2cm)




8 Woodgrain or Black
Right Door (*DF-00010118*)
(68.3 x 39.2cm)


OR



7 White or Grey
Left Door (*D3061A*)
(68.3 x 39.2cm)




8 White or Grey
Right Door (*D3062A*)
(68.3 x 39.2cm)



9 Drawer Wrap (*WRP-00000036*)
(135.45 x 9.5cm)



10 Drawer Base (*TDF-00020844*)
(74.05 x 29.3cm)






















11 Back (*X852-788*)
(85.2 x 78.8cm)




Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

| | | |
|---|--|---|
| A  Metal dowel (F901) x 6 | B  Large locking cam nut (F900) x 4 | C  Small locking cam nut (F3) x 2 |
| D  Nail (F51) x 22 | E  40mm Screw (F910) x 4 | F  25mm Screw (F615) x 6 |
| G  Shelf stud (F110) x 12 | H  13mm Screw (F63) x 8 | I  9mm Screw (F74) x 2 |
| J  9mm Screw (F73) x 4 | K  Plastic Nail (F91) x 4 | L  Overbalance protector kit (F474) x 1 |
| M  Hinge plate (F523) x 4 | N  Hinge (F518) x 4 | |
| O  Drawer runner (F1004) x 2 | | P  Door Stop (F464) x 5 |
| Q  WOODGRAIN and BLACK Handle (F236) x 3 | | R  Wedgefix (F639) x 4 |
| OR  WHITE and GREY Handle (F315) x 3 | | |

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1


Prepare the drawer front

a: Screw 2 metal dowels **A** into the holes shown on the back of the drawer front **6**.

Note: Tighten the metal dowels up fully against the panel.

b: Screw 5 shelf studs **P** into the drawer front **6**.

Note: Tighten the metal dowels and shelf studs up fully against the panels.




Step 2

Prepare the drawer wrap

Insert 2 small locking cam nuts **C** into the holes shown on the drawer wrap **9**.

Note: The arrow on the locking cam nut **must** point towards the hole in the edge of the panel.



Assembly Instructions


Step 3

Assemble the drawer

a: Place the drawer base **10** into the narrow slot on the drawer wrap **9**. Fold the wrap around the base.

b: Turn the drawer wrap assembly over and push it onto the back of the drawer front **6**.


Turn the locking cam nuts **C** clockwise to secure panels - more than 1/2 a turn.



Step 4

Adjust the drawer base


Ensure the drawer base sits flush by turning the shelf studs clockwise or anti-clockwise.




Step 5

Fit the wedgfixes

Turn the drawer assembly over and slide 4 wedgfixes **R** into the back and side grooves, as shown, and tighten up the screws.



Important: Make sure that the drawer assembly is square before fitting the wedgfixes.




Assembly Instructions

Step 6

Attach the handle

Attach a handle **Q** to the drawer front **6** using 2 screws **F**.



This shows the handle for a Woodgrain or Black unit. You may have the White or Grey unit.

Step 7


Fit runners to left side

a: Place a runner **O** on the left side **1**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.




Fitting Ball Bearing Runners

www.youtube.com/watch?v=yG4xtiJJeSg



b: Slide the runner back the other way and fit the 2nd screw **J** into the corresponding hole in the left side **1**.



c: Insert 2 large locking cam nuts **B** into the left side **1**.




Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLBtg

Note: The arrow on the locking cam nut **must** point towards the hole in the edge of the panel.

Fit 2 hinge plates **M** onto the left side **1**, making sure that the slot is facing towards the finished front edge.




Assembly Instructions


Step 8

Fit runners to right side

a: Place a runner **O** on the right side **2**. Slide back the top of runner and use the 2nd hole from the front to fit the 1st screw **J**.




b: Slide the runner back the other way and fit the 2nd screw **J** into the corresponding hole in the right side **2**.



c: Insert 2 large locking cam nuts **B** into the right side **2**.

Note: The arrow on the locking cam nut **must** point towards the hole in the edge of the panel.

Fit 2 hinge plates **M** onto the right side **2**, making sure that the slot is facing towards the




Assembly Instructions

Step 9

Prepare the top

Note: The top and base panels are very similar but, the holes in the top panel are not drilled all the way through.

Screw 4 metal dowels **A** into the holes shown on the top **3**.




Step 10

Join the top and right side

Push the top **3** onto the right side **2**.

Use a screwdriver to tighten the 2 large locking cam nuts **B** fitted to the right side **2**.

Note: Turn the large locking cam nuts **B** as far as they will go - more than 1/2 a turn.



Assembly Instructions


Step 11

Fit the left side

Push the left side **1** onto the top **3**.

Use a screwdriver to tighten the 2 large locking cam nuts **B** fitted to the left side **1**.


Note: Turn the large locking cam nuts **B** as far as they will go - more than 1/2 a turn.



Step 12

Fit the base

Attach the base **4** to the left side **1** and right side **2** using 4 screws **E**.




Assembly Instructions

Step 13

Fit the plastic nails

Tap the plastic nails **K** into the base **4** as shown.

The plastic nails **K** must go up into the bottom edge of the left side **1** and right side **2**.



Step 14

Fit the back

a: Square up the unit by making sure that measurement **x to x** equals **y to y**.

b: Place the back **11** onto the unit.

Nail **D** around the outside edges of the back **11**.

Note: Nails should be spaced about 150mm apart.

Carefully stand the unit up for the next step.





Warning: The unit is heavy. Lift with care.



Squaring up a Chest and fitting the Back Panel

www.youtube.com/watch?v=Feal6541z7o

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Assembly Instructions

Step 15

Fit the overbalance protector kits

a: Before fitting the overbalance protector kit, use a spirit level to check the top of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level.

To prevent possible overbalancing this unit **must be secured** to a suitable wall by fitting of the overbalance protector kit **L** to the unit.

b: Push the unit up against the wall and fit the 1st screw through the bracket and up into the shallow mark-hole drilled into the underside of the top panel.

Slide the bracket against the wall and fit the 2nd screw into the underside of the top panel.

Mark the slot at the back of the bracket for drilling into the wall.


Wall fixings are not supplied as they will need to suit the wall type.

Note: Take care when drilling the wall that you do not drill into any pipes, wires etc. If in doubt, consult an expert.

WARNING!

In order to prevent overturning this product must be used with the wall attachment device provided




a:




Note: The 1st screw uses the shallow mark-hole drilled into the underside of the top panel

See the next page for a guide to wall mounting and fixings

b:




Cut-out in back panel



A Guide to Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:  Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.


Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.

Assembly Instructions

Step 16

Fit the shelf studs

For each of the 3 shelves **5**, insert 4 shelf studs **G** at the required height.




Make sure that the plastic sleeve is fully pushed onto the shelf stud.



Step 17

Fit the shelves

Lower the 3 shelves **5** down onto the shelf studs **G**.



Assembly Instructions

Step 18

Fit the drawer

Slide both the runners ① forward and locate the sides of the drawer wrap ⑨ between them, lining up the holes in the drawer sides with the 2nd 'threaded' holes in the runners ①.

Working from the inside of the drawer, insert 2 screws ① through the drawer sides and out into the 2nd threaded hole in the runner ①.

Note: Do not overtighten the screws ①.

If they catch on the runner ① you may need to loosen them slightly.





Fitting Ball Bearing Runners

www.youtube.com/watch?v=yG4xtiJJeSg

This shows the Woodgrain and Black unit.
You may have the White or Grey unit.

Warning: Use a screwdriver to position the runners as they could have sharp edges



Assembly Instructions

Step 19

Prepare the doors

Push fit 2 hinges **N** into each door **7** and **8**.



Secure each hinge with 2 screws **H**.

Note: Before securing with the screws, make sure that the hinges are positioned at 90 degrees with the edge of the door.




Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLBtg



Note: The right door **8** has a shallow identification hole between the 2 handle holes.



Assembly Instructions

Step 20

Fit doors and handles

Note: The easiest way to attach each door **7** and **8** is to fit the top hinge first, then align and fit the other hinges.

a: Push the hinge **N** onto the front part of the hinge plate **M**. The recess at the bottom of screw B goes into the slot in the hinge plate.

b: Keep the hinge **N** FLAT against the hinge plate **M** as you slide it across as far as it will go. Tighten screw A.

c: The hinge **N** must be flat against the hinge plate **M** prior to any adjustment.


d: The hinge **N** must NOT be AT AN ANGLE to the hinge plate **M** when assembled. This would indicate that the recess at the bottom of screw B had not located in the slot in the hinge plate and the hinge would not be secure. Remove the hinge from the hinge plate and then re-assemble being careful to follow instructions a-c.

e: Attach a handle **Q** to each door **7** and **8** using 2 screws **F**.




Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLBtg



This shows the handles for the Woodgrain or Black unit.
You may have the White or Grey unit.



Note: The right door **8** has a shallow identification hole between the 2 handle holes.

Assembly Instructions

Step 21

Adjust the doors if needed

a: Before adjusting the doors, use a spirit level to check the base (or top) of the unit is level, front-to-back and side-to-side in the 3 positions shown. Use suitable packing pieces (not supplied) to make the unit level BEFORE making any adjustment to the hinges, as shown.

b: Height adjustment.

Loosen screws A on hinge plates and move door up or down as required. Retighten screw A.

c: Forward and Back adjustment.

Loosen screw B on hinge plate and move door in or out as required. Retighten screw B.


d: Sideways adjustment.

To move door 'out' loosen screw C. To move door 'in' tighten screw C.




Hinge Fixing and Door Adjustment

www.youtube.com/watch?v=wIMhUHeLBtg




Assembly Instructions

Step 22



Woodgrain
and Black

White
and Grey



Assembly is complete

Please remove any blue protective film from panel edges and clear protective film from panel surfaces

