

**NOTE:**  
Please read all  
instructions carefully  
before using this product

Table of Contents

Safety Notice

Important Assembly  
Information

Care and Maintenance

Warranty

Ordering Parts

Model TR8001

Retain This  
Manual for  
Reference

010220

**OWNER'S  
MANUAL**



**MARCY®**

## **Mini Folding Trampoline with Support Frame**



**IMPORTANT:** Please read this manual before commencing assembly of this product.

**Pure-Tec Limited**

**[www.puretecfitness.com](http://www.puretecfitness.com)**

**Tel: +44 (0) 1482 212098**

**Email: [service@puretecfitness.com](mailto:service@puretecfitness.com)**

**Monday – Friday 0900 – 1700 GMT**

---

## TABLE OF CONTENTS

IMPORTANT SAFETY NOTICES.....	2
ASSEMBLY INSTRUCTIONS.....	3
CLOSING INSTRUCTIONS.....	4
ATTACHING THE STABILISER FRAME.....	5
WARRANTY.....	6
ORDERING PARTS .....	6

---

## BEFORE YOU BEGIN

Thank you for selecting the MARCY Folding Mini Trampoline with Support Frame. For your safety and benefit, please read this manual carefully before using the equipment. As the official representative for Marcy, we are committed to providing complete customer satisfaction. If you have any questions, or find there are missing or damaged parts, please contact our Customer Solutions Department who will provide immediate assistance.

## CARE & MAINTENANCE

1. Lubricate moving parts with WD-40 or light oil periodically.
2. Inspect and tighten all parts before using the equipment.
3. The equipment can be cleaned using a damp cloth and mild non-abrasive detergent. DO NOT use solvents.
4. Examine the equipment regularly for signs of damages or wear.
5. Replace any defective components immediately and/or keep the equipment out of use until repair.
6. **Failure to examine regularly may affect the safety level of the equipment.**

<p><b>Pure-Tec Limited</b></p> <p><b><a href="http://www.puretecfitness.com">www.puretecfitness.com</a></b></p> <p><b>Tel: +44 (0) 1482 212098</b></p> <p><b>Email: <a href="mailto:service@puretecfitness.com">service@puretecfitness.com</a></b></p> <p><b>Monday - Friday 9 a.m.-5 p.m. GMT</b></p>
--

## IMPORTANT SAFETY NOTICES

This exercise equipment is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble or operate your equipment. In particular, note the following safety precautions:

1. Keep children and pets away from the equipment at all times. DO NOT leave children unattended in the same room with the equipment.
2. Only one person at a time should use the equipment.
3. If the user experiences dizziness, nausea, chest pain, or any other abnormal symptoms, STOP the workout at once. CONSULT A DOCTOR IMMEDIATELY.
4. Position the equipment on a clear, leveled surface. DO NOT use the equipment near water or outdoors.
5. Keep hands away from all moving parts.
6. Always wear appropriate workout clothing when exercising. DO NOT wear robes or other clothing that could become caught in the equipment. Running or aerobic shoes are also required when using the equipment.
7. Use the equipment only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer.
8. Do not place any sharp object around the equipment.
9. Disabled persons should not use the equipment unaided.
10. Before using the equipment to exercise, always do stretching exercises to properly warm up.
11. Never operate the equipment if the equipment is not functioning properly.
12. This equipment is designed and intended for home and consumer use only, not for commercial use.

**WARNING: BEFORE BEGINNING ANY EXERCISE PROGRAMME, CONSULT YOUR DOCTOR. THIS IS ESPECIALLY IMPORTANT FOR INDIVIDUALS OVER THE AGE OF 35 OR PERSONS WITH PRE-EXISTING HEALTH PROBLEMS. READ ALL INSTRUCTIONS BEFORE USING ANY FITNESS EQUIPMENT. PURETEC ASSUMES NO RESPONSIBILITY FOR PERSONAL INJURY OR PROPERTY DAMAGE SUSTAINED BY OR THROUGH THE USE OF THIS PRODUCT.**




**PLEASE TAKE EXTRA CARE WHEN CLOSING OR FOLDING THE TRAMPOLINE. PURETEC CANNOT BE HELD LIABLE FOR DAMAGE CAUSED TO THE TRAMPOLINE BY NOT FOLLOWING THE DIRECTIONS AND ARROW LABELS ON THE FRAME.**

**MAXIMUM USER WEIGHT 115kg**

**SAVE THESE INSTRUCTIONS.**

## OPENING THE TRAMPOLINE

1. Lay the Marcy Trampoline on the floor, in it's still folded position which looks like an oval shape as shown in Image 1. Push out the ends according to the arrows on the picture in Image 1, and the trampoline expands into a semi circle as shown in Image 2. Now ensure the larger outer hinges are touching the floor as in Image 3.



2. Firmly grasp both halves of the frame at the midpoint of each half circle according to the arrows and pull out.  
**Note: Frame will snap open so please read step no.3 carefully. Please keep all fingers away from hinge when opening and closing.**
3. Using steady pressure, with hands open and fingers extended, use palm of hands to push top side of frame up, over and down to open position.
4. With the Marcy Trampoline now open and still upside down, lift the 6 legs to a perpendicular position (up and over its holding platform pin).  
**Note: Be careful not to catch spring cover fabric.**
5. Turn the Marcy Trampoline right side up, and attach the fabric of the skirt evenly around the jumping mat so that the skirt covers all the springs in an even manner. Please note the holes in the fabric skirt should be underneath the springs.
6. Proceed to page 5 for stabilizing bar assembly instructions.

## CLOSING THE TRAMPOLINE

**Important Safety Note: Always close your Marcy Trampoline with 2 people.**


1. Remove fabric skirt to allow easier folding
2. Turn the unit upside down and lay it flat.
3. Pull the 6 legs up and over it's platform pin and lay it down towards the center of the mat.

**Note: Extend the leg spring only enough to get it up and over the platform pin. Do not over extend.**

4. Locate the larger hinges on each side of the trampoline. Stand near the hinges on opposite sides of the Marcy Trampoline facing the upper half of the frame (Image A).




5. Both people kneel facing the "top half" of the Marcy Trampoline placing their knees approximately 5cms below the hinge (Image B).



6. Both people lean forward placing their outside hand on the ground and use their inside hand to grasp the frame at the top of the Marcy Trampoline (Image C).



7. Together pull up gently on the frame and the top half of the frame will raise toward the middle. Ensure that your hands are clear of the moving frame (Image D, Image E). Note: Watch out for your hands, feet and other body part, etc. Always have 2 people to fold the Marcy Trampoline.



8. Once the Marcy Trampoline is folded (now looks like a half moon), simply push the two ends inwards to make the rebounder smaller (the shape will look like a rugby ball). (Image F).




Image D



Image E




Image F

## ATTACHING THE STABILISER FRAME

1. Now find the two bottom halves of the stabilising bar. You will see that the Trampoline surface has two legs with attachments. These are the openings that you will use to place the stabilising bar's two bottom halves. Take the end that slides into the leg attachment and securely place it in the attachment opening (Image 1).

Image 1



2. Repeat step 2 for the second bar.


Image 2



3. This is how the Marcy Trampoline should look after step 2 (Image 2).

4. Find the two parts that make up the top of the stabilising bar and tightly lock both padded ends together (Image 3).

Image 3



5. Now place both ends of the top half of the stabilising bar on the openings of the two bottom halves (Image 4).

Image 4




6. After making sure that all of the parts are tightly secured your Marcy Trampoline should look like the picture (Image 5).

Image 5



The use of the hook is to hitch the spring to the hole on the legs in the event the spring requires re-attaching



# LIMITED WARRANTY

Pure-Tec. warrants this product to be free from defects in workmanship and material, under normal use and service conditions. Please refer to [www.puretecfitness.com](http://www.puretecfitness.com) for warranty conditions. This warranty extends only to the original purchaser and is **valid for home use only**. Pure-Tec's obligation under this Warranty is limited to replacing damaged or faulty parts at Pure-Tec's option.

All returns must be pre-authorized by Pure-Tec. **This warranty does not extend to any product or damage to a product caused by or attributable to freight damage, abuse, misuse, improper or abnormal usage, purchasers own repairs or for products used for commercial or rental purposes.** No other warranty beyond that specifically set forth above is authorized by Pure-Tec.

Pure-Tec is not responsible or liable for indirect, special or consequential damages arising out of or in connection with the use or performance of the product or other damages with respect to any economic loss, loss of property, loss of revenues or profits, loss of enjoyments or use, costs of removal, installation or other consequential damages or whatsoever natures.

The warranty extended hereunder is in lieu of any and all other warranties and any implied warranties of merchantability or fitness for a particular purpose is limited in its scope and duration to the terms set forth herein.

Your statutory rights are not affected.

## **ORDERING REPLACEMENT PARTS**

**Replacement parts can be ordered by contacting our Customer Solutions Department,**

[www.puretecfitness.com](http://www.puretecfitness.com)

Email: [service@puretecfitness.com](mailto:service@puretecfitness.com)

**When ordering replacement parts, please give the following information,**

1. Model
2. Description of Parts
3. Part Number
4. Date of Purchase

### PLEASE NOTE:

IF YOU CLOSE OR FOLD THE MARCY TRAMPOLINE THE INCORRECT WAY NOT FOLLOWING THE DIRECTIONS AND ARROWS ON THE FRAME RESULTING IN DAMAGE TO THE UNIT. MARCY WILL NOT BE HELD RESPONSIBLE AND THE WARRANTY MAY BECOME INVALID.