



3+
YEARS**TOOLS REQUIRED**

(SUPPLIED)

**CONTENTS:**

1. Frame assembly
2. Front wheel assembly
3. Handlebar
4. Steering stem
5. Rear axle (with 4 washers and 2 nuts)
6. Plastic clamp cover
7. Clamp assembly
8. Handlebar bolt, washer and nuts (x2)
9. Large washer (x2)
10. Plastic nut cover (x2)
11. Rear wheel (x2)
12. Plaque (may differ from that illustrated)



Three Wheel Scooter

This scooter must be assembled by an adult.



Check the contents and only remove the protective packaging from each item as and when it is to be fitted.

Please keep the packaging until you have completely assembled the scooter.


Please remove all packaging before giving to a child.

ASSEMBLING THE HANDLEBAR AND FRONT WHEEL

1. Place the handlebar onto the steering stem with the recessed holes facing upwards. Insert the bolts, add the washers, attach the nuts and tighten using one of the spanners provided.
2. Place one large washer onto the fork stem then insert the fork stem through the head tube with the slot in the stem facing rearwards.
3. Place the other large washer onto the fork stem followed by the clamp assembly with the open part facing rearwards.
4. Push the clamp assembly down against the large washer and partly tighten until it lightly nips the fork stem.
5. Slide the plastic clamp cover loosely onto the steering stem and insert it into the fork stem.
6. Set the steering stem to the desired height, ensure it is in between the maximum and minimum insertion mark, check that the wheel is straight in relation to the footplate, then tighten the clamp bolt using one of the spanners provided.
7. Slide the plastic clamp cover down to cover the clamp assembly.

**ASSEMBLING THE REAR WHEELS**

1. Slide the rear axle through the holes so that it protrudes equally at each side of the rear tube insert.
2. Slide the 2 spacers and a wheel (with inner wheel hub facing inwards) onto each end of the rear axle.
3. Slide one nut to each end of rear axle and tighten them both at the same time using the tools provided.
4. Push the plastic nut covers over the nuts.

**SAFETY ADVICE**

This is a three wheel self propelled scooter designed for a single rider only.

It is not intended or equipped for road use, off road use, racing, jumping, stunt riding or use with any motorised device.

NOTE

It should never be ridden by more than one person at a time. Never ride at night, obey all traffic and pedestrian regulations, and give right of way to pedestrians.

Care should be taken when riding on wet pavements as braking action and wheel traction may be reduced.

Never leave your scooter unlocked and unattended.

FOR YOUR CHILD'S SAFETY

Recheck that all screws, nuts and bolts are firmly tightened.

Make sure that your child is capable of riding this scooter.

Do not allow your child to ride unsupervised.

SCOPE AND LIMITED WARRANTY

This warranty does not cover damage or loss from accidents, normal wear, improper assembly or adjustment, jumping, stunt riding, racing or competition, abuse, neglect or when used with any motorised device.

Design and specification may vary.

Please retain this leaflet for reference to the manufacturer.

Made in China to European Safety Standards.

DISTRIBUTED BY

**MV SPORTS & LEISURE LTD**35 Tameside Drive • Castle Bromwich • Birmingham
B35 7AG • UK

www.mvsports.com




The CE mark denotes compliance with the standards laid down by the EC (European Community).

ATTACHING THE PLAQUE

Clip the plaque onto the handlebar.

Please note, the plaque supplied may differ from that shown.


**ASSEMBLED SCOOTER****SAFETY FIRST**

Please check all fixings are secure before handing to a child.

WARNING: Protective equipment should be worn. Not to be in traffic. 20 kg max.

MV recommends the use of protective pads and helmet when using this product.

The toy shall be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and third parties.

**A GUIDE TO SAFE CYCLING & SCOOTERING**

- 1 We recommend this scooter is for pavement use only. It is dangerous to ride on a public highway.
- 2 Do not ride at night. Visibility is often limited at dawn and dusk.
- 3 Always give pedestrians right-of-way and don't ride too close to them. Never park your bicycle or scooter where it can cause a nuisance.
- 4 Avoid hazards that may cause you to lose control of your bicycle or scooter such as pot holes, uneven pavements and manhole covers.
- 5 Leave plenty of room when passing parked vehicles and watch out for doors being opened in your path.
- 6 Remember that braking distance should be increased in wet weather, and regular checks of brakes, steering and lighting should be made.
- 7 Never carry passengers on your bicycle or scooter. Never carry packages in your hands while riding or fix anything to your bicycle or scooter that could obstruct your visibility or control.
- 8 Do not wear anything that restricts your hearing.
- 9 Always ride with both hands on the handlebars.
- 10 Do not wear very loose clothing which could hang down and become caught in the wheels. Wear cuff bands or trouser clips to keep your trousers from getting caught in the chainwheel.
- 11 We recommend that light-coloured or fluorescent clothing be worn which helps others to see you in daylight and poor light.
- 12 Always wear proper safety equipment. We recommend a helmet, long-sleeved shirt, long trousers, shoes, elbow pads and knee pads. Gloves and eye protection also make good sense. Cover your handlebars, stem and top tube with safety pads for extra protection.
- 13 Do not ride your bicycle if the chain cover is not attached

Please refer to the Highway Code regarding rules for cyclists

CUSTOMER SERVICES

MV has taken great care to ensure that this item has reached you in good condition. Should you have a query please contact: customer.services@mvsports.com where your query will be dealt with promptly. Alternatively, you can call on 0870 8404255.