

Energy fiche

| | | | |
|---|---|----------------------|--------------------|
| | Brand | | BUSH |
| | Model | | AG56TBX AG56TWX |
| | Type of Oven | | GAS |
| | Mass | kg | 39,0(+/-2) |
| Upper Cavity | Energy Efficiency Index - conventional | | - |
| | Energy Efficiency Index - fan forced | | - |
| | Energy Class | | - |
| | Energy consumption (gas) - conventional | MJ/cycle - kWh/cycle | |
| | Energy consumption (gas) - fan forced | MJ/cycle - kWh/cycle | - |
| | Heat Source | | GAS |
| | Volume | l | 29 |
| Lower Cavity | Energy Efficiency Index - conventional | | 81,1 |
| | Energy Efficiency Index - fan forced | | - |
| | Energy Class | | A+ |
| | Energy consumption (gas) - conventional | MJ/cycle - kWh/cycle | 4,75 1,32 |
| | Energy consumption (gas) - fan forced | MJ/cycle - kWh/cycle | - |
| | Heat Source | | GAS |
| | Volume | l | 53 |
| | Number of cavities | | 2 |
| | This oven complies with EN 15181 | | |
| <p>Energy Saving Tips</p> <p>Oven</p> <ul style="list-style-type: none"> - Cook the meals together, if possible. - Keep the pre-heating time short. - Do not elongate cooking time. - Do not forget to turn-off the oven at the end of cooking. - Do not open oven door during cooking period. | | | |